

Modular PLCs XControl:
XC-104-...
XC-204-...
XC-303-...

**EATON***Powering Business Worldwide*

All proprietary names and product designations are brand names or trademarks registered to the relevant title holders.

After-sales service and support

Please contact your local office:

Eaton.com/AfterSales

Original manual

This document was originally written in German.

All versions of this document other than those in German are translations of the original German manual.

1. edition 2018, publication date 11/17
2. edition 2022, publication date 08/22
3. edition 2024, publication date 08/24
4. edition 2025, publication date 08/25

© 2017 by Eaton Industries GmbH, 53105 Bonn

All rights, including those of translation, reserved.

No part of this manual may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, micro-filming, recording or otherwise, without the prior written permission of Eaton Industries GmbH, Bonn.

Subject to alteration.



Danger! **Dangerous electrical voltage!**

Before commencing the installation

- Disconnect the power supply of the device.
- Secure against retriggering
- Verify isolation from the supply
- Ground and short-circuit
- Cover or enclose neighbouring units that are live.
- Follow the mounting instructions (AWA/IL) for the device.
- Only suitably qualified personnel in accordance with EN 50 110-1/-2 (VDE 0105 Part 100) may work on this device/system.
- Before installation and before touching the device ensure that you are free of electrostatic charge.
- The functional earth (FE) must be connected to the protective earth (PE) or to the equipotential bonding. The system installer is responsible for implementing this connection.
- Connecting cables and signal lines should be installed in such a way that inductive and capacitive interference will not have a negative impact on the automation functions.
- Install automation devices and related operating elements in such a way that they are well protected against unintentional operation.
- Suitable safety hardware and software measures should be implemented for the I/O interface so that cable or wire breakage on the signal side will not result in undefined states in the automation devices.
- Ensure a reliable electrical isolation of the low voltage for the 24 V supply. Only use power supply units complying with IEC 60364-4-41 or HD 384.4.41 S2 (VDE 0100 Part 410).
- Deviations of the mains voltage from the nominal value must not exceed the tolerance limits given in the specifications, otherwise this may result in malfunction and hazardous states.
- Emergency stop devices complying with IEC/EN 60204-1 must remain functional in all of the automation devices' operating modes. Unlatching the emergency stop devices must not result in an automatic restart.
- Built-in devices for enclosures or cabinets must only be run and operated in an installed state; desktop devices and portable devices only when the housing is closed.
- Measures should be taken to ensure the proper restarting of programs interrupted after a voltage dip or outage. This should not result in dangerous operating states even for a short time. If necessary, emergency stop devices should be implemented.
 - Wherever faults in the automation system may cause damage to persons or property, external measures must be implemented to ensure a safe operating state in the event of a fault or malfunction (for example, by means of separate limit switches, mechanical interlocks, etc.).

Content

0	About this manual	6
0.1	Target group	6
0.2	List of revisions	7
0.3	Additional documentation	7
0.4	Legal disclaimer	8
0.5	I/O system XN300	8
0.6	Writing conventions	9
1	Description of the PLCs	10
1.1	System overview	10
1.2	Communications and interfaces - decentralized expansion	11
1.3	Intended use	12
1.4	Versions	13
1.4.1	XC-104-... and XC-204-...	13
1.4.2	XC-303-...	14
1.5	Key to XControl part numbers	16
1.5.1	Device Version Number	16
1.6	Functionality	17
1.6.1	Power Supply	17
1.6.2	Local inputs/outputs	17
1.6.3	Processor unit	18
1.6.4	Device interfaces	20
2	Installation	30
2.1	Control panel layout	30
2.1.1	Ventilation	30
2.2	Mounting XControl	31
2.3	Uninstalling and disassembly (using the XControl as an example)	35
2.4	Connection terminals	37
2.5	Potential relationship between the components	38
2.6	Wiring in accordance with EMC requirements	39
2.6.1	Cable routing and wiring	41
2.6.2	Suppressor circuit for interference sources	41
2.6.3	Screen earth kit	41
2.7	Lighting protection	42
2.7.1	External lightning protection	42
2.7.2	Internal lightning protection	42
2.8	Connecting the power supply	43
2.8.1	XC-303-... power supply	43
2.8.2	XC-104-..., XC-204-... power supply	43
2.9	Connecting local inputs/outputs	45

2.9.1	Connecting the power supply for local outputs on XC-303-... ..	45
2.9.2	Connecting outputs.....	46
2.9.3	Suppressor circuit for inductive loads	47
2.9.4	Connecting inputs	47
2.9.5	Using inputs as interrupt inputs	50
3	Commissioning	51
3.1	General commissioning instructions	51
3.2	First steps for commissioning XC-104-... and XC-204-... devices	51
3.3	Startup behavior XC-104-..., XC-204-..., XC-303-... ..	53
3.4	Program execution	55
3.4.1	DIP switch S1	55
3.4.2	DIP switch S2.....	56
3.4.3	Program start (STOP → RUN)	56
3.4.4	Program stop (RUN → STOP)	56
3.5	Power off/Interruption of the power supply	57
3.5.1	Test and commissioning (Debugging).....	58
3.5.2	Forcing	58
3.5.3	Reset.....	59
3.6	LED indicators	60
3.7	Operating states when the XControl starts.....	62
3.8	Programs and project	63
3.8.1	Loading programs onto the device.....	63
3.8.2	Saving and deleting a boot application.	64
3.9	Updating the operating/runtime system	65
3.9.1	Updating the operating system with the Web Config Tool.....	65
3.9.2	Updating the operating system with the XSOFT-CODESYS-3 programming system	66
3.10	Factory resetting XC-104-... and XC-204-... ..	68
3.11	Mass production programming through MicroSD or USB	69
3.12	XN300-Assist.....	69
4	PLC configuration.....	71
4.1	Task configuration	71
4.1.1	Creating a cyclical task	72
4.1.2	Creating the event-triggered task and defining the program call .	73
4.2	System events	74
4.3	Multi-tasking.....	75
4.4	Task monitoring by watchdog	78
4.5	Limit values for memory usage.....	81
4.6	Addressing inputs/outputs and marker	82
4.7	Diagnostics.....	83
4.8	Factory reset	85
4.8.1	Resetting the device to factory settings	85

5	Connection set-up PC – PLC.....	86
5.1	Network search with automatic PLC detection	86
5.2	Creating a new project.....	87
5.3	Changing the IP address on the PLC	88
6	In-/output configuration and parameterization.....	90
6.1	Configuring the device's local inputs/outputs	90
6.2	Interrupt processing.....	91
7	Defining system parameters.....	95
7.1	Overview.....	95
7.2	Default parameters	95
7.3	Switch-on of the control with inserted memory card	96
7.4	networkconfig file	96
8	Expansion	99
8.1	Local expansion	99
8.1.1	Configuring the inputs/outputs for local expansions.....	100
8.2	Remote expansion	102
9	CAN	103
9.1	Configuring and commissioning CANopen	104
9.1.1	Adding the CAN manager	105
9.1.2	Setting the baud rate via CANbus.....	106
9.1.3	Incorporating the CAN-Gateway XN-312-GW-CAN.....	107
9.1.4	Attach XN300 slice modules.....	107
9.1.5	Description files for CANopen	109
9.1.6	LEDs on the device.....	110
10	EtherCAT.....	111
10.1	Incorporating the EtherCAT master	111
10.2	Configuring the EtherCAT master.....	111
10.3	Searching for and incorporating EtherCAT modules	113
10.4	Incorporating EtherCAT modules manually.....	114
10.5	Description files for EtherCAT	114
10.5.1	Standard XML files.....	114
10.5.2	Installing the XML file	114
11	Modbus.....	116
11.1	Configuring Modbus TCP	116
11.1.1	Adding an Ethernet adapter	116
11.1.2	Adding a Modbus TCP master and device.....	116
11.2	Configuring Modbus RTU	119
11.2.1	Adding a Modbus master.....	119

11.2.2	Adding Modbus modules	119
12	Web Visu XSOFT-CODESYS-3	120
12.1	Opening XSOFT-CODESYS-3 WebVisu	120
12.2	Selecting the XSOFT-CODESYS-3 WebVisu encryption type	120
13	Web Config Tool for XC-104-... and XC-204-...	122
13.1	Logging in to the Web Config Tool	122
13.2	Navigation	124
13.3	Setting a language.....	125
13.4	Device configuration page – System configuration page	125
13.4.1	Device information	126
13.4.2	Changing / setting up passwords.....	126
13.4.3	USB interface activation.....	127
13.4.4	Power management.....	128
13.4.5	Factory reset	128
13.4.6	Powerfail	129
13.5	Network configuration page.....	129
13.6	Update configuration page	131
13.7	Date & time configuration page	133
13.7.1	Date & Time	133
13.7.2	Time synchronization with NTP.....	133
13.8	Remote access configuration page.....	134
13.8.1	SSH	134
13.9	Legal configuration page	135
13.10	Logs configuration page.....	135
14	OPC UA	136
15	Libraries, function blocks and functions.....	137
15.1	Using libraries.....	138
15.2	Installing additional system libraries.....	138
16	PLC shell commands.....	141
16.1	Using PLC shell commands	141
16.2	List of PLC shell commands (updated)	142
16.3	CPU load shell commands	146
17	Interferences.....	147
18	Maintenance	148
18.1	Cleaning and maintenance	148
18.2	Repairs	148
18.3	Storage and transport.....	148

18.4	Disposal	149
19	Appendix.....	151
19.1	Dimensions and weights	151
19.1.1	XC-303-.....	151
19.1.2	XC-104-..., XC-204-.....	152
19.2	Approvals and national approvals.....	153
19.3	Technical specifications	154
19.3.1	General ambient conditions	154
19.3.2	Power supply on devices and on system bus.....	157
19.3.3	Power supply for local inputs/outputs on XC-204-..., XC-303-....	158
19.3.4	Local inputs XC-204-..., XC-303-....	159
19.3.5	Local outputs XC-204-..., XC-303-....	160
19.3.6	CAN interfaces XC-204-..., XC-303-....	161
19.3.7	RS485-Interface	163
19.4	Glossary	164
	Index	165

0 About this manual

This manual provides information on the XControl series of modular PLCs. The corresponding product groups consist of the following models:

XControl		
XC-104-...	XC-204-...	XC-303-...
XC-104-C10-000	XC-204-C10-000	XC-303-C11-000
	XC-204-C11-003	XC-303-C21-001
	XC-204-C21-001	XC-303-C32-002
	XC-204-C20-002	



Abbreviated XSystem and XControl designations

This manual uses abbreviated designations whenever it is referring to all models.

Whenever it needs to refer to a specific model instead, it will explicitly indicate the model.

Make sure to always use the latest documentation for the Modular PLCs XControl: XC-104-..., XC-204-..., XC-303-....

The latest version of this documentation, as well as additional references, is available for download on the Internet, see also

→ Section "0.3 Additional documentation", page 7



For the latest information on Modular PLCs XControl: XC-104-..., XC-204-..., XC-303-..., please visit our product pages:

Eaton.com/xc300

and the Eaton Online Catalog:

Eaton.com/ecat

Enter "XC300" into the search box and the catalog will take you directly to the corresponding product group.

0.1 Target group

This manual is intended for electricians, electrical engineers, and automation experts, as well as for the people who will be in charge of performing the electrical installation and people who will be using the Modular PLCs XControl: XC-104-..., XC-204-..., XC-303-... as integrated controllers in their own applications.

Electrical engineering and physics-related knowledge and skills, as well as advanced familiarity with the communication interfaces and methods being used, will be required in order to be able to commission the devices.



CAUTION

Installation requires qualified electrician

0.2 List of revisions

The following table lists all major changes.

Publication date	Page	Keyword	New	Modification	Deleted
11/17		New edition	✓		
02/18		Corrections and additions		✓	
01/23		XControl added to all sections	✓		
08/24	11	„Communications and interfaces - decentralized expansion“		✓	
	11	„Overview Eaton Modular PLCs XControl: XC-104-..., XC-204-..., XC-303-...“		✓	
	22	„Ethernet“		✓	
	13	„XC-104-... and XC-204-...“		✓	
	161	„CAN interfaces XC-204-..., XC-303-...“			
	163	„RS485-Interface“			
	51	„First steps for commissioning XC-104-... and XC-204-... devices“		✓	
08/25		Corrections and additions		✓	

0.3 Additional documentation

Please follow the safety instructions in the "Product Cybersecurity Guideline for Modular PLCs XC-104-... XC-204-..." (MZ050018EN) and "Secure Configuration Guidelines XC-303-..." documents and observe the "End User Agreement XC104/204" (MZ050020EN) and "EULA XC-303-..." end-user license agreements.

More information on the topic can be found in the following manual:

- „System description“, MN050017
- "XN300 slice modules", MN050002
- „CANopen Gateway XN-312-GW-CAN“, MN050003
- „EtherCAT Gateway XN-312-GW-EC“, MN050010
- Manufacturer documentation for XSOFT-CODESYS-3, online help for the individual libraries
- Documentation for the CAN modules used
- PLC programming with CODESYS manual, Chapter "Online functions",

in the following instruction leaflets:

- IL050018ZU, XC-303-...
- IL050031ZU, XControl

in the following supplement, which describes how to activate the device's USB interface:

- MZ0500017ZU



The documents specified in this manual, as well as the manual you are reading right now, can also be downloaded free of charge from the Internet in PDF format at:

Eaton.com/documentation

→ Customer support → Download Center – Documentation

Enter the document number ("MN050005", for example), "XControl" or "XC300" into the **Quick Search** text field.

or

on the Modular PLCs XControl: XC-104-..., XC-204-..., XC-303-... product pages:

Eaton.com/xc300

0.4 Legal disclaimer

All the information in this manual has been prepared to the best of our knowledge and in accordance with the state of the art. However, this does not exclude the possibility of there being errors or inaccuracies. We assume no liability for the correctness and completeness of this information.

In particular, this information does not guarantee any particular properties.

Do not use the Modular PLCs XControl: XC-104-..., XC-204-..., XC-303-... before reading and understanding this manual.

It is assumed that the user of this document is thoroughly familiar with the information found in the manuals for incorporating XControl modular PLCs into automation processes.

Hazards posed by the XControl modular PLCs cannot be eliminated if the safety instructions are not observed – especially if the XControl modular PLCs is commissioned and maintained by unqualified personnel and/or the XControl modular PLCs is used improperly. Eaton assumes no liability for any damages resulting from cases such as these.

0.5 I/O system XN300

The ultra-compact XN300 modular slice card I/O system, which features a plug-in connection system, complements Modular PLCs XControl: XC-104-..., XC-204-..., XC-303-... with application-oriented functions that are ideal for optimized system solutions.

There are XN300 slice modules available for power distribution and power supply needs, as well as digital and analog I/O modules and technology modules.



For the latest information on the I/O system XN300, please visit our product pages:

[Eaton.com/xn300](https://www.eaton.com/xn300)

and use the Eaton Online Catalog for information on the available range of products:

[Eaton.com](https://www.eaton.com)

Enter "XN300" into the search box and the catalog will take you directly to the corresponding product group.

The "XN300 slice modules" manual describes all modules.

0.6 Writing conventions

Symbols with the following meaning are used in this manual:

- Indicates instructions to be followed.

Hazard warnings of material damages

ATTENTION

Warns about the possibility of material damage.

Hazard warnings of personal injury



CAUTION

Warns of the possibility of hazardous situations that may possibly cause slight injury.



WARNING

Warns of the possibility of hazardous situations that could result in serious injury or even death.



DANGER

Warns of hazardous situations that result in serious injury or death.

Notes



Indicates useful tips.

- Indicates instructions to be followed

1 Description of the PLCs

1.1 System overview

XC-104-...

The XC100 is the perfect choice for solving simple automation tasks with system-based networking. It can be expanded with up to six snap-on I/O modules from the XN300 system, providing flexibility with regard to system configurations. The device is ideal for implementing small control functions and networking them with higher levels.

XC-204-...

XC200 PLC models can be used to flexibly solve standard automation tasks. The local I/O level can be expanded with up to 16 XN300 I/O modules, while the Ethernet ports make integration into higher levels and networking with Industrial Ethernet easy. The standard interfaces (CAN and RS-485) make it possible to integrate third-party devices and can be used for networking in field bus systems.

XC-303-...

Comprehensive features and interfaces make it possible to flexibly use these compact and powerful PLCs in modular automation solutions. Up to three Ethernet ports for connecting to various networks, paired with standard CAN and RS-485 interfaces, expand the functionality of these devices, turning them into universal control and communication points for networked systems.




Figure 1: System overview XControl

The PLC consists of the:

- PLC with PSU and local inputs/outputs → Page 13

1 Description of the PLCs

1.2 Communications and interfaces - decentralized expansion

- I/O system XN300 → Separate "XN300 slice modules" manual.



In order to program XControl, you will need XSOFT-CODESYS-3 programming software version 3.5.9 or higher.

1.2 Communications and interfaces - decentralized expansion

Modular PLCs XControl: XC-104-..., XC-204-..., XC-303-... support distributed expansion with the use of fieldbus interfaces. The following communication protocols are supported by the corresponding interfaces as follows:

Table 1 Overview Eaton Modular PLCs XControl: XC-104-..., XC-204-..., XC-303-...

Designation	XN300 modules	Retain Data (kb)	ETH 1GB/100MB	RTC	USB	SD-Slot	WEB-Visu HTML5	Interfaces								
								Modbus TCP Server/Client	Ether NET/IP Scanner (MS)	OPC-UA Server	Ether-CAT Master	CAN	CAN-OPEN	RS485	Modbus RTU Server/Client	DIO
XC-303-C32-002	32	128	1x/2x	✓	✓	✓	✓	✓	✓	✓	✓	2x	MS/SL	✓	MS/SL	4x
XC-303-C21-001	32	128	-/2x	✓	✓	✓	✓	✓	✓	✓	✓	1x	MS/SL	✓	MS/SL	–
XC-303-C11-000	32	128	-/1x	✓	–	✓	✓	✓	✓	✓	✓	1x	MS/SL	–	–	–
XC-204-C20-002	16	32	-/2x	✓	✓	–	✓	✓	✓	✓	✓	–	–	✓	MS/SL	2x
XC-204-C21-001	16	32	-/2x	✓	✓	–	✓	✓	✓	✓	✓	1x	MS/SL	–	–	2x
XC-204-C11-003	16	32	-/1x	✓	✓	–	✓	✓	✓	✓	–	1x	MS/SL	✓	MS/SL	–
XC-204-C10-000	16	32	-/1x	✓	✓	–	✓	✓	✓	✓	–	–	–	–	–	–
XC-104-C10-000	6	4	-/1x	✓	✓	–	✓	✓	✓	✓	–	–	–	–	–	–

1.3 Intended use

Modular PLCs XControl: XC-104-..., XC-204-..., XC-303-... are designed for use in machine and system building applications as compact fanless PLCs with comprehensive features and interfaces that can be used to implement flexible state-of-the-art automation solutions.

The devices are approved for use in automation applications exclusively for controlling machines and systems in closed spaces.

It is strictly prohibited to use the devices in order to implement safety relevant functions (in the sense of personal and machine protection). Observe the labels on the modular PLC housing and the corresponding approval specifications and technical data.

Any other use must be discussed and agreed upon with the manufacturer in advance.

→ Section "19.2 Approvals and national approvals", page 153

→ Section "19.3 Technical specifications", page 154

Modular PLCs XControl: XC-104-..., XC-204-..., XC-303-... may only be operated if they have been installed and connected by a qualified electrician. The installation must comply with regulations for electromagnetic compatibility (EMC).



DANGER POSED BY AUTOMATIC STARTING

Powering up the XControl must not result in any hazards being posed by controlled devices, e.g., motors starting unforeseeably or voltages being unexpectedly applied.

1 Description of the PLCs

1.4 Versions

1.4 Versions

The following XControl device models are available:

- XC-104-C10-000
- XC-204-C10-000
- XC-204-C11-003
- XC-204-C20-002
- XC-204-C21-001
- XC-303-C11-000
- XC-303-C21-001
- XC-303-C32-002

1.4.1 XC-104-... and XC-204-...




Figure 2: XC-104-... and XC-204-... connectors

1.4.2 XC-303-...




Figure 3: XC-303-C11-000




Figure 4: XC-303-C21-001




Figure 5: XC-303-C32-002

1 Description of the PLCs

1.4 Versions





Figure 6: Structure XC-303-...

1.5 Key to XControl part numbers



1.5.1 Device Version Number

The device version number is shown on the back of the housing of each Modular PLCs XControl: XC-104-..., XC-204-..., XC-303-... device. These are the first two digits of the device number.

The device version number provides useful service information about the hardware version and operating system version.




Figure 7: Device side with printed device version number

- ① MAC address QR code
- ② Article number
- ③ Device address
- ④ Serial number
- ⑤ Serial number 2D QR code
- ⑥ Eaton product page QR code

1 Description of the PLCs

1.6 Functionality

1.6 Functionality

1.6.1 Power Supply

There is a power connector for powering the processor unit.

Terminal X6 (XC-303) / X4 (XC-104, XC-204) (label: V+/0V) features a 24 V connector for the processor unit and all the slice modules connected to the system bus.

If there is a voltage dip of the 24 V supply voltage (switching threshold is about 10 V) then a power-down logic switches off the 5 V supply to the signal modules (central I/O).

1.6.2 Local inputs/outputs

The digital inputs/outputs can be used either as an input or as an output and connected to sensors or actuators.

They can be used for an interrupt circuit in the application.

When used as outputs, they are designed for 24 V signals.

The following applies to XC-303-...: The digital inputs/outputs feature an additional separate, shared power supply at X2 (label: UL/-) that is galvanically isolated from the bus.

The following applies to XC-204-: The digital inputs/outputs use the shared power supply at X4 (label: V+/0V), which is not galvanically isolated from the bus.

The outputs can be loaded with 500 mA, a duty factor (ED) of 100% and a utilization factor (g) of 100%.

The outputs are short-circuit proof.

XControl	Digital inputs/outputs	Current	Simultaneity factor g
XC-104-C10-000	–	–	–
XC-204-C10-000	2	500 mA	100 %
XC-204-C11-003	2	500 mA	100 %
XC-204-C21-001	–	–	–
XC-204-C20-002	–	–	–
XC-303-C11-000	–	–	–
XC-303-C21-001	–	–	–
XC-303-C32-002	4	500 mA	100 %

1.6.3 Processor unit

Belonging to the processor unit are:

- Processor ARM CORTEX A7 (XC-303-...: Dual Core),
- Memory → Page 18,
- CPU drives → Page 19,
- Real Time Clock (RTC) → Page 18,
- Device interfaces → Page 20,

Real Time Clock (RTC)

All XControl modular PLCs feature a real-time clock that you can access in the user program. Possible functions are:

- Display mode for hours (12/24 hour display),
- Reading and setting of the real-time clock.

A description of the functions can be found in the XSOFT-CODESYS-3 manufacturer documentation for the SysLibRTC.lib library.

In addition, you can set and read the real-time clock with the following PLC shell commands respectively:

- `setrtc` (set the real-time clock),
- `getrtc` (query the real-time clock).

Even in the event of a power supply failure, the real-time clock will continue to work for up to 10 days thanks to a memory backup capacitor.

XControl	Real-time clock tolerances
XC-104-...	± 3 s / day at 25° C
XC-204-...	± 3 s / day at 25° C
XC-303-...	± 3 s / day at 25° C

Memory

Modular PLCs XControl: XC-104-..., XC-204-..., XC-303-... feature a program memory (flash), a random access memory (RAM), and a non-volatile memory (NVRAM) for saving application data.

XControl	Program memory (FLASH)	Cache memory	Retentive data
XC-104-...	4 GB	256 MB	4 kB [NV-RAM]
XC-204-...	4 GB	512 MB	32 kB [MRAM/FRAM]
XC-303-...	128 MB	512 MB	128 kB [NV-RAM]

CPU drives

The XC300 has the following drives available:

Drives	XC300	XC200	XC100
Inside			
System memory	"/home"	"/home"	"/home"
External (optional)			
MicroSD memory card	"/home/disk_sd" "/home/codesys/work" ¹⁾		
USB device	"/home/disk_usb" "/home/codesys/work/usb_a1" ¹⁾ "/home/codesys/work/usb_b1" ¹⁾ "/home/codesys/work/usb_c1" ¹⁾	"/home/disk_usb" "/home/codesys/work"	"/home/disk_usb" "/home/codesys/work"

1) On XC300 with XSOFT-CODESYS-3 Version 3.5.17 or higher

The boot application and the operating system are stored in compressed format and protected against power supply failures in the transactionally safe system memory.
In the operating state, the boot application and the relevant sections of operating system are "unpacked" and copied into the working memory. Meanwhile, the retentive data is stored in the non-volatile NVRAM memory. On all XControl modular PLCs, only the real-time clock (RTC) is backed up with a capacitor. This backup makes it possible for the clock to keep working for 10 days when the device is de-energized.



Transaction safe means that if there is a voltage dip when the file is being processed, the file system and the opened file are generally not destroyed. It is possible however, that data which you have written into the file last opened may be lost.

Figure 8 indicates the interaction of the differing XC300 memory systems/ drives.




Figure 8: XC300 memory organization

1.6.4 Device interfaces



CAUTION INTERFERENCES

The values specified in the technical data, as well as the device's electromagnetic compatibility (EMC), cannot be guaranteed if the following are used: unsuitable cables, improperly assembled and terminated cables, and/or wiring that does not conform to the applicable standards. Only use cables assembled and terminated by professionals.

The cables being used must be assembled and terminated as required by the port/interface description in this document. When wiring the devices, follow all instructions regarding how to wire the corresponding port/interface.

All general directives and standards must be complied with.



CAUTION NON-GALVANICALLY-ISOLATED INTERFACES

The device may be damaged by potential differences.

- ▶ The GND terminals of all bus modules must be connected.
- ▶ Do not connect the connector to the device or disconnect it without first de-energizing the system.



High loads on CPU resources can result in functional limitations. If device access through the programming system is limited due to the load on the device, interrupt the program sequence by switching the RUN/STOP switch to STOP.

1.6.4.1 USB host 2.0



The USB interface for XC-104-..., XC-204-... devices needs to be activated before the first time it is used – please refer to → Section “3.2 First steps for commissioning XC-104-... and XC-204-... devices”, page 51.



Please note that the maximum current load for the USB interface on the XC-303-... is 100 mA and that the maximum current load for the USB interfaces on the XC-104-... and XC-204-... is 500 mA.


Only one USB storage device can be used at a time. This applies even if using a USB hub would make it possible to use multiple USB storage devices, for example.

The output voltage is protected from overloads.

1 Description of the PLCs

1.6 Functionality

Table 2 USB 2.0 Host, type A, downstream port, USB port pinout

USB-Host Type A	Pin	signal
	1	+5 V ---
	2	USB-
	3	USB+
	4	GND

See also:

- Technical data → Page 154

USB cable

- Use standard shielded USB 2.0 cables only.
- Maximum cable length: 5 m.

See also:

- Technical data → Page 154

1.6.4.2 MicroSD memory card, USB device

MicroSD memory card and USB device are used to run external mass storage devices. You can load the recipe data, general data and the user program into them. The operating system (OS) supports memory types with the FAT32 file system.

You can transfer the operating system to the MicroSD or the USB device in order to load it into other PLCs from there by updating the operating system → Section “3.3 Startup behavior XC-104-..., XC-204-..., XC-303-...”, page 53.

XControl	SD card	USB
XC-104-...	–	✓
XC-204-...	–	✓
XC-303-...	32 GB	✓

ATTENTION

The file system of the MicroSD memory card and USB device is not transaction-safe. Accordingly, make sure that the program has closed all files before you remove a MicroSD and/or USB device or turn off the power.

MicroSD memory card

The SD LED shows a green light to indicate that a MicroSD is inserted.



We recommend using a MicroSD memory card that is suitable for industrial data storage, such as item 191087, MicroSD memory card 2 GB with adapter. The SD and SD-XC standards are supported up to 32 GB.

USB device

The USB port can also be used to load the user program or update the system.



CAUTION

When using commercially available peripheral devices with the USB Host, it is important to keep in mind that their EMC interference immunity parameters may render them unsuitable for use in industrial environments.



CAUTION NON-GALVANICALLY-ISOLATED INTERFACES

The device may be damaged by potential differences.

- Do not connect the connector to the device or disconnect it without first de-energizing the system.

1.6.4.3 Ethernet

Every Ethernet port (eth0, eth1, or eth2) can be used for communication between the Modular PLCs XControl: XC-104-..., XC-204-..., XC-303-... and the programming device.

Each of the device's Ethernet ports provides a different transfer rate:

Interface	Baud Rate [MBit/s]	XC-303-C32-002	XC-303-C21-001	XC-303-C11-000	XC-204-C20-002	XC-204-C21-001	XC-204-C11-003	XC-204-C10-000	XC-104-C10-000
eth0	10, 100	√	–	–	√	√	√	√	√
eth1	10, 100	√	√	√	√	√	–	–	–
eth2	10, 100, 1,000	√	√	–	–	–	–	–	–

These Ethernet ports are used for programming and debugging, as well as to update the PLC's operating system and the operation of Ethernet based automation protocols.

Recommendation: Use an ethernet connection when connecting a PC.


ATTENTION

- Every ethernet interface must have a correct network configuration.
- If a device has multiple ethernet interfaces, they must use different network addresses, i.e., one of the first three octets must be used to differentiate between them.

1 Description of the PLCs

1.6 Functionality

Table 3 Assignment of the ethernet interface

RJ45 socket	PIN	Ethernet 10/100 MBit	Ethernet 1000 MBit
	8	–	BI–_D4
	7	–	BI+_D4
	6	Rx–	Rx–_D2
	5	–	BI–_D3
	4	–	BI+_D3
	3	Rx+	Rx+_D2
	2	Tx–	Tx–_D1
	1	Tx+	Tx+_D1

Ethernet (patch) cable

The connecting cable to be selected depends on the the ambient conditions at the installation location (interference, flexibility, transmission speed).

- Use standard ethernet (patch) cables with RJ45 connectors of category Cat 5 or higher only (IEC/EN61131-2, EN50178).
- Maximum cable length: 100 m.
If the network covers a longer distance, use the required appropriate infrastructure components.
- Observe the installation guidelines for ethernet wiring in ISO/IEC 11801 and EN 50173.



CAUTION FORCES ON THE ETHERNET INTERFACE

Communications may be affected, and the connection's mechanical components may be damaged, if the ethernet interface is subjected to strong vibrations or the RJ45 plug-in connection is subjected to pulling.

- Protect the RJ45 plug-in connection from strong vibrations.
- Protect the RJ45 plug-in connection from tensile forces at the socket.

To establish communications between Modular PLCs XControl: XC-104-..., XC-204-..., XC-303-... and the programming device, follow the description for your connected device.

Default IP addresses

The Ethernet interfaces are delivered with the following IP addresses by default:

Interface	XC-303-...	XC-204-...	XC-104-...
eth0	192.168.119.248	192.168.119.204	192.168.119.104
eth1	192.168.137.248	DHCP	–
eth2	192.168.138.248	–	–

Subnet mask: 255.255.255.0

See also:

- Functionality → Page 17
- Technical data → Page 154

1.6.4.4 RS485

The serial RS-485 interface (X3) depends on the device model.

XControl	RS485 serial interface for Modbus RTU
XC-303-...	✓ ¹⁾
XC-204-C20-002	✓
XC-204-C21-001	—
XC-204-C11-003	✓
XC-204-C10-000	—
XC-104-...	—

1) Galvanically isolated from the system power supply

The serial RS-485 interface can be used to connect an external display device, for example.

The RS-485 connection can be used to connect to another PLC as a Modbus RTU master or Modbus RTU device. The protocol supports EVEN, ODD, and NONE parity, as well as 1 or 2 stop bits, and is accordingly in conformity with the CODESYS serial adapter.

Screened twisted-pair cables must be used.

Adjustable baud rates [bauds]	Maximum possible cable length
1200	1200 m
2400	
4800	
9600	
19200	
38400	
576000	
115200	

Configuration: plug connector, 3-pin, spring-loaded plug-in terminal block

1 Description of the PLCs

1.6 Functionality

Table 4 PLUG-FMC-3S spring-loaded plug-in terminal block with RS-485 interface pinout

Plug connector		X1 (XC-204-...) X3 (XC-303-...)	RS485
		1	Data cable A
		2	Data cable B
		3	GND RS485

Activating the bus termination resistors

The first and last stations on the RS-485 cable must be terminated with a bus termination resistor.

To activate the bus termination resistors for the RS-485 cable, switch the following two DIP switches on S1 to the ON position:

- XC-303-...: TRSa and TRSb
- XC-204-...: 3 and 4




Figure 9: DIP switch S1




Figure 10: Activating the bus termination resistors for the RS-485 interface

RS485 cable

- Use the specified connection cable assembled by electrically qualified personnel only.

- Maximum cable length: 1200 m.

See also:

- Functionality → Page 17
- Technical data → Page 154

1.6.4.5 CAN

The CAN interfaces depend on the device model.

XControl	CAN1	CAN2
XC-303-C32-002	✓ ¹⁾	✓
XC-303-C21-001	✓ ¹⁾	–
XC-303-C11-000	–	✓
XC-204-C20-002	–	–
XC-204-C21-001	✓	–
XC-204-C11-003	✓	–
XC-204-C10-000	–	–
XC-104-C10-000	–	–

¹⁾ Electrically isolated

The CAN interfaces can be run individually as a CAN master or CAN device.

The CAN 1 interface (X4) on XC-303-...- devices is galvanically isolated from power supply U_s (X6). This is not the case for any other devices or CAN interfaces.

Configuration: X4 and/or X5 plug connector, 3-pin, PLUG-FMC-3S spring-loaded plug-in terminal block.

Table 5 Configuration of the CAN interface

Plug connector	X4, X5	CAN
	1	CAN_H
	2	CAN_L
	3	GND CAN

Activating the bus termination resistors

Bus termination resistors must be installed at the first and last station on the CAN bus. A bus termination resistor with a resistance of 120 Ω can be activated with DIP switches for this purpose.

To activate the bus termination resistors for CAN 1, switch the following DIP switch on S1 to the ON position:

- XC-303-...: TC1
- XC-204-...: 5




Figure 11: S1 DIP switch setting for CAN1

To activate the bus termination resistors for CAN 2 on XC-303-..., switch the S1 TC2 DIP switch to the ON position:




Figure 12: S1 DIP switch setting for CAN2




Figure 13: Activating the bus termination resistors for the CAN interfaces (CAN1 or CAN2)

CAN baud rates and cable lengths

- Use connection cables that conform to ISO 11898 only.
- The maximum cable length is determined by the baud rate.

Table 6 Max. cable lengths CAN

CAN baud rates [kbauds]	Maximum possible cable length	
50	1000 m ^{2,3}	² Starting from a cable length of 200 m, we recommend using optocouplers in the CAN stations
100	600 m ²	
125	500 m ²	
250	250 m ²	³ It may be necessary to use repeaters starting from a cable length of 1000 m
500	100 m	
800	50 m	
1,000	25 m	



If an application attempts to activate an unsupported baudrate, the CAN controller will switch to passive mode.
 Note (XC204/XC303): The CAN baud rates 10kBaud and 20kBaud are not supported.

Reaction of the station on the CAN bus

Station/bus monitoring: CAN telegrams are sent and received directly by the user program. An interruption on the CAN Bus will only be recognized when the respective CAN slave is monitored by the PLC (Nodeguarding function).

Start/Stop behavior:

Can be configured with the application.

- Reset to default value (usually "0")
- The current value is maintained (user-specific)

Switch on voltage:

The order in which you switch on the power supply of the individual CAN stations has no effect on the functioning of the CAN bus. Depending on the parameters set, the controller "waits" for stations that are not present or starts them when the station is connected to the CAN net.

Communication with CAN stations:

The following documents describe the communication with the CAN stations and their configuration:

- XSOFTE-CODESYS-3 manufacturer documentation, online help
Library description: CANUser.lib/CANUser_Master.lib
- Field bus support -> CAN-based field buses
- CANopen -> CANopen Manager (Master)
- Documentation for the CAN modules used

An blinking green LED next to the X4 or X5 plug connector (whichever is in use) will indicate when data is being transferred on the CAN bus. → Section "3.6 LED indicators", page 60.

1 Description of the PLCs

1.6 Functionality

See also:

- Functionality → Page 17
- Device Interface → Page 20
- Technical data → Page 154

2 Installation



CAUTION

Installation requires qualified electrician



DANGER OF ELECTRIC SHOCK!

All (de-)installation work must be carried out with the entire installation in a de-energized state.

Follow the safety rules in DIN VDE 0105:

- De-energize and isolate the system.
- Secure against retriggering.
- Verify complete isolation from the supply.
- Earthing and short-circuiting.
- Cover or enclose any neighboring live parts.

2.1 Control panel layout

The layout of the components inside the control panel is a major factor for achieving interference-free functioning of the plant or machinery. During the project planning and design phase, as well as its implementation, care must be taken that the power and control sections are separated.

The power section includes:

- Contactors
- Coupling/interfaces components,
- Transformers,
- Variable frequency drives,
- Current converters.

In order to effectively exclude any electromagnetic interference, it is a good idea to divide the system into sections, according to their power and interference levels. In small control panels it is often enough to provide a sheet steel dividing wall, to reduce interference factors.

2.1.1 Ventilation

When designing the system, make sure that the Modular PLCs XControl: XC-104-..., XC-204-..., XC-303-... are adequately ventilated.

In order to ensure that the maximum operating ambient temperature will not be exceeded, make sure that there is enough clearance between the system block's vents and any neighboring components, as well as between the vents and the control panel's back plate.

Keep a minimum clearance of 50 mm from passive components. If the adjacent components are active elements (e.g., power supplies, transformers), keep a minimum clearance of 75 mm instead.

2 Installation

2.2 Mounting XControl

2.2 Mounting XControl

XC-303-... must be installed exclusively horizontally on an EN/IEC 60715 DIN-rail (TS 35). XC-104-... and XC-204-... modular PLCs can also be installed horizontally with the DIN-rail, but only in such a way that the modular PLC will be underneath any additional XN300 slice modules – please refer to → Figure 15, page 32, B.

Make sure to keep the minimum clearances required for ventilation.

Before installation, expand the Modular PLCs XControl: XC-104-..., XC-204-..., XC-303-... with the required XN300 slice modules to get the system block you want.

Observe the following when installing the device in a control cabinet, distribution board, or enclosure:

- The power supply connections and the terminal connections must be protected from being touched directly during operation.
- The DIN-rail must establish a conductive connection to the control panel's back plate.
- The whole system block needs to be mounted on the DIN-rail and then secured in place by closing the locking elements.



Detailed instructions on how to install the XN300 slice modules can be found in the "XN300 slice modules" manual.

Note: XN modules must not be plugged or unplugged while the power is on. This can cause the XN module to become defective.




Figure 14: XC-303-...




Figure 15: XC-104-..., XC-204-...




Figure 16: Installation using the XControl for a system block as an example

a	b	c	θ
30 mm (1.18")	30 mm (1.18")	100 mm (3.94")	$\leq 60^{\circ}\text{C}$ ($\leq 140^{\circ}\text{F}$), A $\leq 55^{\circ}\text{C}$ ($\leq 131^{\circ}\text{F}$), B

The following figures use an XC-303-... device as an example to show and illustrate the installation requirements. To do this, follow the steps below:

- The Modular PLCs XControl: XC-104-..., XC-204-..., XC-303-... must be the first element on the left in the system block.

2 Installation

2.2 Mounting XControl

- ▶ Disengage the side locking tabs on the XN300 slice modules by pulling on the front cover (blue).
Make sure that all locking tabs (blue) are in the front so that they will engage the new slice. (the front cover stay-put function is intended to make the process easier).



The front cover of the Modular PLCs XControl: XC-104-..., XC-204-..., XC-303-... is non-detachable and cannot be removed.

- ▶ Attach an XN300 slice module from the right in such a way that the locking tabs engage the guide.




Figure 17: Joining the XControl modules and XN300 to form a system block

- ▶ Grab the front cover from the top and bottom and push it back towards the XN300 slice module so that the modules lock solidly into place with each other.




Figure 18: Locking the system block in place

- ▶ Repeat these steps until all the XN300 slice modules form a system block together with the PLC.

- Pull the locking elements at the back of the Modular PLCs XControl: XC-104-..., XC-204-..., XC-303-... and all XN300 slice modules up. You can use a screwdriver to do this.




Figure 19: Securing the system block on the DIN-rail

- Tilt the system block forward and place it against the DIN-rail's bottom edge in an inclined position.




Figure 20: Placing the system block against the bottom edge of the DIN-rail

- Push the system block over the DIN-rail's top edge.
- Secure the system block.
To do this, push the locking elements at the back of the Modular PLCs XControl: XC-104-..., XC-204-..., XC-303-... and all XN300 slice modules down.
You can use a screwdriver to do this.

2 Installation

2.3 Uninstalling and disassembly (using the XControl as an example)




Figure 21: Locking the system block into place on the DIN-rail

- Check to make sure that the system block is solidly mounted.

2.3 Uninstalling and disassembly (using the XControl as an example)

- De-energize the system.
Follow the safety rules in DIN VDE 0105 when doing so:
- Press on the release mechanism (with a screwdriver, for example) to release all contacts.
- Disconnect all plug connectors from the Modular PLCs XControl: XC-104-..., XC-204-..., XC-303-... and the XN300 slice modules.

To disassemble the system block, follow the steps below:

- Slide the locking elements at the back of the XControl and the XN300 slice modules up.
You can use a screwdriver to do this.




Figure 22: Releasing the system block locking elements

- Tilt the system block forward, then pull the block, from its bottom edge, away from the DIN-rail.

2.3 Uninstalling and disassembly (using the XControl as an example)




Figure 23: Placing the system block against the bottom edge of the DIN-rail

- ▶ Disengage the locking tabs between the modules by pulling on the front cover (blue).



The front cover's stay-put function will indicate that the locking tabs have been disengaged.

The front cover of the Modular PLCs XControl: XC-104-..., XC-204-..., XC-303-... is non-detachable and cannot be removed.




Figure 24: Disengaging the front cover

- ▶ Once the locking tabs have been disengaged, you can separate the modules from each other.




Figure 25: Disassembling the system block

2.4 Connection terminals

Plug connector

X1 – Xn: The plug connectors with spring-loaded push-in terminals are included as standard with the Modular PLCs XControl: XC-104-..., XC-204-..., XC-303-....

Connecting cable

➔ Only use copper cables designed for at least 90°C as the connecting cable.

To use them, the conductor simply needs to be slid into the appropriate contact and will be locked into place.

In order to release the conductor, simply press on the release mechanism, e.g., with a screwdriver, to pull out the conductor from the corresponding contact.

Table 7 Connection specifications

Cable cross-sectional areas			XControl
10 mm (0.39") 	Solid	mm ²	0.2 – 1.5
10 mm (0.39") 	Flexible with uninsulated ferrule	mm ²	0.2 – 1.5
10 mm (0.39") 	Flexible with insulated ferrule	mm ²	0.2 – 0.75
	Ferrule d	mm	≤ 2.8
	AWG		24 – 16
	Strip length	mm	10

2.5 Potential relationship between the components

2.5 Potential relationship between the components

Modular PLCs XControl: XC-104-..., XC-204-..., XC-303-... feature a contact point that is used to establish a protective earth connection to the DIN-rail. Moreover, all power supply earth connections are connected to the protective earth.

One exception is the XC-303-... supply voltage for the local inputs and outputs U_L at terminal X6. The ground connection at X6 is not connected to the protective earth.

- 0V
- $\oplus$




Figure 26: Potential relationships Modular PLCs XControl: XC-104-..., XC-204-..., XC-303-... with I/O system XN300




Figure 27: Potential relationships XControl

2 Installation

2.6 Wiring in accordance with EMC requirements




Figure 28: Potential relationships XC-104-..., XC-204-...

The galvanic isolation for the ethernet interfaces is listed in the appendix – please refer to → Section “Galvanic separation”, page 155.

2.6 Wiring in accordance with EMC requirements

Undesired faults can occur on the field bus and the analog inputs due to electromagnetic interference. This can be minimized beforehand by the implementation of suitable EMC measures.

These include:

- EMC-conformant system configuration,
- Routing all analog input and field bus cables in a way that meets EMC requirements
- Measures designed to reduce potential differences
- The correct installation of the field bus system (cable, connection of the bus connectors, etc.),
- Using shielding

2.6 Wiring in accordance with EMC requirements

for DIN-rail




Figure 29: Field bus shielded by using a shield

Modular PLCs XControl: XC-104-..., XC-204-..., XC-303-... feature a protective earth connection point at the back.




Figure 30: Page preview XControl

① Functional earth

2 Installation

2.6 Wiring in accordance with EMC requirements

2.6.1 Cable routing and wiring

Cables are divided into the following categories:

- Electric power lines (e.g. power cables carrying high currents, or lines to current converters, contactors, solenoid valves),
- Control and signal cables (e.g. digital input cables),
- Measurement and signal cables (e.g. fieldbus cables).



Always route power cables and signal cables as far apart as possible. This avoids capacitive and inductive coupling. If separate cable routing is not possible, then the first priority must be to shield the cable responsible for the interference.

Take care to implement proper cable routing both inside and outside the control panel, to keep interference as low as possible:

- ▶ Avoid parallel routing of sections of cable in different power categories.
- ▶ As a basis rule, keep AC cable separated from DC cables.
- ▶ Keep to the following minimum clearance:
 - at least 10 cm between power cables and signal cables;
 - at least 30 cm between power cables and data or analog cables.
- ▶ When routing cables, make sure that the outgoing and return leads of a circuit pair are routed together. The opposing currents on this cable pair cause the sum of all currents to equal zero. The generated electromagnetic fields cancel each other out.

2.6.2 Suppressor circuit for interference sources

- ▶ Connect all suppressor circuits as close to the source of interference (contactors, relays, solenoids) as possible.



Switched reactors should always have suppressor circuitry fitted.

2.6.3 Screen earth kit

- ▶ Use shielded cables for the connections to the data interfaces.

The general rule is the lower the coupling impedance, the better the shielding effect.

2.7 Lighting protection

2.7.1 External lightning protection

All cables between buildings must be shielded. Metal conduits are recommended for use here. Fit signal cables with overvoltage protection, such as varistors or other surge arresters. Implement these measures ideally where the cable enters the building and at least at the control panel.

2.7.2 Internal lightning protection

Internal lightning protection covers all those measures taken to reduce the effects of a lightning strike and the resulting electrical and magnetic fields on metallic installation and electrical plant. These measures are:

- Lightning protection equipotential bonding
- Shielding,
- Using surge protective devices

2.8 Connecting the power supply



DANGER

The power supply for the Modular PLCs XControl: XC-104-..., XC-204-..., XC-303-... must be a SELV power supply unit.

The power supply is protected against polarity reversal.

2.8.1 XC-303-... power supply




Figure 31: Connecting the XC-303-... power supply

2.8.2 XC-104-..., XC-204-... power supply




Figure 32: Connecting the XC-104-..., XC-204-... power supply

The Modular PLCs XControl: XC-104-..., XC-204-..., XC-303-... powers the system bus.

XC-303-...	5 VDC/1.6A and 24 VDC/1.6 A
XC-204-...	5 VDC/0.8A and 24 VDC/0.8A
XC-104-...	5 VDC/0.4A and 24 VDC/0.4A

The system bus communication channel on the XN300 slice modules is powered with the 5 V on the Modular PLCs XControl: XC-104-..., XC-204-..., XC-303-...'s system bus.

In addition, the system bus provides a 24 VDC supply voltage used to internally power the XN300 slice modules. Modules with high power consumption levels, however, will also need an additional power supply. Some XN300 slice modules require an external 24 VDC power supply.



For more information, please refer to "XN300 slice modules".

2 Installation

2.9 Connecting local inputs/outputs

2.9 Connecting local inputs/outputs

XC-303-... and XC-204-... modular PLCs feature local inputs/outputs.

These digital inputs/outputs are configured as inputs by default. However, this configuration can be changed in the corresponding XSOFTE-CODESYS-3 dialog box.

Please refer to → Section "6.1 Configuring the device's local inputs/outputs", page 90.

The inputs/outputs on the XC-204-... are not galvanically isolated and are powered by the system power supply (V+). Meanwhile, the inputs/outputs on the XC-303-... are galvanically isolated from the system power supply and require an external power supply (UL).

2.9.1 Connecting the power supply for local outputs on XC-303-...




Figure 33: Connecting the power supply for outputs Q1 to Q4

The cross-sectional area of the +24 V cables used to supply power to the inputs/outputs must be sized for the maximum total current drawn by all the outputs.

2.9.2 Connecting outputs

A maximum current of 0.5 A is permissible per output. The outputs are short-circuit proof to 24 VDC and GND.

If a short-circuit or overload occurs at one of the digital outputs, the output will be switched off. Once the short-circuit or overload condition is fixed, the output will automatically switch back on.

An LED is assigned to each output. A switched (active) output will be indicated by the LED showing a green light.

Connect the outputs, unshielded, with a connection cable with a maximum length of 30 m.

Designation	Number of outputs	Current/output[kb] [mA]	Max. total current [A]
XC-303-C32-002	4	500	2
XC-303-C21-001	—	—	—
XC-303-C11-000	—	—	—
XC-204-C20-002	—	—	—
XC-204-C21-001	—	—	—
XC-204-C11-003	2	500	1
XC-204-C10-000	2	500	1
XC-104-C10-000	—	—	—




Figure 34: Connecting the local outputs of an XC-303-...PLC

2 Installation

2.9 Connecting local inputs/outputs




Figure 35: Connecting the local outputs of an XC-204-...PLC



For wiring examples, please refer to the "XN300 Slice Modules" manual.

2.9.3 Suppressor circuit for inductive loads

High induced voltages may be produced when inductive loads are switched off.

In order to prevent system malfunctions caused by voltage peaks (e.g., coupling on analog cables), it is recommended to use a suppressor circuit (RC suppressors or flyback diodes) directly on inductive loads.

2.9.4 Connecting inputs

XControl features inputs with a +24 V level that can be used to read signal states "0" and "1". The modules feature input filters designed to suppress glitches on the corresponding signal cables.

Inputs I1 to I4 can be parameterized as interrupt inputs.

Connect the inputs with a shielded connection cable with a maximum length of 30 m.

An LED is assigned to each input in order to indicate the input's current state.

Designation	Number of inputs	Can be configured as an interrupt input
XC-303-C32-002	4	✓
XC-303-C21-001	—	—
XC-303-C11-000	—	—
XC-204-C20-002	2	✓
XC-204-C21-001	2	✓
XC-204-C11-003	—	—
XC-204-C10-000	—	—
XC-104-C10-000	—	—




Figure 36: Connecting XC-303-... local digital inputs

2 Installation

2.9 Connecting local inputs/outputs




Figure 37: Connecting XC-204-... local digital inputs

2.9.5 Using inputs as interrupt inputs

The inputs can be configured as interrupt inputs in the corresponding XSOF-TCODESYS-3 parameter dialog box.

The interrupts can be triggered with a rising or falling edge or simply with any edge.




Figure 38: Interrupt input connections




Figure 39: Switching thresholds for inputs in conformity with EN 61131-2

See also:

- Timing requirements for the interrupt inputs: Technical data → Page 154

3 Commissioning

3.1 General commissioning instructions

3 Commissioning

The Modular PLCs XControl: XC-104-..., XC-204-..., XC-303-... need to be commissioned together with the XN300 slice modules in the corresponding system block.



For more information, please refer to the "XN300 slice modules" manual.

3.1 General commissioning instructions

The signals received by analog modules are very small in comparison to digital signals. In order to ensure that these modules work properly, it is absolutely necessary to route all cables carefully:

- The DIN-rail must have a proper earth connection
- The cables used to connect to the analog signal sources must be as short as possible and must not be routed parallel to digital signal cables.
- Analog signal cables must be screened.
- The screening must be terminated at a screening bus.
- Do not route the input cables parallel to load circuits.
- Suppressor circuit for all contactor coils (RC suppressors or flyback diodes)

3.2 First steps for commissioning XC-104-... and XC-204-... devices

For commissioning you have to connect your PC to the device with an Ethernet cable. Since your PC must be in the same subnet as the device, configure your network settings as follows:



Requirement:
You will need admin rights on your PC!

- ▶ Connect your PC to the device with a Cat5 (or higher) standard Ethernet patch cable with RJ45 plug connectors.



Make sure to use the eth0 port on the device only!





Figure 40: Connecting the PC to the XControl eth0 port with a standard Ethernet patch cable

3.2 First steps for commissioning XC-104-... and XC-204-... devices

- ▶ Set the IP address for the Ethernet port on the PC or the USB/Ethernet adapter (if any) to the same number range as that of the default IP address of the eth0 port on the XC-104-... or XC-204-... device! If you are connecting the device for the first time, you will only be able to do this if you change the PC's IP address.

Changing the PC's IP address

- ▶ Click on the  Start menu on your PC and then on  Settings
- ▶ Click on  Network & Internet.
- ▶ Click on "Properties."
- ▶ Open the Windows control panel „Network Connections“.
- ▶ Right-click the desired Ethernet interface, then select „Properties“.
- ▶ Select Internet Protocol Version 4 (TCP/IPv4), then click "Properties".
- ▶ In the "Internet Protocol Version 4 (TCP/IPv4) Properties" dialog box, enter a fixed IP address for the PC. This IP address must be in the same number range as the device's default IP address, but must not be the same as the latter. 192.168.119.xxx, e.g. 192.168.119.100.



- ▶ Enter subnet mask 255.255.255.0.
- ▶ Confirm with OK.
- ▶ Switch on the power supply at the device.

You can now log in to the device with a browser and perform the basic configuration. Proceed as explained in this section: Sie können sich nun per Browser am Gerät anmelden und die grundlegende Konfiguration vornehmen. Gehen Sie dazu wie in diesen Kapiteln beschrieben vor:

- Log in to the device → Section "13.1 Logging in to the Web Config Tool", page 122
- Enable remote access via SSH → Section "13.8.1 SSH", page 134
- Activate the USB interface and USB Factory Reset → Section "13.4.3 USB interface activation", page 127
- Set date and time → Section "13.7.1 Date & Time", page 133

3 Commissioning

3.3 Startup behavior XC-104-..., XC-204-..., XC-303-...

- Configure network settings → Section “13.5 Network configuration page”, page 129

3.3 Startup behavior XC-104-..., XC-204-..., XC-303-...

To update the operating system/user program, the drives will be checked for updated versions. If any updated versions are found, they will be copied to internal memory.

The following flow diagrams show which program is used. The diagrams also show how the operating system (OS) can be updated with the MicroSD memory card or USB Host.

The device will be restarted and will start with the updated operating system and, if applicable, a stored boot application.





Figure 41: Startup sequence for XControl with MicroSD memory card and USB Host



Note:
The XControl's startup behavior is configured in "home\InitPlc".

3.4 Program execution

The program's execution can be influenced with the position of DIP switch S1.

3.4.1 DIP switch S1

The STOP DIP switch changes the CPU operating state with ON/OFF.




Figure 42: Device-model-specific configuration: DIP switch S1 for XC-303-...




Figure 43: Configuration of DIP switch S1 for XC-104-... , XC-204-...

3.4.2 DIP switch S2

DIP switch 2 has a special function for XC-104-... and XC-204-... devices. In the ON state, the device sends responses to broadcast requests from the discovery service.

① S1		ON	OFF
1	☐	1 STOP	PLC stops
2	☐	2 SF	Special Function
3	☐	3 TC	X4 (CAN termination)
4	☐	4 TRSa, X3 (RS485 termination)	–
5	☐	5 TRSb	–

Figure 44: XC-104-..., XC-204-...

3.4.3 Program start (STOP → RUN)

You have the following possibilities to start the program:

	Program exists in main memory	Program should be loaded
Prerequisite	- CPU in STOP - STOP switch ON	- CPU in STOP - STOP switch OFF
Action	Switch the STOP switch to OFF	- Load program - In online operation, issue the "Start" command.
Result for all variables	CPU in RUN Values are retained at the start	CPU in RUN Initial values are activated

3.4.4 Program stop (RUN → STOP)

A change of the DIP switch to the ON position leads the central processing unit to the STOP state after completion of the program cycle (ending of all active tasks).

The PLC settings under the XSOFT-CODESYS-3 Device tab are used to define what should happen in the CPU's STOP state.

Default setting:

- In the "Always update tags" field: "Disabled (update only if used in a task)"
- In the "Behavior for outputs in Stop": "Keep current values."

This will ensure that the values of the outputs used in the I/O tasks will be kept after the tasks end.

When running tests and simulations, the "Enabled 1 (use bus cycle if not used in any tasks)" option should be selected in the "Always update tags" field. This is the only way to ensure that all inputs and outputs will be shown with their latest state in the simulation.

You can stop the program in one of two ways:

- In online operation, issue the STOP command.
- Switch the STOP DIP switch to the ON position.

3 Commissioning

3.5 Power off/Interruption of the power supply

3.5 Power off/Interruption of the power supply

When the program is running, the switching off or interruption of the (CPU) power supply will cause the program cycle or all tasks to be aborted immediately. If this happens, data consistency will no longer be guaranteed!

All outputs in which the I/O tasks are used are set to 0 or switched off. The behavior of retentive variables in shown in can be seen in → Table 9.

The remaining program cycle will not be completed when power is reconnected!

If data consistency is absolutely necessary for an application, additional measures are required, such as the use of a uninterruptible power supply with battery back-up. The PLC is started as shown in Figure 46 and Figure 41.

Table 8 How the tags behave after the program starts

Variable type	Behavior of the variables after ...	
	Cold start	Warm start
Non-retentive	Activation of the initial values	Activation of the initial values
Retain Persistent	Values remain in memory	Values remain in memory

CPU operating state display

The CPU's operating state is indicated by the status display LEDs under PLC and PRG in the front:

CPU status	LED PLC	
	Green	Red
RUN	ON	OFF
STOP	Flashes	OFF
NOT READY	OFF	ON

If the runtime system does not start properly, the PLC LEDs will signal the NOT READY state. The CPU remains in STOP state. The CPU can be restarted after elimination of the fault. See → Section “3.6 LED indicators”, page 60 for details on the LED indicators.

3.5.1 Test and commissioning (Debugging)

The Modular PLCs XControl: XC-104-..., XC-204-..., XC-303-... supports the following test and commissioning features:

- Breakpoint/Single step mode,
- Single cycle mode,
- Forcing,
- Online modification, → PLC programming with CODESYS manual, Chapter "Online functions",

Breakpoint/Single step mode

Breakpoints can be set within the application program. If an instruction has a breakpoint attached, then the program will halt at this point. The following instructions can be executed in single-step mode. Task monitoring is deactivated.

ATTENTION

Any outputs already set when the program reaches the breakpoint remain set!

Single cycle mode

In single-cycle operation, one program cycle is performed in real time. The outputs are enabled during the cycle. At the end of the cycle, the output images are cancelled and the outputs are switched off. Task monitoring is active. Task monitoring is active.

3.5.2 Forcing

All user program tags can be initialized with default values. A local output is only forced if the corresponding variable is assigned by default and the central processing unit is in the RUN state.

Flag Display

The inputs/outputs are to be referenced in order to visualize the states of the configured inputs/outputs in an interval controlled task in the PLC configurator. The following syntax is sufficient in the ST programming language in order to be able to display individual I/O bits.

Example:

```
%IB0; (referencing of inputs I0.0 - I0.7)
%QB0; (referencing of outputs Q0.0 - Q0.7)
```

In the instruction list (IL):

```
LD    %IB0
ST    Default byte
LD    Default byte
ST    %QB0
```

3 Commissioning

3.5 Power off/Interruption of the power supply

3.5.3 Reset

There are three different types of Reset commands:

- Warm reset,
- Reset cold,
- Full reset.

→ Table 9: The commands also affect the state of the CPU: shows the commands to use for initializing a retentive variable range. The commands also affect the state of the CPU.

Table 9 Behavior of the program and the variables after a Reset

Variable type	Reset command		
	Warm reset	Reset cold	Full reset ¹⁾
Non-retentive	Activation of the initial values	Activation of the initial values	Activation of the initial values
Retain Persistent	Values remain in memory	Values remain in memory	
Program	Is stopped; then restarted	Is stopped; then restarted	Is deleted; PLC in NOT READY state; the PRG LED turns off; then load the program onto the device again and start it

1) After "Full reset," the program must be loaded into the XControl again. In online operation, the "Start" command can now be issued.



For more information, please refer to the XSOF-TCODESYS-3 Online Help using "RETAIN" as a keyword.

3.6 LED indicators

The status display LEDs in the front are used to indicate the signal states of the Modular PLCs XControl: XC-104-..., XC-204-..., XC-303-..., the interfaces, and the inputs and outputs.




Figure 45: LEDs using XC-204-... and XC-303-... as an example

- ① PLC LED: RuntimeSystem loaded (green)/
active communication with programming system (green blinking)
RUN (green)/STOP (blinking green)/ERROR (red)
- ② LED PRG (red)/No Error(green)
- ③ MicroSD detected LED (green/-)
- ④ USB active LED (green/-)
- ⑤ LED Ethernet2 Activity (green)
- ⑥ LED Ethernet2 Activity eth1 [10/100]Mbps (orange) /1000Mbps (green)
- ⑦ LED Ethernet1 Activity (green)
- ⑧ LED Ethernet1 Activity eth1 [10/100]Mbps (orange)
- ⑨ LED Ethernet0 Activity (green)
- ⑩ LED Ethernet0 Activity eth1 [10/100]Mbps (orange)
- ⑪ LED Q1-Q4 (green)
- ⑫ U_L 24V detected LED (green)
- ⑬ LED RS485 connected (green/red)
- ⑭ CAN1 connected LED (green/red), flashes during data transfers (Rx + Tx)
- ⑮ CAN2 connected LED (green/red), flashes during data transfers (Rx + Tx)
- ⑯ V+ 24 VDC detected LED (green)
- ⑰ USB controller accessing storage device LED

3 Commissioning

3.6 LED indicators

Table 10 LED status display

	Status LED			Description
	red	green	orange	
PLC	–	–	–	RuntimeSystem not started No power on X6
	–	Flashes	–	PLC RuntimeSystem started, connection to XSOFT-CODESYS-3
	–	ON	–	PLC RuntimeSystem started
	ON	–	–	Error status of the RuntimeSystem - Hardware Error - Checksum Error - Could not start SSL connection Fix: Check the log file
	ON	ON	–	Firmware update
PRG	–	–	–	No application on device
	–	ON	–	Application running
	ON	–	–	Application stopping; program signaling error condition Because of the following, for example: - Unsuccessful data access - Task interval time > Watchdog time
	–	Flashes	–	Application stopped
	ON	ON	–	Firmware update
SD	–	–	–	No MicroSD memory card detected
	–	ON	–	MicroSD memory card detected
USB	–	–	–	No USB Host detected
	–	ON	–	USB Host plugged in
	–	–	ON	XC-204-..., XC-104-...: Current access operation on storage device.
RS485	–	–	–	
	–	ON	–	Communication channel open
	–	Flashes	–	Bus activity
CAN1 CAN2	–	–	–	No bus activity
	–	Flashes	–	Bus activity OK (CAN), FLASHES with every frame
	ON	–	–	Bus error
	Flashes	Flashes	–	Warning
	red	green	orange	
eth0...eth2	–	–	–	No active connection
	–	ON	–	Active connection
	–	ON	Flashes	Active connection and data being received or transmitted
Ethernet Activity	–	–	–	Ethernet communication / link status
	–	ON	–	
	–	–	ON	
	–	ON	ON	

1) Flashes: The flashing frequency can vary depending on the transfer rate on the bus.
When there are large volumes of data, the flashing will look like a solid green light on the LED.

3.7 Operating states when the XControl starts

	Status LED			Description
	–	Green	–	
Q1...Q4	–	–	–	There is a LOW signal at the input.
	–	ON	–	Input has a HIGH signal
POW	–	–	–	No power on X6
	–	ON	–	24 VDC power for device present at X6
U _L at Q1...Q4	–	–	–	No power
	–	ON	–	Power supply present

1) Flashes: The flashing frequency can vary depending on the transfer rate on the bus.
When there are large volumes of data, the flashing will look like a solid green light on the LED.

3.7 Operating states when the XControl starts

PLC and PRG are used to indicate the operating states.

3.8 Programs and project

3.8.1 Loading programs onto the device

You must log on in order to load recently created or modified programs into the device. The question "Load the new program?" will appear. The load operation will start once this prompt has been confirmed.



Please note that the "Retain" variables are initialized during the load process, but the "PERSISTENT" variables retain their value.


In order to safely store the program, a boot application must be generated by the user program. The "Create boot application" command will load the program from the PC onto the system memory and save it as a boot application in a non-volatile manner.

To create a boot application, follow the steps below:

- ▶ Change over to the "Online" folder.
- ▶ Select the "Login" command.
- ▶ Select the "Create boot application" command.

Alternatively, you can configure XSOFT-CODESYS-3 in such a way that a boot application will be generated automatically when the user program is downloaded. To automatically generate a boot application during the download, follow the steps below:

- ▶ Select "Application" in the browser.
- ▶ Select the "Properties" option in the context menu.
- ▶ Open the "Boot Application" tab.
- ▶ Enable the "Implicitly generate boot application during download" option.



3.8.2 Saving and deleting a boot application.

Saving a boot application on the MicroSD memory card

- ▶ Make sure that communications with the XControl device have been established.
- ▶ Make sure that the boot application was compiled without errors.
- ▶ Make sure that the microSD card is inserted into the device.
- ▶ In Explorer, double-click on the device (e.g., "Device (XC-303)") and select "PLC Shell" under the "Device" tab.
- ▶ Enter the `copyprojtosd` command into the command line.

An "XC303" directory with a "project" subdirectory will be created for the boot application. The boot application will be named `<application_name>.app` ("Application.app", for example) and stored in this subdirectory. In this case, `<application_name>` refers to the application in Explorer. In addition, an `<application_name>.crc` file will be generated.

The boot application will be stored on the MicroSD memory card in the aforementioned directory structure.

You can use the `copyprojtosd` PLC shell command to copy the boot application (e.g., for a backup copy) or change the file's name. However, only the boot application named `<application_name>.app` will be active in the XSOF-TCODESYS-3 software.

Saving a boot application on the USB device

- ▶ Make sure that communication with the device has been established.
- ▶ Make sure that the boot application was compiled without errors.
- ▶ Make sure that there is a USB device plugged into the USB Host.
- ▶ In the configuration tree, double-click on the device (e.g., "Device (XC...)") and select "PLC Shell" under the "Device" tab.
- ▶ Enter the `copyprojtousb` command into the command line.

An "XC..." directory with a "project" subdirectory will be created for the boot application. The boot application will be named `<application_name>.app` ("Application.app", for example) and stored in this subdirectory. In this case, `<application_name>` refers to the application in Explorer. In addition, an `<application_name>.crc` file will be generated.

The boot application will be stored on the USB device in the aforementioned directory structure.

You can use the `copyprojtousb` PLC shell command to copy the boot application (e.g., for a backup copy) or change the file's name. However, only the boot application named `<application_name>.app` will be active in the XSOF-TCODESYS-3 software.

Deleting a boot application from the MicroSD

Click on the "Device → PLC Shell" folder and enter the `remprojfromsd` command for the XControl.

3 Commissioning

3.9 Updating the operating/runtime system

Deleting a boot application from the USB device

Click on the "Device → PLC Shell" folder and enter the `remprojfromusb` command for the XC....

3.9 Updating the operating/runtime system

With the Modular PLCs XControl: XC-104-..., XC-204-..., XC-303-... it is possible to replace the operating/runtime system with the latest versions.



If you transfer a current operating/runtime system to an older hardware version, it is possible that not all functions of the operating system will be supported by the hardware.



When an operating/runtime system is uploaded to the PLC, the existing operating/runtime system will be overwritten!



Observe the information in the corresponding release notes, which are also available at Download Center.

The operating/runtime system is updated exclusively with XSOFTECODESYS-3. A *.tar file is installed on the device for this purpose.

For XC-104-... and XC-204-... devices, the operating system can also be updated with the Web Config Tool.

Update	Tool	Firmware format
RTS	Network (SSH) or USB/SD card	*.ipk
OS	Web Config Tool	*.rauc

For XC-303,

Update	Firmware version	Tool	Firmware format
OS/RTS	Before and including V3.5.16	Network (SSH) or USB/SD card	*.tag
	From V3.5.16 (excl.) to V3.5.19 (excl.)	SD/USB	
	After and including V3.5.19	USB/SD card or network (SSH) after enabling SSH + assigning a password.	

Individual operating system components can be installed separately for these devices:

1. Operating system Linux
2. Bootloader
3. PLC Runtime System

3.9.1 Updating the operating system with the Web Config Tool

For more information, please refer to → Section "13.6 Update configuration page", page 131.

3.9.2 Updating the operating system with the XSOFT-CODESYS-3 programming system

Procedure:

- ▶ Establish a connection to the modular PLC with the PC's Ethernet interface.
→ Chapter 5 "Connection set-up PC – PLC", page 86.
- ▶ Go to the "Device" screen in XSOFT-CODESYS-3 and open the "Firmware" tab.




Figure 46: "Device" screen

3 Commissioning

3.9 Updating the operating/runtime system





Figure 47: "FTP installation" window for XC-303-...

- ▶ Enter the PLC's IP address and click on "Next."
- ▶ Select the "XC303" device type and click on "Next."
- ▶ Select the components you want to install:
 - For XC-303-... devices: "PLC operating system".
 - For XC-104-... and XC-204-... devices:
 - "Bootloader"
 - "Linux"
 - "PLC Runtime System".



- ▶ Click on the <Continue> button.
- ▶ Stop the PLC
Switch the S1 Stop DIP switch to ON
- ▶ Click on "Download" to start downloading the firmware.
- ▶ Wait until the dialog box shows a message saying "Download successful."
Then close the window with "RETURN."
- ▶ Click on "close" to exit the Setup Wizard.
- ▶ Start the PLC
Switch the S1 Stop DIP switch to OFF
- ▶ Restart the Modular PLCs XControl: XC-104-..., XC-204-..., XC-303-....

The update process when using removable media or a local directory (→ Figure 47, page 67) is similar to that for FTP installation.

Procedure:

- ▶ Insert the USB device or MicroSD memory card into the PC.
- ▶ Select "Removable Drive" in the "XC... OperatingSystem Download" screen (→ fig. 47).
- ▶ Select the removable media directory and click on "Next."
- ▶ Select the "XC303" device type and click on "Next."
- ▶ Select the "PLC operating system" component and click on "Next."
- ▶ Click on "Install" to start downloading the firmware.
- ▶ Click on "Done" to exit the Setup Wizard.

The firmware files will be found in a directory on the removable medium called **XC.../Firmware**.

- ▶ If you want to use the device's USB port, make sure that you have activated it – please refer to → Section "3.2 First steps for commissioning XC-104-... and XC-204-... devices", page 51.
- ▶ Insert the USB device or the MicroSD memory card into the modular PLC.

The system will check whether there is a different operating system on the removable medium. If one is found, the system will start updating the firmware. When this occurs, the status display LEDs under PLC and PRG in the front will flash alternately (green), as will SF (red).



The new firmware version will not be enabled until the PLC is restarted.

3.10 Factory resetting XC-104-... and XC-204-...

There are two ways to carry out a factory reset:

1. Factory reset with the Web Config Tool
2. Factory reset through the USB port

Use the first method if you know the access information for the device, as this is the fastest of the two options – please refer to → Section "13.4.5 Factory reset", page 128.

3 Commissioning

3.11 Mass production programming through MicroSD or USB

You can use the second method if you do not know the password for the device. However, this method requires the preparation steps outlined below.

Method 2: Factory reset through the USB port

To do so, follow the steps below:

- ▶ Make sure that the "Enable USB factory reset" switch is enabled (i.e., in the right-hand switch position) on the Device configuration page in Web Config Tool.
- ▶ Prepare a storage device with a USB interface and store a file named "factory-reset.txt" on it.
- ▶ The only content of this file should be the device's serial number, e.g., "100000001098".
- ▶ Make sure that the device is de-energized.
- ▶ Plug the storage device into the device's USB port.
- ▶ Switch on the power supply at the device.

As soon as the storage device is connected to the device through the USB port and the device is switched on and starts booting up, the device will check whether the "factory-reset.txt" file is found on the storage device and whether the content of the file matches the device's serial number. If they do, the device will be reset to its default settings.

The "factory-reset.txt" file will then be deleted from the storage device. The "Enable USB factory reset" switch will be disabled, i.e., switched to the left-hand switch position.

All Ethernet ports will be reset to their default settings. If a password has been set, it will be deleted.

3.11 Mass production programming through MicroSD or USB

The operating system and the application can be programmed through a MicroSD memory card or USB device.

→ Section "3.3 Startup behavior XC-104-..., XC-204-..., XC-303-...", page 53.

3.12 XN300-Assist

XN300-Assist is a planning, ordering, and commissioning program that can be used to make it easier to configure SDOs. In addition, XN300-Assist makes it possible to configure XN300 slice module parameters with processed cleartext. This configuration can be saved as an INI file and then imported into XSOFT-CODESYS-2 or XSOFT-CODESYS-3. As a result, only system-relevant SDOs, such as the enable signal for analog value transmission, still need to be configured directly in CODESYS.

XN300-Assist includes the following functions:

- Selecting modules, as well as a gateway

- Reading device parameters for the gateway and modules of the system bus.
- Generating a project-specific EDS file
- Generating a project-specific INI file for XSOFT-CODESYS-2 or XSOFT-CODESYS-3
- Status indication of the inputs/outputs
- Wiring test
- Firmware Update
- Importing actual configurations
- Display of cyclical and acyclical diagnostics messages

The Online Help function provides a detailed description of how to use XN300-Assist. In order to open it, click on the "?" icon on the XN300-Assist menu bar or press the <F1> key.

4 PLC configuration

4.1 Task configuration

Processing of the project can be controlled via tasks. Each task can be assigned with a range of programs which should be run during execution of the task.

The task is defined by a name, a priority and a type which defines under which conditions a task starts. Priority and task conditions determine the sequence in which the tasks are to be processed.

You can select "cyclical" or "event-triggered" as the task condition. A cyclical task is restarted after the set interval time has elapsed. An event-triggered task is only started when the event occurs. You can also link system events such as "Start", "Stop" or "Reset" with the execution of a program.

The task priorities can be parameterized with a value from 0 to 31 where 0 is the highest priority and 31 is the lowest priority.

In principle the output image is written onto the physical outputs before every task is called and the map is read by the inputs (updating of the input/output map). The task is executed thereafter. In addition, all system activities are carried out before or after the task call. This includes for example, communication with the XSOF-CODESYS-3 or Online changes.

Updating of the input/output image by multiple tasks is described in the Section "Multi-tasking" on Page 75.

All IEC tasks, including those with the highest priority can be interrupted by an interrupt or an event controlled task.

Time monitoring (Watchdog) can be activated for each task.



For a detailed task configuration description, please refer to the manual for programming PLCs with XSOF-CODESYS-3

Following is an example used to illustrate the PLC specific settings.

Creating a task (example)

First create the cyclic task "Basic" with the assigned program "Basic_prog". Then you can add the event-triggered "Param" task with the "Param_prog" program. In the program "Basic_prog" an event is programmed which invokes the "Param" task.

The following steps are necessary in order to create a task:

- Add a task
- Define the program call
- Create the program

4.1.1 Creating a cyclical task

- ▶ In the project's configuration tree, select the "Device (XC-303)" device -> "PLC Logic" -> "Application".
- ▶ Select "Task configuration" in the configuration tree.
- ▶ Select the "Add object" and "Task" options in the context menu.
- ▶ Enter in the Name field a name such as "Basic".
- ▶ Set the task in the dialog as in Figure 48.

Define the program call

With the program call you define which program is to be called with the task "Basic".

- ▶ Right-click on the icon for the "Basic" task you created previously and select the "Add object" -> "Program call" option in the context menu.
- ▶ Enter "Basic_prog" as a name into the "Add call" pane.
- ▶ Confirm the program name with "Add."




Figure 48: Configuring the cyclical task with a program call

Writing a program

- ▶ Open the editor for the "Basic_prog" POU by double-clicking on it.
- ▶ You can now enter a program. In the program example the variable "bCount" is incremented.
If the count = 20, global tag a will be set to TRUE.

4 PLC configuration

4.1 Task configuration




Figure 49: Creating a program element for a cyclic task

4.1.2 Creating the event-triggered task and defining the program call

The procedure corresponds to the creation of a cyclic task.

- ▶ Create a task of type "Event" named "Event" as shown in Figure 50.
- ▶ Enter global Boolean tag "a" as the event by clicking on the ... button, double-clicking on the "GVL" folder in the "Input assistance" dialog box, selecting tag "a", and confirming with "OK".
- ▶ Enter the program call "Event_prog".




Figure 50: Creating an event controlled task

Writing a program

- ▶ Select "Application", select the "Add object" option in the context menu, and enter (POU) as an object with the name "Param_prog".
- ▶ You can now enter a program. The program example Param_prog (Figure 51) increments the variable "value" by the value 1. The Param_prog is processed if the variable a = TRUE.




Figure 51: Programmed element for event controlled task

Events can only be triggered by Boolean tags.

4.2 System events

A function can be called with the help of a system event. It can be used when the PLC is started to initialize modules with parameters. The system events are independent of the task!

Assigning a function to a system event

- ▶ Add an event handler in the task configuration under the "System Events" tab.
 - ▶ Select one of the available events (e.g., "StartDone") and enter a function name (e.g., "AfterStart") in the "Function being called" field.
4. "System Events" - select an event (e.g., "Start") and enter the name of the POU (e.g., "Power_prog") that should be executed. **Check required**




Figure 52: Assigning the function to a system event

- ▶ Double-click on the function name to open the editor and program the actions that should be taken after the start.

4 PLC configuration

4.3 Multi-tasking




Figure 53: Programming a function



Further information concerning the system events can be found in the online help of the programming system.

4.3 Multi-tasking

The XC300 runtime system is a multi-tasking system. In other words, multiple tasks can be processed simultaneously.

Updating the input/output image table

If the local and central inputs/outputs are programmed in several tasks, the input/output image table in XSOFT-CODESYS-3 will be updated according to special rules:

By default, the only inputs read and outputs set before every task are the ones used in the task.

In other words, the CPU does not work with an unchanging input/output image table within a cycle. Instead, the input/output image table changes within the cycle based on the task.

After the start, the system updates the inputs used (e.g., in the first task). The name of the first task "Prog1" is in the Figure 55. If the system detects an input that is connected to an XN300 slice module (e.g., XN322-16DI) through the configuration, only this module input will be updated in the image table. If this task has additional inputs that are assigned to other slice modules, the inputs of these modules will be updated as well.

The same behavior applies to the outputs. If, for example, outputs QX6.0 and QX7.1 of output module "1" are addressed by different tasks, the outputs of this module will not only be updated by the first task. For instance, the first task could set output QX6.0, while the second task could reset the output based on a changed input image table.



Do not access the same input or output from different tasks.

Examples

The examples are based on the following configuration:




Figure 54: Configuration of XC-303 with local inputs/outputs and I/O system XN300 inputs/outputs as a central expansion

The task configuration now looks as follows:




Figure 55: Task configuration for examples

Example 1:

Table 11 Task details for example 1

Task name	Priority	Cycle time
Prog 1	2	50 ms
Prog 2	1	10 ms

In the first task ("Prog1"), the "progtes(1)" program uses input IX4.0 of input module 1 and input IX6.0 of input module 2. Before the first task ("Prog1") starts, only these inputs will be updated.

In the second task "Prog2" the input IX4.1 of input module 1 is programmed in the program "progtes(2)". The input of this input module is updated before the 2nd task ("Prog2") starts.

Example 2:

Table 12 Task details for example 2

Task name	Priority	Cycle time
Prog 1	2	50 ms
Prog 2	1	20 ms

In example 2 in the first task the input IX4.0 is programmed and in the second task the input IX4.1 and output QX4.0 is programmed.

At the beginning of the first task, input IX4.0 is updated. If this input is set, output QX4.0 is set as well. Otherwise, it is reset.

At the beginning of the second task, input IX4.1 of the input module is updated and output QX4.0 is set or reset.

As a result, the control sequence could result in output QX4.0 being set in the first task and reset in the second. In other words, the output would be toggled.

Creating a task with consistent inputs/outputs

Avoid access to the physical outputs from several tasks. In order to guarantee a clear PLC sequence, create for the local inputs/outputs and the inputs/outputs of the local expansion module a task in which all inputs are copied in global variables and at the end of the interval all outputs of global variables are written to the output module (I/O update task). The I/Os are consistent (data integrity) within this task. The global variables can then be used instead of the I/Os in other tasks.



Do not access the same input or output from different tasks.



On the XC300 PLC a maximum of 50 tasks are possible. The parameterization of a task as "free wheeling" is not supported.

Note with parametric programming of the watchdog time that the POU called with the interrupt service routines, extends the task run times accordingly.

4.4 Task monitoring by watchdog

The processing time of a task can be monitored in terms of time required using a watchdog. The following applies for defining the monitoring time:

$$\text{Processing time} < \text{Interval time of the task} < \text{Watchdog(time)}$$

If the processing time of the task exceeds the interval time, the end of the second interval time is awaited until the task is restarted.

→ Watchdog inactive.

The watchdog interrupts the program processing if the processing time of the task exceeds the watchdog time.

Furthermore, the frequency (sensitivity) can be set, which the number of exceeds allows. In this case the outputs of the PLC are switched off and the user program is set to the "Halt" state. Afterwards, the user program must be reset with RESET.



If the watchdog is deactivated, there will be no task monitoring!



CAUTION

If you want to parameterize a task without a Watchdog or want to deactivate the Watchdog at a later time, all the outputs which have been accessed up to this time can continue to remain active. This is the case for example, when the task can't be ended due to a continuous loop (programming error) and/or missing end condition (stepping condition). The outputs continue to retain their "High potential" until the operating mode is changed from RUN to STOP or until the control voltage for the outputs is switched off.

Configuring a watchdog

You can select the following settings in the task configuration:

- Watchdog on/off
- Watchdog time
- Watchdog sensitivity.

These settings apply for time controlled and event controlled tasks.

Watchdog active

The watchdog is started at the commencement of every processing cycle and reset again at the end of the task.



The following rule applies for definition of the watchdog time with several tasks: each watchdog time must be longer than the sum of task interval times.

4 PLC configuration

4.4 Task monitoring by watchdog

If the processing time is longer than the watchdog time (sensitivity = 1) – e.g. with a continuous loop in a program – the watchdog becomes active. If the processing cycle is shorter than the watchdog time, the watchdog is not activated.

The triggering of the watchdog continues to be dependant on the watchdog sensitivity. The watchdog sensitivity determines when the watchdog will be triggered, after the watchdog time has been exceeded by a determined number of consecutive occasions.

The watchdog is triggered:

- immediately when the watchdog time is exceeded with a watchdog sensitivity of "1",
- immediately after the "x"th consecutive time that the watchdog time is exceeded with a watchdog sensitivity of "x".

For example, a task with a watchdog time of "10 ms" and a watchdog sensitivity of "5" will end at the latest after $5 \times 10 \text{ ms} = 50 \text{ ms}$.

Example: Watchdog active

The interaction of interval time (IZ), task run time (TZ), watchdog time (WT) and watchdog sensitivity are illustrated by the following configuration example:

- Watchdog on
- Watchdog time (WT) = 15 ms
- Watchdog sensitivity = 2

The interval time (IZ) of the task is 10 ms.

Variant ①: The watchdog is not triggered as the task time always remains below the defined watchdog time.

Variant ②: The watchdog is triggered 15 ms after commencement of the second task ⚡, as both times are longer than the defined watchdog time and occur consecutively.

Variant ③: The watchdog is triggered 15 ms after commencement of the second consecutive task, which is longer than the defined watchdog time.

Variant ④: Endless loop: The watchdog is triggered ⚡, because the task time takes longer than the watchdog time multiplied by the watchdog sensitivity ($2 \times 15 \text{ ms} = 30 \text{ ms}$).




Figure 56: Watchdog active, multiple tasks with differing priority

Watchdog deactivated

The cycle time of a task is not monitored when the watchdog is deactivated. The task will be terminated once it has been completed and will not be started again until the next interval starts.

Example: Watchdog deactivated

The interval time (IZ) is 10 ms.

Variant ①: The interval time (IT) of a task was set to 10 ms. The actual task time (TT) is 15 ms. The task is started on the first call but is not terminated before the second cycle. Therefore, the task is not started again in the second cycle. Only in the third cycle – after 20 ms – is it possible to restart the task. The task does not run every 10 ms but rather only at a time interval of 2×10 ms.

Variant ②: The running cycle is not ended.




Figure 57: Watchdog deactivated

Multiple tasks with the same priority

You can assign several tasks with the same priority. The tasks are split according to the "Time Slice" principle and are practically executed simultaneously as part intervals (Round Robin).

4 PLC configuration

4.5 Limit values for memory usage

4.5 Limit values for memory usage

The data memory of the Modular PLCs XControl: XC-104-..., XC-204-..., XC-303-... is divided into memory segments. The segment sizes are shown in Figure 58.

The global data utilizes multiple segments. The required amount can be specified to suit the size of the loaded program.

You can see the segment size under <Device (XC303) → Device Information → memory-layout>:

Example:




Figure 58: Device (XC-303) memory segment size

The maximum segment size for inputs, outputs, and markers is 1,280 bytes. The maximum size for retentive tags is 98 KBytes.

4.6 Addressing inputs/outputs and marker

If you open the PLC configuration of a new project, you will receive the current view of the default settings of the addressing. In this setting the addresses are automatically assigned and address conflicts (overlaps) are reported.

Variable	Kanal	Adresse	Typ	Beschreibung
XN_322_16DI_PD_1				
	Eingang0	%IW8	WORD	Eingangskanäle X1.1 bis X4.16
	X1_1	%IX8.0	BOOL	Eingang X1.1
	X1_2	%IX8.1	BOOL	Eingang X1.2
	X1_3	%IX8.2	BOOL	Eingang X1.3
	X1_4	%IX8.3	BOOL	Eingang X1.4
	X2_5	%IX8.4	BOOL	Eingang X2.5
	X2_6	%IX8.5	BOOL	Eingang X2.6
	X2_7	%IX8.6	BOOL	Eingang X2.7
	X2_8	%IX8.7	BOOL	Eingang X2.8
	X3_9	%IX9.0	BOOL	Eingang X3.9
	X3_10	%IX9.1	BOOL	Eingang X3.10
	X3_11	%IX9.2	BOOL	Eingang X3.11
	X3_12	%IX9.3	BOOL	Eingang X3.12
	X4_13	%IX9.4	BOOL	Eingang X4.13
	X4_14	%IX9.5	BOOL	Eingang X4.14
	X4_15	%IX9.6	BOOL	Eingang X4.15
	X4_16	%IX9.7	BOOL	Eingang X4.16

Figure 59: Default setting of the addressing

If you add a module to the PLC in the configurator, the configurator will assign this module with an address. Further modules are assigned with the next addresses in ascending order. You can also assign the addresses freely. However, if you access the "Automatic calculation of addresses" function later, the addresses are shown in reassigned ascending order.

Check for overlapping addresses

During compilation, addresses assigned twice will be detected and an error message will be generated.

Addressing by data type

If you assign an address to a word-addressable module tag (e.g., I/O system XN300 InputChannel2 on the XN322-4AI-PTNI) with the "Input address" field and this address does not match the data type (e.g., IB11), the PLC configurator will automatically show the next word address after the preceding tag (e.g., IW12).

Variable	Mapping	Kanal	Adresse	Typ
InputChannel1			%IW10	WORD
InputChannel2			%IB11	WORD
InputChannel3			%IW14	WORD
InputChannel4			%IW16	WORD
ModuleDiag			%IB18	BYTE
WireBreakDiag			%IB19	BYTE
RangeDiag			%IB20	BYTE

Figure 60: Addressing by data type

4.7 Diagnostics

The following diagnostic methods are available:

- LED signaling
- Error messages when compiling the project
- I/O system XN300 Master Diagnostics possibilities
- Diagnostic shell commands

Module present / module not present

Runtime system started / not started

PLC LED signaling

If the program has an error condition, the PLC status display LED in the front will light up red and flash green, since the program will be stopped automatically. → Section "3.6 LED indicators", page 60.

Status LED		Description
red	green	
PLC	–	–
	–	Flashes
	–	ON
	ON	–
	ON	ON
		RuntimeSystem not started • No power on X6
		Communication
		PLC RuntimeSystem started
		Error status of the RuntimeSystem • Flash Error • Checksum error • Could not start SSL connection Fix: Check the log file
		RuntimeSystem has started and is signaling an error condition.

1) Flashes: The flashing frequency can vary depending on the transfer rate on the bus.

A program error condition can be caused by the following:

- Watchdog: E.g., the interval time of a task > The watchdog time
- Unsuccessful data access: E.g., attempting to access a protected area

I/O system XN300 Master Diagnostics possibilities

For errors that occur in the system block (XC-303 locally expanded with modules with I/O system XN300), the status can be requested from the XN300 master for diagnostic purposes. To do so, follow the steps below:

- ▶ Open XSOFT-CODESYS-3 to access the device online.
- ▶ In the configuration tree, select the "Device (XC-303)" device and "XN300_Master".
- ▶ Double-click on "XN300_Master" and open the "XN300Master Parameters" tab.

- In an error scenario, the "Current value" column will contain an error number and a corresponding description. For instance, the following example has error number "47" and "The CoDeSys SDIAS configuration is not yet found on the PLC!" as the description.





Figure 61: "XN300Master Parameters" tab with error message

Display example showing messages for the local XN300 system bus



For more information on diagnostics, please refer to the manual for the I/O system XN300, "XN300 slice modules" and "CANopen Gateway XN-312-GW-CAN"

Shell commands for diagnosing I/O system XN300 modules used

- In Explorer, double-click on the device (e.g., "Device (XC-303)") and select "PLC Shell" under the "Device" tab.
- Enter the "?" command into the command line.

4.8 Factory reset

4.8.1 Resetting the device to factory settings

If you want to reset the device to factory settings, you can use either the XControl web configuration server or the native configuration tool (on XV devices).

If you use the XControl web configuration server, follow the steps below:

- ▶ First log in to the device
- ▶ Go to the "Device" configuration page.
- ▶ Click on the "Factory reset" button. A confirmation prompt will appear.
- ▶ Confirm with OK. The device will be reset to factory settings, which might take a few minutes.
- ▶ When the device has restarted and is ready (PLC LED is green), refresh the browser window.
- ▶ You can proceed with the device configuration as explained in
→ Section "13.1 Logging in to the Web Config Tool", page 122.

5 Connection set-up PC – PLC

The connection between PC and CPU (PLC) can be established via one of the Ethernet interfaces eth0 to eth2.

The Ethernet connection's transfer rate will be controlled with the autosensing function. Components in (detect) mode will automatically detect whether the connection is a 10 Mbit or 100 Mbit connection.

In this chapter you will get to know the settings to be made in the XSOFT-CODESYS-3 software. The following example shows how to create a new project.

5.1 Network search with automatic PLC detection

The PC will attempt to connect to the PLC and will indicate a successful connection with green circles.




Figure 62: Successful connection between PC and XControl PLC

5 Connection set-up PC – PLC

5.2 Creating a new project

5.2 Creating a new project

- ▶ Start by making sure that you have connected the PC's Ethernet port or USB/Ethernet adapter to the device's Ethernet port with a cable.
- ▶ Make sure that the IP addresses for the PC and the device are in the same number range.
- ▶ Start the XSOFT-CODESYS-3.
- ▶ Click on "File", "New Project", "Standard Project" and enter a project name (e.g., "Test").
- ▶ In the next screen, select a device (e.g., "XC-303 (Eaton Automation)") and the programming language you want to use (e.g., "structured text" [ST]).
- ▶ Confirm the information being displayed by clicking on "OK."

The device will be added to the project. The default tree for the project will be generated as the corresponding configuration tree. The application will contain the library manager with all required libraries, and the "PLC_PRG" Main Task will have also been created already.

Establishing communications

- ▶ You can edit and rename the device name (e.g., "Device (XC-303)"), the "Application" application, and the "PLC_PRG" main program if necessary.
- ▶ Double-click on the "Device (XC-303)" device and select the "Communication" tab.
- ▶ Click on the "Search network" button or enter the PLC's IP address.

All the devices that can be reached will be listed.

- ▶ Clicking on the "Flash" button will cause the selected device to output a temporary flashing pattern.



Use this function to clearly identify the PLC.




Figure 63: Adding a device with the corresponding IP address

5.3 Changing the IP address on the PLC

When changing IP addresses, make sure that the IP addresses for the PC and the Modular PLCs XControl: XC-104-..., XC-204-..., XC-303-... belong to the same network/subnet.

Example:

IP address **PC**:192.168.119.100

Subnet mask:255.255.255.0

XControl IP address:192.168.119.204

Subnet mask:255.255.255.0

There are three different ways to change the PLC's IP address:

1. PLC shell commands `getipconfig; setip... ..addr/...netmask/...gateway`
2. `setipconfig` and `getipconfig` functionality in the `EA_Network` library
3. `networkconfig.template` on MicroSD memory card or USB device
4. Web Config Tool for XC-104-... and XC-204-... modular PLCs → Section "Change the device's IP address", page 130.

PLC shell command


- ▶ Open the PLC browser – please refer to → Section "16.1 Using PLC shell commands", page 141.
- ▶ Enter `setipconfig <IP address>` into the command line
- ▶ Confirm with <Enter>.
- ▶ Restart the device after you have changed the IP address.

setipconfig function

Make sure that the `EA_Network` library has been added in the library manager.

Use the function in your program (in "PLC_PRG", for example).

- ▶ To do this, open the input assistance function with <F2>.



- ▶ Select "Function block call" under "Categories."

5 Connection set-up PC – PLC

5.3 Changing the IP address on the PLC

- ▶ Select "EA_Network", "POUs", "Configure local ethernet interface", "NET_SetIPConfig".
- ▶ Enter the port, the IP address, and the subnet mask as the corresponding parameters.

networkconfig

If you are unable to establish a connection to the device (because you do not know the IP address, for example), you can use the "networkconfig.template" file with a MicroSD memory card or a USB device to set a new IP address for the XControl's Ethernet interfaces.

Setting the IP address for Ethernet interface ethx:

Prerequisites: The NW_UPDATE_FROM_USB or NW_UPDATE_FROM_SD tag must be set to "1".

In the case of XC-104-... and XC-204-... modular PLCs, the device's Ethernet interface must additionally be activated – please refer to → Section "13.4.3 USB interface activation", page 127.

- ▶ Save the "networkconfig.template" file in a directory on your PC. On the XC-303, the file will be found in the "one" directory
- ▶ Edit the file.
- ▶ Assign a valid IPv4 IP address and subnet mask
For example: ETH1_IP_ADDRESS=192.168.137.248 and
ETH1_SUBNET_MASK=255.255.255.0



If the properties for an Ethernet adapter change, all the parameters need to be completely entered into the file even if they match the corresponding default settings.

- ▶ Save the "networkconfig.template" file as a file named "networkconfig".
- ▶ Copy the file to the "XC303/update" directory on the MicroSD memory card/USB device.
- ▶ Insert the MicroSD memory card into the XControl.
- ▶ Reboot the XControl and then delete the file from the MicroSD memory card/USB device.

6 08/25 MN050005ENIn-/output configuration and parameterization

6.1 Configuring the device's local inputs/outputs

The I/Q1 to I/Q4 local inputs/outputs of the PLC are configured as inputs by default. If you want to change this configuration, follow the steps below:

- ▶ Select the device in the configuration tree and double-click to open the "Device" tab.
- ▶ Select "LOCAL_IO Parameter".
- ▶ Double-clicking on a cell in the "Value" column will show a drop-down menu that you can use to define the node as an input, output, or interrupt input.




Figure 64: Configuration of the inputs/outputs

6.2 Interrupt processing

When an interrupt occurs, the operating system executes the program organization unit (POU) linked to the interrupt source.



The execution of the interrupt POU is **not** time monitored. Programmed infinite loops will not be exited!

Local inputs I1 to I4 can be used as interrupt sources.

They can be configured with Device-> local _IOParameters.

Available settings:

- Int falling
- Int rising
- Int descending + rising

The POU called by the interrupt-event is always completely processed and cannot be interrupted by a new interrupt. A new interrupt is only carried out after the current interrupt has ended.

ATTENTION

All the outputs controlled (H signals) up to this point remain active and can't be switched off.

The interrupts are enabled in the RUN state of the CPU and inhibited in the STOP state. Interrupt sources that are not enabled in the configuration will not trigger an interrupt. If a POU is not assigned to an enabled interrupt source, the interrupt is recognized and executed but without running a POU.

Frequent occurrence of an interrupt during program execution can cause the programmed task time to time-out and result in a RESET being initiated by the Watchdog.

Interrupts can be inhibited and re-enabled from the program. The functions `DisableInterrupt` and `EnableInterrupt` are provided for this purpose. A call parameter in the XSOFTE-CODESYS-3 software determines if an individual interrupt or all interrupts are enabled or inhibited. Enabling of an inhibited interrupt must be performed with the same parameter used to inhibit it.

Both the `DisableInterrupt` and `EnableInterrupt` functions are components of the `EA_XC303Events.lib` library. This library must – if not already done so – be integrated into the library manager of the XSOFTE-CODESYS-3, see → Section “15.2 Installing additional system libraries”, page 138.

DisableInterrupt

With this function, you disable (deactivate) a parameterized physical interrupt by accessing it from the user program.




Figure 65: "DisableInterrupt" function

EnableInterrupt

With this function, the physical interrupt which was deactivated beforehand can now be re-enabled as an active interrupt.




Figure 66: "EnableInterrupt" function

Parameterization

The parameterization and prioritization of the interrupt occurs in the "PLC and Task Configuration" of the CODESYS (activate the "Resources" tab and call up the "Task configuration → system events" folder). Each interrupt can be assigned with a POU here.

Example of interrupt processing

A "Basic" task contains a POU "PLC_PRG". A further POU "Fastprog" should be processed if an L → H rising edge on the input I0.4 generates an interrupt.

- Create the POUs „FAST_PRG“ as shown in Figure 67.




Figure 67: PLC and Task configuration

- Changeover to the PLC configuration and assign input I0.4 (L → H edge) e.g. the interrupt source "Interrupt - rising edge" from the drop-down menu.




Figure 68: allocation I0.5 → interrupt source

- Change over to the Task configuration and open the "System events" folder.




Figure 69: System events

- ▶ Select "UserInterrupt 4".
- ▶ Select the "Called POU" column area.
- ▶ Select the "FAST_PRG" POU and confirm with "OK".
- ▶ Save the project. You can now test it.

The "FAST_PRG" program will be called with every rising edge at input 4.

7 Defining system parameters

7.1 Overview

7 Defining system parameters

7.1 Overview

System parameters independent of the project can be set by you and saved on the memory card. These parameters will be grouped together on the card in the following files:

- `networkconfig.template` -> `networkconfig`
- `deleteboardapplication.template` -> `deleteboardapplication`

You can also use the memory card in other PLCs. When starting, the PLC will automatically apply the parameters defined in the files.

- SD/USB in XC-303/update folder
- `deleteboardapplication.template` -> `deleteboardapplication`

Templates on the PLC in the "home" folder.

7.2 Default parameters

The InitPLC file is always created with all PLC-specific entries.

Default parameters are stored internally in the system. They can be read out in the shell with `getinitplcsettings` and set with `setinitplcsetting <arg>`.

All parameters are predefined already. The following screenshot shows the parameters with the corresponding default values, which you can change as necessary.

```
getinitplcparam

ENABLE_SSH=1
ENABLE_SFTP=1
ENABLE_PING_RESPONSE=1
OVERWRITE_BP=1
COPY_BOOTPROJECT_FROM_SD=1
COPY_BOOTPROJECT_FROM_USB=1
COPY_BOOTPROJECT_FROM_USER_DEFINED_BP_PATH=0
USER_DEFINED_BP_PATH=
ALLOW_BOOTPROJECT_DELETION=1
FW_ONLY_NEWER_VERSION=0
FW_FORCED_OVERWRITE=0
FW_INSTALL_FROM_SD=1
FW_INSTALL_FROM_USB=1
```

```

FW_INSTALL_FROM_XSOFTCODESYS=1
FW_INSTALL_FROM_USER_DEFINED_FW_PATH=0
USER_DEFINED_FW_PATH=
NW_UPDATE_FROM_USB=1
NW_UPDATE_FROM_SD=1
PLC_START_DELAY_SEC=4
DISABLE_PLC_START=0
PLC_CORE_USAGE=CORE_1
PLC_SUPERVISE_RTS=1
PLC_REBOOT_ON_RTS_TERMINATION=1
LOGFILE_DIR=/var/log
LOGFILE_STARTUP=XC303Log.txt
LOGFILE_RTS=codesyscontrol.log
MAP_NFS_FOLDER=0
NFS_SOURCE_PATH=
MAP_CIFS_FOLDER=0
CIFS_SOURCE_PATH=
CIFS_USER_NAME=
CIFS_DOMAIN_NAME=
CIFS_PASSWORD=

```

7.3 Switch-on of the control with inserted memory card

These system parameters are also active after a new program is loaded.

The start process will update the following:

- Firmware
- Boot project (user program)
- Network configuration

See also → Section “3.3 Startup behavior XC-104-..., XC-204-..., XC-303-...”, page 53.

For all checks in general after the Modular PLCs XControl: XC-104-..., XC-204-..., XC-303-... start, the MicroSD slot will be checked first and then the USB Host!

If there is a boot application on the MicroSD memory card or USB device and it is a newer version than the one stored in the XControl, the boot application in the PLC will be updated.

The retentive data will then be loaded.

If the PLC is in the middle of a warm/cold start and the "STOP" DIP switch is in the "OFF" position, the user program will be started.

The positions of the DIP switch are described in detail in → Section “3.4.1 DIP switch S1”, page 55.

7.4 networkconfig file

You can change the device settings for the network in this file. Blank entries will be ignored.

7 Defining system parameters

7.4 networkconfig file

To modify the parameters, follow the steps below:

Prerequisite: The NW_UPDATE_FROM_USB or NW_UPDATE_FROM_SD tag must be set to "1".

- ▶ Open the "networkconfig" file and edit the parameters you want.
- ▶ Save the edited file with the name "networkconfig" in the ".XC303/update" directory on the MicroSD memory card or USB device.
- ▶ Insert the MicroSD memory card into the slot or plug in the USB device.
- ▶ Start the Modular PLCs XControl: XC-104-..., XC-204-..., XC-303-....

You can find templates for the "networkconfig" and "deleteBootproject" files on the Eaton Download Center.

Table 13 Predefined default parameters in the networkconfig file

```
#-----  
# ETH 0  
#-----  
ETH0_DISABLE=  
# 1 will disable the interface.  
# Default value:0  
  
ETH0_ENABLE_DHCP=  
# 1 will enable dhcp client on the interface.  
# Default value:0  
  
ETH0_IP_ADDRESS=  
# Should contain a valid IP-v4 ip-address,  
# if DHCP is enabled this field must be left blank.  
# Default value:192.168.119.248  
  
ETH0_SUBNET_MASK=  
# Should contain a valid IP-v4 subnet mask  
# Default value:255.255.255.0  
  
ETH0_BROADCAST=  
# Should contain a valid broadcast address  
# Default value:255.255.255.255  
  
ETH0_DEFAULT_GATEWAY=  
# Should contain a valid IP-v4 ip-address of the default gateway.  
# Default value: no default value.
```



```
#-----  
# ETH 1  
#-----  
ETH1_DISABLE=  
# 1 will disable the interface.  
# Default value:0  
  
ETH1_ENABLE_DHCP=  
# 1 will enable dhcp client on the interface.  
# Default value:0  
  
ETH1_IP_ADDRESS=  
# Should contain a valid IP-v4 ip-address,  
# if DHCP is enabled this field must be left blank.  
# Default value:192.168.137.248  
  
ETH1_SUBNET_MASK=  
# Should contain a valid IP-v4 subnet mask  
# Default value:255.255.255.0  
  
ETH1_BROADCAST=  
# Should contain a valid broadcast address  
# Default value:255.255.255.255  
  
ETH1_DEFAULT_GATEWAY=  
# Should contain a valid IP-v4 ip-address of the default gateway.  
# Default value: no default value.  
#-----  
# ETH 2  
#-----  
ETH2_DISABLE=0  
# 1 will disable the interface.  
# Default value:0  
  
ETH2_ENABLE_DHCP=  
# 1 will enable dhcp client on the interface.  
# Default value:0  
  
ETH2_IP_ADDRESS=  
# Should contain a valid IP-v4 ip-address,  
# if DHCP is enabled this field must be left blank.  
# Default value:192.168.138.248  
  
ETH2_SUBNET_MASK=  
# Should contain a valid IP-v4 subnet mask  
# Default value:255.255.255.0  
  
ETH2_BROADCAST=  
# Should contain a valid broadcast address  
# Default value:255.255.255.255  
  
ETH2_DEFAULT_GATEWAY=  
# Should contain a valid IP-v4 ip-address of the default gateway.  
# Default value: no default value.
```

8 Expansion

8.1 Local expansion

The XControl PLC can be expanded locally with up to 32 XN300 slice modules. To do this, the PLC and the XN300 slice modules need to be joined together and mounted on a mounting rail (DIN-rail) as a block. The I/O system XN300 has a large range of XN300 slice modules available that offer special functionalities in addition to digital and analog inputs and outputs, with two examples being a weigh module and a motor driver module.



For the latest information on the I/O system XN300, please visit our product pages:

Eaton.eu/xn300

and use the Eaton Online Catalog for information on the available range of products:

Eaton.com/ecat

Enter "XN300" into the search box and the catalog will take you directly to the corresponding product group.

The "XN300 slice modules" manual describes all modules.




Figure 70: XControl central expansion XN300 slice modules

8.1.1 Configuring the inputs/outputs for local expansions

If you have expanded the XControl PLC with XN300 slice modules and assembled them into a system block mounted on the DIN-rail, you can set up the corresponding configuration in XSOFT-CODESYS-3 as follows:

- ▶ Make sure that all XN300 slice modules are connected and powered.
- ▶ Open the XSOFT-CODESYS-3 project.
- ▶ In the device tree, select the "Device (XC-303)" device.
- ▶ Select the "Add device..." option in the context menu.
- ▶ Select the "XN300-Master" under "Miscellaneous" in the "Add device" dialog box.
- ▶ Confirm by clicking on the "Add Device" button.

The XN300_Master will appear in the device tree.

- ▶ Select the "XN300-Master" in the device tree.
- ▶ In the "Add device" dialog box, under "Miscellaneous," select the XN300 slice modules that you used to make a system block with the XControl. Select the XN300 slice modules in the same order that they are physically connected to the XControl.

The device tree will now show all the devices. Alternatively, the customer can perform a device scan.




Figure 71: Device tree with XN300 slice modules

8 Expansion

8.1 Local expansion




Figure 72: Declaring values




Figure 73: Define XN300 slice modules parameters

8.2 Remote expansion

→ Section “Modular PLCs XControl: XC-104-..., XC-204-..., XC-303-... support distributed expansion with the use of fieldbus interfaces. The following communication protocols are supported by the corresponding interfaces as follows:”, page 11

The following sections describe the individual fieldbus interfaces.

9 CAN

The components in the XN300 I/O system can be networked into a CAN node with the XControl: XC-204-..., XC-303-... modular PLCs with the Eaton CAN-Gateway XN-312-GW-CAN.

Each CAN node makes it possible to add expansions with the I/O system XN300 by adding up to 32 XN300 slice modules.




Figure 74: CAN node as a distributed expansion for the Modular PLCs XControl: XC-104-..., XC-204-..., XC-303-...

To do this, you will need to mount the system block consisting of a gateway and XN300 slice modules on a DIN-rail. The system block and the PLC can be mounted separately from each other. The XN300 system has a large range of XN300 slice modules available that offer special functionalities in addition to digital and analog inputs and outputs, with two examples being a weigh module and a motor driver module. For an overview of the XN300 slice modules, please refer to the "XN300 slice modules" manual.


The distance between the modular PLCs and an XN300 gateway can be up to 1000 m. The actual value depends on the baud rate used – please refer to → Section "Table 6 Max. cable lengths CAN", page 28.

9.1 Configuring and commissioning CANopen

Modular PLCs XControl: XC-104-..., XC-204-..., XC-303-... can communicate both through CAN and through CANopen. Communication through CANopen is described below.

Any CAN gateway can be connected to the CAN master by using the appropriate EDS file.

Following is an example showing how to connect an XN-312-GW-CAN CANopen gateway, including XN300 slice modules, to the CANopen master.



If you are putting the field bus into operation for the first time, you will first have to set up the PLC programming environment.

Initial commissioning

The following steps need to be carried out in general:

- ▶ Connect the Modular PLCs XControl: XC-104-..., XC-204-..., XC-303-... to the programming PC
- ▶ Connect the PLC to the CAN-Gateway XN-312-GW-CAN with a CAN bus cable.
- ▶ Set the DIP switches for CAN
 - Section "Activating the bus termination resistors", page 27.
- ▶ Set the node ID and the baud rate
- ▶ Save the configuration for the I/O system XN300 connected to the CAN-Gateway XN-312-GW-CAN in the "config check" on the gateway.
- ▶ Open your project in XSOFT-CODESYS-3 or create a new one
 - Section "5.2 Creating a new project", page 87.

9 CAN

9.1 Configuring and commissioning CANopen

9.1.1 Adding the CAN manager

- ▶ In the device tree, select the "Device (XC-303)" device.
- ▶ Right-click on it to open the context menu and select the <Add device...> option.

The "Add device" dialog box will appear. You can leave the dialog box open.

- ▶ Select the "CANbus" under "Field buses" in the "Add device" dialog box.
- ▶ Confirm by clicking on the "Add Device" button.

The CANbus will appear in the configuration tree.

- ▶ Select "CANbus" in the configuration tree.
- ▶ Select the baud rate.
- ▶ Select the "CANopen Manager" under "Field buses" in the "Add device" dialog box.

The CANopen Manager will appear in the configuration tree. EDS files for Eaton field bus modules will be installed automatically.




Figure 75: CANopen parameters for CANopen manager

9.1.2 Setting the baud rate via CANbus

- ▶ In the "Devices" configuration structure, double-click on <CANbus (CANbus)>.
- ▶ Open the "CANbus" tab and select the baud rate you want, e.g., <125000>.




Figure 76: CANopen manager baud rate



For more detailed information, please refer to the online help for XSOFT-CODESYS-3, which can be opened by pressing the <F1> function key.

- ▶ The EDS files for the field bus modules from other manufacturers must be additionally installed in XSOFT-CODESYS-3 – please refer to → Section "9.1.5.2 Installing the EDS file", page 109.

9 CAN

9.1 Configuring and commissioning CANopen

9.1.3 Incorporating the CAN-Gateway XN-312-GW-CAN

- ▶ To add the CANopen gateway to your configuration, right-click on "CANopen manager (CANopen manager)."
- ▶ Click on the <Add device...> option.

The list will show all the devices that can be configured:




Figure 77: Adding a CANopen device

- ▶ Select the corresponding CAN-Gateway XN-312-GW-CAN.
- ▶ Click on the <Add device> button.

The selected CAN-Gateway XN-312-GW-CAN will be added to the configuration tree.

- ▶ If the CAN devices you want are not found in the list, update the XSOFT-CODESYS-3 version you are using or load the appropriate EDS file → Section "9.1.5.2 Installing the EDS file", page 109.
- ▶ Check the settings for the parameters for XN_312_GW_CAN by double-clicking on "XN_312_GW_CAN (XN-312-GW-CAN)" in the configuration tree.
- ▶ Open the "XN_312_GW_CAN/General" tab and check the device's "Node ID."



For more information on all other gateway settings and on mapping, please refer to the manual for CAN-Gateway XN-312-GW-CAN.

9.1.4 Attach XN300 slice modules

- ▶ To configure the system block, right-click on the CANopen device, e.g., "XN_312_GW_CAN (XN-312-GW-CAN)" in the "Devices" configuration structure.
- ▶ Then click on the <Add device...> option.

The "Add device" dialog box will appear if it is not open already. The dialog box will show a list with all the XN300 slice modules that can be configured.

9.1 Configuring and commissioning CANopen




Figure 78: "Add device" dialog box for selecting CAN modules for the XN-312-GW-CAN

► Select the XN300 slice module you want and then select <Add device>. The XN300 slice module will be added to the "Devices" configuration structure.



You can change the order of the XN300 slice modules in the configuration structure by dragging and dropping them accordingly.

A maximum of 32 XN300 slice modules can be added to the CANopen device.

The device tree will now show all the devices.




Figure 79: XControl with CANopen master, CAN-Gateway XN-312-GW-CAN, and four XN300 slice modules

If you are using analog modules, observe the following requirements:

- If you use the default mapping (index 0x6401/x) for analog modules, you will need to enable PDO-based transmission for these I/O slice modules by setting the value of object index 0x6423, subindex 0 to TRUE.
- Regulate the bus load on the CAN field bus
The following procedure is recommended in order to prevent the XN-312-GW-CAN gateway from generating a heavy load on the CAN field bus:

9 CAN

9.1 Configuring and commissioning CANopen

- Use internal module filters; please consult manual "XN-300 Slice Modules", MN050002-EN.
- If you use the default mapping (index 0x6401/x), you can configure a transmission filter for each individual payload object (SDO objects: AI_DELTA_VALUE, index 0x6426/x).
When this filter is configured, the gateway will update and transmit the corresponding value only if this value is different from the last transmitted value by more than the configured delta.

By setting an inhibit time or selecting a synchronous transmission type, TPDO properties can be configured in such a way as to avoid impermissible bus loads .

NOTICE

The short data refresh cycle times in the XN300 system can result in the CAN transmission path being subjected to high loads. Accordingly, it is recommended to limit the data being transmitted by using the various PDO properties available (e.g., inhibit time), especially in the case of analog input and technology modules featuring counters.

9.1.5 Description files for CANopen

The gateway XN-312-GW-CAN is integrated into the CANopen structure with the aid of a standardizes EDS file (Electronic Data Sheet).

This EDS file lists all objects with the associated sub-indexes and the corresponding entries. The EDS file will be installed automatically in XSOFT-COD-ESYS-3 with the CANopen master.

9.1.5.1 Standard EDS files

Make sure that you are working with the latest version of the standard EDS files in your PLC programming environment. If modules are not listed, check whether there are available updates for the files in the Download Center
→ Page 7. To find it quickly, simply enter "XN300" or "EDS" as a search term.

9.1.5.2 Installing the EDS file

If you want to install an updated EDS file or an EDS file from another device manufacturer, follow the steps below:

- ▶ Select and download the latest version of the EDS file.
- ▶ Save and unzip the "*.zip" file to a project folder of your choice.
- ▶ Click on the <Tools | Device Repository...> menu option in XSOFT-COD-ESYS-3.
- ▶ Click on the <Install...> button.
- ▶ Use Explorer to select the EDS file you want.
- ▶ Confirm with click on <Open>.
- ▶ Click on "OK" on the "The device has been successfully installed" prompt.

9.1 Configuring and commissioning CANopen




Figure 80: "Devices" pane with CAN manager in the configuration structure

- ▶ Double-click on CANopen_Manager (CANopen Manager).
- ▶ Check the settings under the "CANopen Manager" tab.

9.1.6 LEDs on the device

The status display LEDs in the front signal the corresponding state.

→ Section "3.6 LED indicators", page 60

	Status LED		Description
	red	green	
CAN1	—	—	No bus activity
CAN2	—	Flashes	Bus activity OK (CAN), FLASHES with every frame
	ON	—	Bus error
	Flashes	Flashes	Warning

1) Flashes: The flashing frequency can vary depending on the transfer rate on the bus.

Every successfully transmitted/received CAN frame triggers the LED.

10 EtherCAT

10.1 Incorporating the EtherCAT master

10 EtherCAT

Following is a description explaining how to configure the XC-204-... / XC-304-... PLCs as EtherCAT master in order to operate EtherCAT modules.

The Eaton EtherCAT Gateway XN-312-GW-EC is used as an example of an EtherCAT module in this case. This EtherCAT gateway assumes the coordinator role for additional modules and their input and output functions.

Further information about the gateway:

- Manual „EtherCAT Gateway XN-312-GW-EC“:
<https://www.eaton.eu/documentation>
Document number „MN050010“
- Device description files:
<https://www.eaton.eu/software>
Device Description Files > XN300 > XN-312-GW-EC

10.1 Incorporating the EtherCAT master

- ▶ In the device tree, select the "Device (XC-303)" device.
- ▶ Right-click on it to open the context menu and select the <Add device...> option.

The "Add device" dialog box will appear. You can leave the dialog box open.

- ▶ Select "EtherCAT | Master | EtherCAT Master" under "Field buses" in the "Add device" dialog box.
- ▶ Confirm by clicking on the "Add Device" button.

The EtherCAT master will appear in the configuration tree.




Figure 81: Device tree with EtherCAT master

10.2 Configuring the EtherCAT master

- ▶ Double-click on "EtherCAT_Master (EtherCAT Master)" in the PLC configuration device tree.
- ▶ Click on the <Search> button in the "General" tab.

10 EtherCAT

10.2 Configuring the EtherCAT master




Figure 82: EtherCAT master parameters

XSOFT-CODESYS-3 will show the MAC addresses and names for the Ethernet interfaces on the XControl PLC.




Figure 83: List of all XC-303-C32-002 PLC Ethernet interfaces found

- ▶ Select the Ethernet port to which you connected or will be connecting the EtherCAT gateway. The eth2 interface is preferred for the XC-303.
- ▶ Select the "Select network by name" setting in the "General" tab. This will make the PLC connect by name (e.g., "eth2") independently of the MAC address.
- ▶ Enable the "Automatic slave restart" option so that communication with the modules will start automatically.




Figure 84: EtherCAT master settings

10 EtherCAT

10.3 Searching for and incorporating EtherCAT modules

10.3 Searching for and incorporating EtherCAT modules

To connect the XControl PLC to an EtherCAT module, follow the steps below:

- ▶ Log in to the XControl PLC by using the <Online|Log in> command sequence in XSOFT-CODESYS-3.
- ▶ Right-click on "EtherCAT_Master (...)"
- ▶ Then select <Search for device...>.

The PLC programming software will run an automatic search for all devices connected to the XControl EtherCAT_Master. The search result list dialog box will show all the devices that were found.




Figure 85: Search result list for the search for devices

- ▶ Click on the <Copy all devices to the project> button.

The devices will be shown in the PLC configuration's device tree. Modules that are already connected to the EtherCAT gateway will also be shown in the device tree automatically.




Figure 86: Device tree with EU5C-SWID-ETHERCAT gateway and SmartWire-DT modules

- ▶ If the EtherCAT devices you want are not found in the list, update the XSOFT-CODESYS-3 version you are using or load the appropriate XML file; → Section "10.5 Description files for EtherCAT", page 114.
- ▶ Check the settings for the parameters for the EtherCAT gateway by double-clicking on "XN_312_GW_EC (...)" in the device tree.



For more information on gateway settings, please refer to the gateway manual and the XSOFT-CODESYS-3 Online Help.

10.4 Incorporating EtherCAT modules manually

As an alternative to the description in → Section "10.3 Searching for and incorporating EtherCAT modules", page 113, you can also add the EtherCAT modules to the XControl PLC manually. To do so, follow the steps below:

- ▶ Right-click on "EtherCAT_Master (...)" in the device tree.
- ▶ Click on the <Add device...> option.

The list will show all configurable devices:




Figure 87: Adding an EtherCAT device

- ▶ Select the EtherCAT module.
- ▶ Click on <Add device> in the "Add device" dialog box.

The EtherCAT module will be added to the device tree.

10.5 Description files for EtherCAT

Device description files in XML format are required in order to incorporate and configure EtherCAT modules in XSOFT-CODESYS-3. These files contain standardized descriptions of the EtherCAT modules and their parameters.

The device description files are installed in XSOFT-CODESYS-3 automatically with the EtherCAT master.

10.5.1 Standard XML files

Make sure that you are working with the latest version of the device description files in your PLC programming environment. If modules are not listed, check whether there are available updates for the files in the Download Center of the respective device manufacturer.

10.5.2 Installing the XML file

If you want to install an updated XML file or an XML file from another device manufacturer, follow the steps below:

- ▶ Select the latest version of the device description files and download them.
- ▶ Save and unzip the "*.zip" file to a project folder of your choice.
- ▶ Click on the <Tools | Device Repository...> menu option in XSOFT-CODESYS-3.
- ▶ Click on the <Install...> button.
- ▶ Use Explorer to select the XML file you want in the project folder.

10 EtherCAT

10.5 Description files for EtherCAT

- ▶ Confirm with click on <Open>.
- ▶ Confirm the "The device has been successfully installed" prompt by clicking on "OK".
- ▶ Double-click on "EtherCAT_Manager (EtherCAT Manager)".
- ▶ Check the settings under the "EtherCAT Manager" tab.

11 Modbus

11.1 Configuring Modbus TCP

11.1.1 Adding an Ethernet adapter

XSOFT-CODESYS-3 offers two different Ethernet connection options. An Ethernet adapter can be used to define the corresponding protocol: EtherNet/IP or Modbus TCP.

- ▶ In the device tree, select the "Device (XC-303)" device.
- ▶ Right-click on it to open the context menu and select the <Add device...> option.

The "Add device" dialog box will appear. You can leave the dialog box open.

- ▶ Select "EtherNet/IP | Ethernet Adapter| Ethernet" under "Field buses" in the "Add device" dialog box.
- ▶ Confirm by clicking on the "Add Device" button.

The Ethernet master will appear in the configuration tree.




Figure 88: Ethernet master parameters

11.1.2 Adding a Modbus TCP master and device

- ▶ To add the Modbus TCP master to your configuration, right-click on "Ethernet (Ethernet)":
- ▶ Click on the <Add device...> option.

The list will show the available Ethernet devices or Ethernet-based protocols such as Modbus.

- ▶ Select "Modbus | Modbus TCP Master | Modbus TCP Master".
- ▶ Then click on the <Add device...> option
- ▶ Select "Modbus TCP Master" in the device tree.
- ▶ Right-click on it to open the context menu and select the <Add device...> option.
- ▶ Select "Modbus TCP Slave".
- ▶ Then click on the <Add device...> option

11 Modbus

11.1 Configuring Modbus TCP




Figure 89: Adding a Modbus TCP slave

The TCP master does not need information specifying which Modbus_TCP_Slave is on the bus. It only needs the Modbus_TCP_Slave's IP address and register number.

- ▶ Select the "Modbus_TCP_Slave" slave connection in the configuration tree.
- ▶ Click on the <Add device> button.

The Modbus TCP device will be added to the configuration tree.

A maximum of 32 Modbus TCP masters can be added.




Figure 90: Modbus TCP master parameters




Figure 91: Modbus TCP slave parameters

11 Modbus

11.1 Configuring Modbus TCP




Figure 92: Modbus TCP slave parameters

11 Modbus

11.2 Configuring Modbus RTU

11.2 Configuring Modbus RTU

11.2.1 Adding a Modbus master

- ▶ In the device tree, select the "Device (XC-303)" device.
- ▶ Right-click on it to open the context menu and select the <Add device...> option.

The "Add device" dialog box will appear. You can leave the dialog box open.

- ▶ Select "Modbus | Modbus Serial Port| Modbus COM Port" under "Field buses" in the "Add device" dialog box.
- ▶ Confirm by clicking on the "Add Device" button.

The Modbus_COM_Port will appear in the configuration tree.




Figure 93: Modbus COM port parameters

11.2.2 Adding Modbus modules

- ▶ To add a Modbus module to your configuration, right-click on the "Modbus_COM_Port" node.
- ▶ Click on the <Add device...> option.

The list will show all the devices that can be configured:




Figure 94: Adding a Modbus device

- ▶ Select the corresponding Modbus device, e.g., "Modbus Serial Device."
- ▶ Click on the <Add device> button.

The selected Modbus device will be added to the configuration tree.

12 Web Visu XSOFTECODESYS-3

Modular PLCs XControl: XC-104-..., XC-204-..., XC-303-... feature a web server used to deploy the visualization generated by XSOFTECODESYS-3. The way the web visualization is handled is explained in the XSOFTECODESYS-3 Help.

Keywords: CODESYS visualization / "Web Visu" object

12.1 Opening XSOFTECODESYS-3 WebVisu

A description of the web visualization interface can be found in section 7.4, "Web visualization", of the manual for programming PLCs with CODESYS.

The visualization can be accessed through any of the Ethernet interfaces on the Modular PLCs XControl: XC-104-..., XC-204-..., XC-303-....

However, this requires for a corresponding webvisu.htm XSOFTECODESYS-3 WebVisu project to be found on the device already.

If the device is addressed through Ethernet port eth2 with the default IP address, for example, the XControl-specific web visualization call will be as follows:

Unencrypted: <http://192.168.138.248:8080/webvisu.htm>

Encrypted: <https://192.168.138.248/webvisu.htm>

If you have changed the IP address, replace the IP address in the "http:\\..." call with the address you have selected.

ATTENTION

The number of clients that can access the Modular PLCs XControl: XC-104-..., XC-204-..., XC-303-... simultaneously is limited to 10.

12.2 Selecting the XSOFTECODESYS-3 WebVisu encryption type

The web server for XSOFTECODESYS-3 projects can be accessed either with the HTTP or HTTPS protocol. The 3S CODESYSControl.cfg file specifies which of the protocols should be available.

This file can be found on the device, in the "\\home\\codesys\\work\\config\\" directory. It can be loaded in XSOFTECODESYS-3 and written back after editing.

To change the protocol for the web server, follow the steps below:

Open the file and search for the entry for [CmpWebServer].

The Connection Type parameter will determine which protocols are permitted as follows:

12 Web Visu XSOF-TCODESYS-3

12.2 Selecting the XSOF-TCODESYS-3 WebVisu encryption type


ConnectionType=

0: Only HTTP connections allowed

1: Only HTTPS connections allowed

2: HTTP and HTTPS connections allowed

3: HTTP and HTTPS connections allowed, but access via HTTP will automatically be redirected to HTTPS.



```
OSPriority.High.End=155
#16 priority levles
OSPriority.AboveNormal.Base=156
OSPriority.AboveNormal.End=173
#16 priority levles
OSPriority.Normal.Base=184
OSPriority.Normal.End=201
#16 priority levles
OSPriority.BelowNormal.Base=202
OSPriority.BelowNormal.End=219
#8 priority levles
OSPriority.Low.Base=230
OSPriority.Low.End=239
#14 priority levles
OSPriority.Lowest.Base=240
OSPriority.Lowest.End=255

[CmpOpenSSL]
WebServer.Cert=server.cer
WebServer.PrivateKey=server.key
WebServer.CipherList=HIGH
WebServer.CertStoreBase=/home/etc/PKI/

[CmpWebServer]
FileUploadDirectory=/home/PlcPrg/visu
#EnableLogger=1
ConnectionType=2
#For ConnectionType there are the following options:
#0: Only http-connections are possible
#1: Only https-connections are possible
```


13 Web Config Tool for XC-104-... and XC-204-...

The Web Config Tool can be used to configure XC-104-... and XC-204-... modular PLCs with operating system version V3.1.0.0 or higher. Access is possible with an up-to-date browser installed on a connected device or the PC.



Please note that Internet Explorer is not supported.

Security

The encryption uses a 2048-bit RSA key. This key will be generated on the device the first time it starts. Please note that the Web Config Tool cannot be used at all without this encryption.

Since there is no way to check a certificate in local IP ranges, the "Untrusted certificate" dialog box will be shown. Instead, you can check whether the certificate's digital thumbprint has changed so as to prevent man-in-the-middle attacks.

Remote use

The XControl Web Config Tool can be accessed through a remote browser.

13.1 Logging in to the Web Config Tool

In order to be able to access the Web Config Tool, you must know the IP address of the device that you want to configure. The device or the PC with which you want to access the XControl device must be in the same subnet as the XControl device.

The service runs on port 8375 and uses the https protocol. This means that if the device's IP address is, for example, "192.168.119.204", the URL will be "https://192.168.119.204:8375/#/login".

To open the Web Config Tool, follow the steps below.

After logging in, you can use the Web Config Tool as described below.

Password setup

If you reset the device to its factory settings, the Web Config Tool will ask you to create a password when you access the device. The default language will be English.




This means that the first person who logs in will be the person creating the password.

13 Web Config Tool for XC-104-... and XC-204-...

13.1 Logging in to the Web Config Tool

The following screen will appear:



The screenshot shows the 'Initial setup of remote user' interface. At the top, there is a toggle switch for 'Allow remote access without password'. Below this is a yellow warning box with a triangle icon stating: 'Enabling remote access without password can pose a security risk and is not recommended.' Underneath the warning is a 'Password' input field with a toggle icon on the right. Below the password field is a list of password requirements, each preceded by a checkmark: 'At least 8 characters in length', 'At least 1 digit', 'At least 1 uppercase letter', 'At least 1 lowercase letter', and 'At least 1 special character: (valid: ! @ # \$ ^ & *)'. Below these requirements is a 'Confirm password' input field, also with a toggle icon. At the bottom right of the form is a blue 'Apply' button.

Figure 95: Enter password

The password must meet the following requirements:

- Minimum of 8 characters in length
- At least 1 number
- At least 1 uppercase letter
- At least 1 lowercase letter
- At least 1 special character, with the following characters allowed: ! @ # \$ ^ &



Please note that the password will not be accepted unless all the above conditions are met.

After creating the password, you will be automatically authenticated.

Authentication and session

Once you create a password, the login screen will be shown every time you access the Web Config Tool afterwards.



Passwords are created during initial commissioning.




Figure 96: Authentication with password

You can change the password on the "Device" configuration page.



After 15 minutes of inactivity, you will be logged out automatically. When this happens, the login screen will be shown with a message saying that your session expired.

13.2 Navigation

After logging in, the following page will appear:




Figure 97: Web Config Tool start page

To navigate to a different page, you will need to click on the  button on the left in the top blue bar. Once you click on the button, a pane with all the configuration pages will appear. You can then access any configuration page from the pane.

You can close the pane with the configuration pages at any time by clicking on the < arrow at the top right of the pane.

To log off, click  in the upper blue bar.

13 Web Config Tool for XC-104-... and XC-204-...
13.3 Setting a language

13.3 Setting a language

As soon as the device is ready, the top blue bar will show the language selection drop-down menu for the Web Config Tool. As of this writing, German and English are available as languages. English will be selected by default.



Figure 98: English and German language selection options

13.4 Device configuration page – System configuration page





Figure 99: System configuration page with disabled USB interface

13.4.1 Device information

"Device information" will show information regarding the device and the image currently being run. In addition, you can change the password for the web configuration by clicking on the "Change password" button.



Device information	
Model number	XC-204-C11-003
Serial number	100000001098
Image name	eaton-image
Image version	v1.0.0-rc7
Bootloader version	2020.04.1.0
OS version	v3.2.0.0-rc11

Change password


Figure 100: Device configuration page – Device information section

13.4.2 Changing / setting up passwords

If you reset the device to its factory settings, the Web Config Tool will ask you to create a password when you access the device. The following screen will appear:

13 Web Config Tool for XC-104-... and XC-204-...

13.4 Device configuration page – System configuration page



Change password

Current password 

New password 

- ✓ At least 8 characters in length
- ✓ At least 1 digit
- ✓ At least 1 uppercase letter
- ✓ At least 1 lowercase letter
- ✓ At least 1 special character: (valid: ! @ # \$ ^ &)

Confirm new password 

Cancel Change password

Figure 101: Change password

Once you create a password, it will be possible to change it but not to delete it (unless you carry out a factory reset) – please refer to

13.4.3 USB interface activation

Enable USB

In the "USB" section, you can enable the USB interface by toggling the corresponding switch to the right and disable it by toggling it to the left. If the USB interface is not enabled, USB Autostart and USB factory resets will not be possible.

Enable/disable USB Autostart

The USB Autostart function is used to automatically start executable files on a plugged-in USB storage device when the device is booting up.

If USB Autostart is enabled, the system will search for shell scripts named "etn-startup.sh" in the root directory of the partitions on a plugged-in USB drive and run them with a GNU Bash interpreter.

Enable/disable USB factory reset.

The ability to reset the device to factory settings will be enabled (i.e., available) if you toggle the "Enable USB factory reset" switch to the right. For information on how to reset the XControl device to factory settings, please refer to → Section "3.10 Factory resetting XC-104-... and XC-204-...", page 68.




Figure 102: Device configuration page – USB section

13.4.4 Power management

You can restart and shut down the device in the "Power management" section. To prevent the device from being shut down or restarted accidentally, you will need to confirm these actions in a confirmation prompt.




Figure 103: System configuration – Power management section

13.4.5 Factory reset

In the "Factory reset" section, you can reset your device directly to factory settings without the need for additional preparation. A confirmation prompt will appear after you click on the button. If you confirm the "factory reset," the prompt will disappear.




Figure 104: System configuration – Factory reset section

All Ethernet ports will be reset to their default settings. If a password has been set, it will be deleted.

13 Web Config Tool for XC-104-... and XC-204-...

13.5 Network configuration page

A factory reset can also be carried out by plugging in a storage device into the device's USB port and booting the device – please refer to → Section “Enable/disable USB factory reset.”, page 127.

13.4.6 Powerfail

To keep data retentive, it will be copied from RAM to NVRAM when the device is switched off. As soon as the data has been stored, the time until the device is de-energized will be counted up. This time will be shown in the "Powerfail" section.

If this time falls below a value of 10 ms, an error message will appear in order to let you know that the data can no longer be stored in a retentive manner.

There are two possible causes for this error message:

1. The remaining time has decreased due to the components getting older.
2. The operating system is in an error condition.




Figure 105: System configuration – Powerfail section

13.5 Network configuration page

The number of "Network interfaces" sections that you can use to set up the IP configuration for each interface will depend on the specific number of network interfaces on the device.

The screenshot shows the 'System configuration' page. On the left, the 'Network interface eth0' section includes a DHCP toggle (currently off), and input fields for IP address (192.168.0.150), Subnet mask (255.255.255.0), Default gateway (192.168.0.1), DNS server (62.2.17.60), and MAC address (00:05:4b:05:2f:32). On the right, the 'General settings' section includes a Hostname field with the value 'eaton-ceag-x11'. Both sections have 'Reset changes' and 'Apply' buttons at the bottom.

Figure 106: Network configuration page with one Ethernet interface

Change the device's IP address

If you change the configuration, you will be disconnected from the Web Config Tool. If this happens, you will need to log in again with the new IP address. There are two options: The first one is to use static address assignments, in which case you will have to assign an IP address, a subnet mask, a default gateway, and a DNS server. The second is to enable the DHCP service, in which case a configuration will be automatically requested from your network – please refer to → Section “13.5 Network configuration page”, page 129.

You can change the hostname in the "General settings" section. This name will be used for specific multicast DNS services. This type of service, which you can use to find the device without knowing the corresponding IP address, is provided with XSOFT-CODESYS-3.

13 Web Config Tool for XC-104-... and XC-204-...

13.6 Update configuration page

13.6 Update configuration page

You can update the operating system and the bootloader under "Update." The runtime system cannot be updated with the Web Config Tool. It can only be updated with XSOF-TCODESYS-3.

You can upload a RAUC bundle in order to update the device's operating system or the bootloader. The file will have .raucb as an extension.

You can simply drag&drop the *.raucb file you want to use.



Do not turn off or unplug the device during the update!





Figure 107: No RAUC bundle selected

If you have already uploaded a RAUC bundle, the name of the bundle will be shown here.

After selecting the package and tapping the "Update" button, it is important for you to remain on the page until the upload is completed. You can follow the corresponding progress on the first progress bar, as shown below.

You can follow the corresponding progress on the first progress bar, as shown below.



Progress display

Once the upload has been completed, the second bar will show the installation progress.




Figure 108: Update progress bar

As soon as the update has been completed, you will need to restart the device in order to run the new version.

- To do this, click on the "Restart" button shown after the update is completed.



Please note that you can only apply one update after each restart.

13.7 Date & time configuration page

The "Date & time" configuration page will show the current device time without taking into account the local device's time zone.

The screenshot displays the 'System configuration' interface. On the left, the 'Date & Time' section shows the current device time as '13 February 2022 16:42:08' and the selected timezone as 'Etc/UTC'. It includes 'Reset changes' and 'Apply' buttons. On the right, the 'Time synchr NTP' section features an 'Enable' toggle, 'Preferred address' and 'Second address' both set to '127.0.0.1', and a 'Reset changes' button.

Figure 109: "Date & time" configuration page

13.7.1 Date & Time

You can set the time, including the corresponding seconds, and the time zone. If you change the time zone, the time shown above will not be re-calculated.

13.7.2 Time synchronization with NTP

In the "Time synchronization with NTP" section, you can enable NTP and select a preferred address and a backup address. The NTP service will then be used to correct the time and the system time every minute. This can also help counteract RTC drift if the device runs for multiple years or decades.

13.8 Remote access configuration page

You can use the "Remote access" configuration page to enable and disable the corresponding service.




Figure 110: "Remote access" configuration page

13.8.1 SSH


You can enable and disable remote access in the "SSH" section.



Make sure to disable SSH after you no longer need it and the device is in a production environment. This will disable remote access and improve the device's security.

13.9 Legal configuration page

The "Legal" configuration page shows all open-source software packages delivered with the running image, as well as the corresponding versions. It also shows the licenses for the delivered software packages as applicable.



13.10 Logs configuration page

On the "Logs" configuration page, you can download various log files generated on the device. To download the log file, double-click on the "Download" button.




Figure 111: Stored log files

14 OPC UA

OPC Unified Architecture, or OPC UA for short, is a standardized communication protocol for exchanging data between machines that makes it possible to use all devices universally.

CODESYS V3.5.9 and higher supports OPC UA.

The OPC UA server is integrated into the PLC. When the PLC starts, the OPC UA server will be started automatically as well.

OPC UA's scope of functionality matches OPC DA's scope of functionality. The URL for the OPC UA server needs to be entered into the OPC UA client:

„opc.tcp://<IP-Address>:4840“

Just like with OPC DA, the symbol list needs to be set up in X-SOFT-CODESYS 3.

To run the OPC UA server, additional information needs to be loaded onto the PLC. The symbol configuration will be generated during the download for this purpose.

- Basic types of derived function blocks
- Contents of attributes assigned with compiler pragma directives
- Tag type (INPUT / OUTPUT / IN_OUT)

To generate the symbol configuration, follow the steps below:

- ▶ Select the application and open the context menu
- ▶ Click on "Add object" and "Symbol configuration."
- ▶ Please specify a file name.
- ▶ Enable the "Support OPC UA functionalities" option.
- ▶ Confirm with OK.

The symbol configuration editor will appear.

You can use this editor to define all the tags that should be transferred.

The symbol configuration will be updated with the next download or online change.

15 Libraries, function blocks and functions

The libraries contain IEC function blocks and functions that you can use, for example, for the following tasks:

- Data exchange through the CAN bus
- Controlling the real-time clock
- Determining bus load of the CAN bus
- Triggering interrupts
- Sending/receiving data through the interfaces



Codesys helps users with various functions and function blocks that are managed in libraries. There are available libraries for assistance with the following, for example:

- Field bus communication (z.B. CAN),
- Real-time clock functions
- Communication through serial interfaces
- File handling functions

The following libraries are available:

Library	Description
EA_Network	This library provides Ethernet interface configuration functions for all Eaton PLCs with Ethernet interfaces. Contains POU's to configure a local Ethernet interface and contains POU's to create and work with additional IP-Addresses.
IODrvEtherCAT	EtherCAT Stack container library
EA_CANopen	Library for CANopen
IODrvModbus	Library for Modbus RTU
IODrvModbusTCP	Library for Modbus TCP
IODrvEthernet	Library for Modbus TCP
EA_CAN types	(when using Eaton CAN devices)
EA_CAN library	Function blocks for CAN
EA_XC303Events	Library for interrupt processing
EA_XN322_SI_RS	This library provides serial interface configuration functions for all Eaton PLCs with an RS-232 and an RS-485 interface.



Examples of libraries available to users:

- EA_CANopen ,
- IODrvModbus,
- SysCom,
- SysFileAsync...

15.1 Using libraries

When creating a standard project, libraries with frequently used functions will be automatically added to the project.

This includes, for example, the Standard.lib library with known function blocks such as: counter, timer, trigger function blocks, etc.

Additional libraries that are added automatically include the IoStandard-Lib and 3SLicense-Lib libraries.

When you open a project, the following libraries will be copied to the library manager.

- 3SLicense (system library)
- Standard.lib
- IoStandard
- BreakPointLogging

If the application requires additional libraries, you will need to install them manually in the library manager.

When the project is saved, these libraries will be assigned to the project and will be available the next time you open the project.

15.2 Installing additional system libraries

If necessary, you can install additional libraries manually.

The following steps are required:




Figure 112: Libraries, installing manually

- 1. Make sure that the library you want to install is found on a folder on your PC.
- 2. In the configuration tree, double-click on "Library manager." Click on the "Add library" menu option.

15 Libraries, function blocks and functions

15.2 Installing additional system libraries





Figure 113: Adding a library to the library repository

►3. Click on the "Install..." button.

►4. In Explorer, select the library in the folder where it is stored.



►5. Confirm with click on <Open>.

The new window will show the libraries available, depending on the target system.

►6. Select "Add library."




Figure 114: Search for a library in the library repository

15 Libraries, function blocks and functions

15.2 Installing additional system libraries

- 7. To find the installed library faster, enter a search string into the search box (e.g., "XN300").
- 8. Select the library to install and click <OK>.

The library now appears in the Library Manager.




Figure 115: Search for a library in the library repository



In addition, users can create their own libraries in order to store frequently recurring tasks as functions or function blocks in them.

16 PLC shell commands

16.1 Using PLC shell commands

16 PLC shell commands

The PLC shell is a text-based PLC monitor. PLC shell commands for scanning particular information from the PLC are entered in an entry line and sent to the PLC as a string. The returned response string is displayed in a result window of the PLC shell. This functionality is used for diagnostics and debugging tasks.

16.1 Using PLC shell commands

To enter a PLC shell command, follow the steps below:

- ▶ Establish a connection to the device.
- ▶ In CODESYS, double-click on the "Device (XC303)" device in the configuration tree.
- ▶ Select the "PLC Shell" tab.
- ▶ Enter the PLC shell command into the input line below or click on the "..." button and select the PLC shell command you want by double-clicking on it.
- ▶ Add other settings to the command if necessary, e.g. baud rate with `setcomconfig`.
- ▶ Press the Return button.

The result will be displayed.




Figure 116: PLC Shell tab with results for the "?" browser command

16.2 List of PLC shell commands (updated)

The following PLC shell commands are available.

Table 14 PLC shell commands in alphabetical order

Attribute ID	Description
?	Prints a list of available commands.
applist	Print List of currently loaded applications.
caninfo	Display CAN Controller Informationen
canload <arg>	Display of the loading of the CAN fieldbus <arg> <none> show CAN-Bus load. <reset> reset CAN-Bus load statistics.
canshow ²⁾ <arg>	Shows CAN controller statistics <1>; <2>; <none> for both controllers
canshowReset ²⁾ <arg>	Resets CAN controller statistics <1>; <2>; <none> for both controllers
cert-createsr ²⁾ [<number in search result with "cert-getapplist">]	Generates CSR files for all applications.
cert-export ²⁾ <trust level>	Exports the specified certificate [<number in search result with "cert-getcertlist">]
cert-getapplist	Shows all registered certificates being used (ID of component and use) Display all registered applied certificates (Component ID and application)
cert-getcertlist ²⁾ [<trust level>]	Lists all certificates with the specified trust level. If you do not specify a trust level, all certificates will be listed. Available trust levels • untrusted: Untrusted certificates • trusted: Trusted certificates • own: The PLC's certificates • quarantine: Certificates with a trust level (trusted / untrusted) that could not be clarified with a validation. This will result in incoming connections being rejected.
cert-genselfsigned [<number retrieved by "cert-getapplist"> <expdays=>]	Generates self-signed certificates; you can use expdays= to specify the certificate's validity period Standard value: 365 days Generate all self signed certificates
cert-gendhparams [len in bits]	Generates the parameters for the Diffie-Hellman key exchange Important: This operation can take several minutes! Generate parameters needed for Diffie-Hellman key exchange. Attention may run several minutes!
cert-import ²⁾ <trust level> <Dateiname.cer>	Imports the specified certificate.
cert-remove ²⁾ <trust level> <number in search result with "cert-getcertlist" or "all">	Removes the specified certificates.
cert-importcrl	Import all certificate revocation lists (CRLs).
channelinfo	Return communication channel information.
clearsram ²⁾ <segment number>	Initializes and flags the SRAM segment or the whole SRAM as free. The segment number can be retrieved with the following shell commands: "getsramlayout" or "all":
copyprojtosd	Copy the (boot) project onto a Multi Media Card (incl. directory structure/project directory)
copyprojtousb ¹⁾	Copy the (boot) project onto the USB drive (incl. directory structure/project directory)
factoryreset<arg>	Factory reset the device with the given serial number
getcmdlist	Used internally to display all available commands.

16 PLC shell commands

16.2 List of PLC shell commands (updated)

Attribute ID	Description
getdhcpstate ²⁾	Returns the status of the Ethernet interface(s) in regard to whether DHCP is enabled Example: eth0 : DHCP Enabled = NO
gethwinfo	Show hardware information
getdevicebrandname ²⁾	Returns the device name Example: Device Brand Name = XC-204-C11-003
gethostname ²⁾	Returns the host name Example: Host name = eaton-xc204
getinitplcsettings ²⁾	Returns the settings for the boot project Example: BP_OVERWRITE=1 BP_COPY_FROM_USB=1 BP_ALLOW_DISABLE_START=1 RTS-Update-Settings FW_ONLY_NEWER_VERSION=0 FW_FORCED_OVERWRITE=0 FW_INSTALL_FROM_USB=1 RTS-Startup-Settings RTS_START_DELAY_SEC=0 RTS_DISABLE_START=0 RTS_SUPERVISE=1
getipadress ²⁾ <adaptername>	Shows the IP address of the Ethernet interfaces (= Ethernet adapters)
getipconfig	Display Ethernet address
getipdns	Display current DNS address
getipgateway	Display Gateway address
getmacaddr	Display the physical (MAC) address of the Ethernet interface (<arg> = interface name)
getipnetmask	Display the IP subnet mask (<arg> = interface name)
getntpconfig ²⁾	Returns the settings of the NPT server daemon Example: Preferred Server 127.0.0.1 Min Poll 4 Max Poll 10 Standard Server 127.0.0.1 Min Poll 4 Max Poll 10 Ntp Service: stopped
getsramlayout ²⁾	Example: --- SRAM layout: Address=0xb6801000 Segment[0]: Tag=TAG_RETAIN_FREE, Size=32488, Guid=00000000-0000-0000-0000-000000000000
getserial ²⁾	Shows the device's serial number.
getswitchpos ²⁾	Shows the current switch position Example: Switch position: RUN
getprgprop	[not implemented, yet]
getprgstat [<app name> <app index>]	Get the status of one specific or all loaded applications.
getrtc	Display data and time [YY:MM:DD] [HH:MM:SS]
getsslversion ²⁾	Shows which OpenSSL version was used for the encryption Example: OpenSSL 1.1.1n 15 Mar 2022
gettimezone	Show actual timezone information (offset to UTC)
getversion	Show device versions list
licinfo	Show license info

16 PLC shell commands

16.2 List of PLC shell commands (updated)

Attribute ID	Description
listadapters ²⁾	Shows the available Ethernet interfaces (= Ethernet adapters).
logdelfilter [<CmpName>...]	Delete the log filter settings for specified components
loggetfilter [<CmpName>...]	Retrieve the current log filter settings for specified components
logsetfilter [<CmpName>...] <FilterValue>	Configure log filter settings using hexadecimal values
mem <address> <size>	Shows the free memory on disk_sys. Print Hexdump of specified memory region
ntpsetpolltime ²⁾ <arg>	NTP polltime <arg> = Can be used to set to preferred (0=normal, 1=preferred) minpoll maxpoll
ntpsetserver ²⁾ <arg>	Configures the NTP server address <arg> = Preferred server address (0= DNS name or 1= IP address)
ntpstart ²⁾	Starts or refreshes the NTP server daemon.
ntpstop ²⁾	Stops the NTP server daemon.
password-disable	Disable user management (not recommended, reboot required)
password-enable	Enable user management (reboot required)
password-reset	Remove actual user management (reboot required)
pid [<app name> <app index>]	Output Dump GUIDs of one specific application or all loaded applications.
pinf [<app name> <app index>]	Output project information of one specific application or all loaded applications.
plcload ¹⁾	Display system performance: CPU usage [%]
powerfailinfo	Display Powerfail info (→ Section "13.4.6 Powerfail", page 129)
reboot	Accept changes (registry save) and restart PLC
reflect ¹⁾	Mirror current command line for test purposes.
reload [<app name> <app index>]	Reloads the boot application
remprojfromsd	Deletes the backup project from the microSD card
remprojfromusb	Deletes the backup project from the USB drive
resetprg [<app name> <app index>]	Reset user program
resetprgcold [<app name> <app index>]	User program cold reset
restoresram ²⁾ <filename>	Restores the entire SRAM content from the file.
restoreretains ²⁾ [<applicationname>]	Restores retained data from file(s) [optionally only for the specified application].
rtc-get ²⁾	Returns the UTC universal time with the DateTime string.
rtc-set ²⁾	Sets the UTC universal time with the DateTime string (see ISO 8601)
rtsinfo	Returns information on the runtime system, e.g., the processor and the version of the runtime system.
saveretains ²⁾ [<applicationname>]	Saves retained data in file(s) [optionally only from the specified application].
savesram ²⁾ <filename>	Saves the entire SRAM content in a file
sddisable	Disable SD storage
sdenable	Enable SD storage
sdstate	Show SD state
sessinfo-getcnt ²⁾	Retrieves the number of data sets with session information.
sessinfo-list ²⁾	Lists all data sets with session information.
setdhcpstate ²⁾ <arg>	Set DHCP on/off (<arg> = AdapterName)
sethostname	Set new hostname
setinitplcsettings ²⁾ <arg> <val>	Assigns the <val> value to the <arg>s InitPlc setting.
setipaddr <arg>)	Set ip-address (<arg> = AdapterNo Adr1.Adr2.Adr3.Adr4)

16 PLC shell commands

16.2 List of PLC shell commands (updated)

Attribute ID	Description
setipconfig	Set IP address and subnet mask (<arg> = AdapterName Adr1.Adr2.Adr3.Adr4 Mask1.Mask2.Mask3.Mask4)
setipdns	Set DNS address [setipdns adr1.adr2.adr3.adr4]
setipgateway <arg>	Set ip default gateway (<arg> = AdapterNo Adr1.Adr2.Adr3.Adr4)
setipnetmask <arg>	Set ip-subnetmask (<arg> = AdapterNo Adr1.Adr2.Adr3.Adr4)
setrtc ¹⁾	Set date and time [YY:MM:DD] [HH:MM:SS]; e.g.setrtc 03:07:24 10:46:33
setsshstate ²⁾ <arg>	Enable encryption. SSH enabled: <arg>=1; SSH disabled: <arg>=0
settimezone <arg>	Setting new timezone information (<arg> = offset to UTC)
showsecuritysettings ²⁾	Shows the list of all security settings and the current configuration.
showtimezones ²⁾	Shows a list of selectable time zones.
sshstate ²⁾	Shows the configured state for the encryption Example: SSH = disabled
startprg [<app name> <app index>]	Start a specific or all user programs
stopprg [<app name> <app index>]	Stop a specific or all user programs
storagestate ²⁾	Shows the storage state. Example: USB Storage Devices mounted: 0 SD Storage Devices mounted: 0
taskprioget <taskname>	Shows the priority of the given task
taskprioget <taskname> <prio>	Sets the priority of the given task
taskinfo	Shows a list with information about all tasks
unmountall ²⁾	Terminates the connection to all active USB partitions.
usbautostartdisable ²⁾	Disables the USB interface; USB Autostart=disabled
usbautostartenable ²⁾	If a USB data storage device is plugged into the USB port, projects will be started there automatically; USB Autostart=enabled
usbdisable ²⁾	Disables the USB interface.
usbenable ²⁾	Enables the USB interface; a USB data storage device can be read.
usbfactoryresetenable	Enable USB factory reset
usbfactoryresetdisable	Disable USB factory reset
usbstate ²⁾	Shows the USB state Example: USB Storage=enabled USB Autostart=enabled
xngetversion	Shows version information; shows current XN driver version
xnmodules	shows currently configured and connected SDIAS modules
xnvariables	shows XN module variables
xnconfig	shows XN module configuration variables
xndebug ²⁾	Example: Debug level is set to 3

1) You can access help with extended information for this PLC shell command in CODESYS. Enter a question mark followed by a space before the command
e.g.: ? plcload in the command line of the PLC browser

2) Available for devices with runtime system version 3.5.17 or higher

16.3 CPU load shell commands

plcload

The `plcload` PLC shell command provides information on the current CPU-system load.

The "SchedGetProcessorLoad" function from the Codesys V3 CmpSchedule library provides the processor load.

A utilization of more than 95 percent can cause a failure of the serial and Ethernet communication and/or an impairment of the real-time response.

canload

The `canload` PLC shell command shows the CAN bus load.
`caninfo` shows the CAN buses' baud rates and states.

You can also get information regarding the CAN bus with the `CAN_GetBusLoad` and `CAN_GetBusState` functions in the `EA_CAN` library.

17 Interferences

This section provides troubleshooting information for your Modular PLCs XControl: XC-104-..., XC-204-..., XC-303-... in case it does not behave as expected.

Fault	Cause	Remedy
XControl will not boot up	There is no 24 VDC supply voltage	Check the input wiring. Switch on XControl.
PLC LED = red; solid	Indicates a runtime system error. Device hangs on startup; the runtime system does not start, a connection cannot be established through XSOF CODESYS; LED PRG = OFF, Cause 1: Invalid OS version loaded; the OS version on the device is too new/old to support the respective PLC runtime system. Cause 2: The device's last restart was triggered by a hardware watchdog timeout. In both cases, a LOG file will be written to /var/log/codesyscontrol.log	Cause 1: Install the appropriate operating system for the runtime system. Cause 2: Start the device manually; if the fault occurs again, check the application for errors that trigger the watchdog. If necessary, check whether the boot application version matches the runtime system version.
	The runtime system starts, PRG LED = ON or OFF, Cause: Retentive data could not be loaded. Additional information can be found in the LOG file, which can be read with XSOF CODESYS.	Log in to the device through XSOF CODESYS and read the log file
LED PRG = ROT	Indicates an application error. • The attempt to load the boot project failed. • An exception occurred in the application. Additional information can be found in the LOG file, which can be read with XSOF CODESYS.	Log in to the device through XSOF CODESYS and read the log file

18 Maintenance

18.1 Cleaning and maintenance

The devices are maintenance-free.
However, the following work may be necessary:

- Cleaning the device when soiled.



CAUTION POINTY, SHARP OBJECTS AND CORROSIVE LIQUIDS

Do not use any pointy or sharp objects (e.g., knives) for cleaning. Do not use aggressive or abrasive cleaning products or solvents.

Make sure that no liquids get into the device (short-circuit hazard) and that the device is not damaged in any way.

- ▶ Carefully clean the device with a clean, soft, damp cloth. If there are any spots that are proving difficult to get off, spray a little dishwashing liquid on the damp cloth first.

18.2 Repairs

For repairs, please contact your vendor or Eaton's Technical Support.



CAUTION DESTRUCTION

The device should only be opened by the manufacturer or by an authorized repair center. Operate the device until only with the enclosure fully closed and sealed.

Contact your local supplier or Eaton technical support for repairs.

Use the original packaging to ship the device.

18.3 Storage and transport



CAUTION UV LIGHT

Plastics will become brittle when exposed to UV light. This artificial aging will reduce the device's lifespan. Protect the device from direct sunlight and other sources of UV radiation.



CAUTION SHORT-CIRCUIT HAZARD

If the device is or has been exposed to environmental fluctuations (ambient temperature, air humidity), condensation may form on or inside it. As long as this condensation is present, there will be a short-circuit hazard.

Do not switch on the device when it has condensation in or on it.

If the device has condensation in or on it, or if the panel has been exposed to environmental fluctuations, let the panel settle into the existing ambient temperature before switching it on. Do not expose the device to direct thermal radiation from heating appliances.

The ambient conditions must be met when transporting and storing the device.

The ambient air temperature for storage / transportation must not exceed the maximum specified limit:



Before commissioning

If storing/transporting the device in cold weather conditions or in such a way that it will be exposed to extreme differences in temperature, make sure that no condensation forms on or inside the device.

If there is condensation in or on the device, do not switch on the device until it is completely dry.

- Use the original packaging to ship the device.

The device is sturdily built, but the components inside it are sensitive to excessively strong vibrations and/or mechanical shock.

Accordingly, make sure to protect the device from mechanical loads that exceed the scope of the unit's intended use.

The device should only be transported in its original packaging after being packed properly.

18.4 Disposal



CAUTION

Installation requires qualified electrician

IMPORTANT!

Dispose of recyclables as required by your local recycling regulations.

Devices no longer being used must be professionally disposed of as per local regulations or returned to the manufacturer or the relevant sales office.

19 Appendix

19.1 Dimensions and weights

19.1.1 XC-303-...

XC-303-...		
Dimensions (H × D × W)	mm	104.7× 72 × 50
	inch	4.12 × 2.83 × 1.97
Space units (SU) width		4 SU
Weight	kg	0.3
	lb	0.66
Mounting		DIN-rail IEC EN 60715, 35 mm
Mounting position		Vertical, upright




Figure 117: Dimensions XC-303-...

19.1.2 XC-104-..., XC-204-...

		XC-104-..., XC-204-...
Dimensions (H × D × W)	mm	104.7 × 72 × 23
	inch	4.12 × 2.83 × 0.91
Space units (SU) width		2 SU
Weight	kg	0.11
	lb	0.24
Mounting		DIN-rail IEC EN 60715, 35 mm
Mounting position		Vertical, upright




Figure 118: Dimensions XC-104-..., XC-204-...

19 Appendix

19.2 Approvals and national approvals

19.2 Approvals and national approvals

Modular PLCs XControl: XC-104-..., XC-204-..., XC-303-... and XN300 system devices are approved for use in several countries and regions.

Approvals and declarations	
cUL	cULus (pending; expected file No.: E205091)
CE	The devices in the XControl series of products comply with all applicable European Union (EU) Directives and feature the CE marking.

19.3 Technical specifications

19.3.1 General ambient conditions

	XC-104-...	XC-204-...	XC-303-...
Ambient climatic conditions			
Standards	IEC/EN/DIN EN 61131-2	IEC/EN/DIN EN 61131-2	IEC/EN/DIN EN 61131-2
Ambient temperature	-20...+60°C		-20...+55°C
Storage temperature	-25...+70°C		-40...+80°C
Mounting position	horizontal and vertical, relative to the DIN-rail Derating must be taken into account for vertical mounting		horizontal, relative to the DIN-rail
Relative humidity, non-condensing (IEC/EN 60068-2-30)	5...95%		
Air pressure (in operation)	max. 2000m	max. 2000m	max. 2000m
Ambient mechanical conditions			
Protection Style	IEC: IP20		
Vibration resistance			
constant amplitude (5 - 8.4 Hz)	±3.5 mm	±3.5 mm	±3.5 mm
Constant acceleration (8.4 - 150 Hz) g	±1.0	±1.0	±1.0
Shock resistance half sinewave, 15 g/11 ms	18 impact resistances	18 impact resistances	9 impact resistances
Drop / drop height (IEC EN 60068-2-31)	50 mm	50 mm	50 mm
Free fall, packaged (EN60068-2-32)	0.3m	0.3m	0.3m
Overvoltage category	II	II	II
Pollution degree	2	2	2
Insulation resistance (UL61010-2)	–	–	500 V _{eff}
Connection terminals	Plug-in terminal block		
Terminal capacities			
Spring-cage terminals			
solid	0.2 - 1.5mm ²		
Flexible with uninsulated ferrule	0.25 - 1.5mm ²		
Flexible with insulated ferrule	0.25 - 0.75mm ²		
Collar	d≤ 2.8mm		
AWG	24-16		
Strip length	10mm		
PLC			
Microprocessor PLC	NXP CORTEX A7 Single with 800 MHz + CORTEX M4 with 200 MHz	NXP CORTEX A7 Dual with 1 GHz + CORTEX M4 with 200 MHz	Freescal CORTEX A7 Dual core with 960 MHz
Memory			
Program memory	eMMC-FLASH: 2 GB		QSPI-FLASH: 128 MB
Cache memory	DDR3L-RAM: 256 MB	DDR-RAM: 512 MB	DDR-RAM: 512 MB

19 Appendix

19.3 Technical specifications

	XC-104-...	XC-204-...	XC-303-...
Data memory	NVRAM, depending on the PLC version: 4 to 32 kBytes		NV-RAM: 128 kByte
Retain/Persistent data	4 kByte	32 kByte	96 kByte
Operating System	Embedded Linux with RT patch	Embedded Linux with RT patch	Embedded Linux with RT patch
Watchdog	Yes	Yes	Yes
RTC (Real Time Clock)	Yes	Yes	Yes
External storage devices			
Mikro Secure Digital Card	–	optional	Yes
USB Drive	Yes	Yes	yes, optional
PLC status indication	LED, two-colored, green, red	LED, two-colored, green, red	LED, single-colored, green LED, single-colored, red
System bus			
Maximum number of bus modules	6	16	32
I/O image table refresh rate	< 1ms	< 1ms	< 1ms
Ethernet interfaces			
Terminal type	RJ45	RJ45	RJ45
Baud rate			
eth0, eth1	10/100MBit/s	10/100MBit/s	10/100MBit/s
eth2	–	–	10/100/1.000MBit/s
Galvanic separation	eth0 closed	eth0...1 closed	eth0...2 closed
From each other	–	Yes	Yes
System bus	Yes	Yes	Yes
U _L supply voltage I/Q1...I/Q4	–	I/Q1...I/Q2, yes	I/Q1...I/Q4, yes
RS485	–	Yes	Yes
CAN1	–	Yes	Yes
CAN2	–	–	Yes
Local inputs	–	Yes	Yes
Local outputs	–	Yes	Yes
USB interface			
Type of interface	USB 2.0 Host Type A, downstream port		
Power supply for connected devices:			
Rated operating voltage	5 V DC (-5% +10%)	5 V DC (-5% +10%)	5 V DC (-5% +10%)
max. current	500 mA	500 mA	100 mA
Galvanic separation from			
System bus	no	no	no
POW	no	no	no
U _L supply voltage I/Q1...I/Q4	–	no	Yes
RS485	–	no	Yes
CAN1	–	no	Yes

	XC-104-...	XC-204-...	XC-303-...
CAN2	–	–	no
Local inputs	–	no	Yes
Local outputs	–	no	Yes

Electromagnetic compatibility		XC-104-...	XC-204-...	XC-303-...
immunity				
ESD	Contact discharge	6 kV, criteria B	6 kV, criteria B	4 kV
XC-303-...: (IEC/EN 61000-4-2)	Air discharge	8 kV, criteria B	8 kV, criteria B	8 kV
XC-204-...: (EN 61131-2:2008)				
XC-104-...: (EN 61131-2:2008)				
Electromagnetic fields (RFI) criteria A				
0.8 – 1.0 GHz		0.08 – 1.0 GHz: 10 V/m	0.08 – 1.0 GHz: 10 V/m	0.8 – 1.0 GHz: 10 V/m
1.4 – 2.0 GHz		1.4 – 6.0 GHz: 3 V/m	1.4 – 6.0 GHz: 3 V/m	1.4 – 2.0 GHz: 3 V/m
2.0 – 2.7 GHz				2.0 – 2.7 GHz: 1 V/m
Burst (EN 61131-2, Level 3) criteria B	POW	2 kV	2 kV	2 kV
	eth 0...2 ¹⁾	1 kV	1 kV	1 kV
	Local inputs/outputs ¹⁾	1 kV	1 kV	1 kV
Surge, (	POW, symmetrical, asymmetrical	0.5kV; XC-104-.../XC-204-...: 61000-6-2, criteria B	0.5kV; XC-104-.../XC-204-...: 61000-6-2, criteria B	0.5kV; XC303-...: (EN61131-2, Level 1), criteria B
	eth 0 to 2/CAN/RS-485, balanced ¹⁾	1kV	1kV	1kV
	Local inputs/outputs, balanced	–	–	1kV
Cable dependant interference, induced by high frequency fields EN61131-2		10 V	10 V	10 V

1) If provided

19 Appendix

19.3 Technical specifications

19.3.2 Power supply on devices and on system bus

POW power supply of the CPU	XC-104-...,	XC-204-...	XC-303-...
Power loss ride through			
Duration of dip	10 ms	10 ms	20 ms
Rated operating voltage			
Rated value U_e	24 V DC	24 V DC	24 V DC
admissible range	19.2...30V DC	19.2...30V DC	18...30V DC
Residual ripple	$\leq 5\%$	$\leq 5\%$	$\leq 5\%$
Protection against polarity reversal	Yes	Yes	Yes
Input current I_e	max. 1 A	max. 2.4 A	max. 3.3 A
Maximum heat dissipation (without local I/O)	8W	8W	8W
Galvanic separation from POW to			
System bus)	no	no	no
U_L supply voltage I/Q1...I/Q4	no	no	Yes
RS485 ¹⁾	no	no	Yes
CAN1 ¹⁾	—	no	Yes
CAN2 ¹⁾	—	—	no
Local inputs	—	no	Yes
Local outputs	—	no	Yes
eth0...eth2	Yes	Yes	Yes
Status indication POW	LED, single-colored, green	LED, single-colored, green	LED, single-colored, green
UBP_24 output voltage for the XN300 slice modules			
Output rated voltage	24 V DC	24 V DC	24 V DC
Output current	0.3 A	0.8 A	1.6 A
Short-circuit rating	no	no	Yes
Galvanic separation from POW	no	no	no
UBP_5 output voltage for the XN300 slice modules			
Output rated voltage	5 V DC	5 V DC	5 V DC
Output current	0.3 A	0.8A	1.6A
Short-circuit rating	Yes	Yes	Yes
Galvanic separation from POW	no	no	no

1) If provided

19.3.3 Power supply for local inputs/outputs on XC-204-..., XC-303-...

On XC-204-... devices, the local inputs and outputs are powered through the system power supply. On XC-303-... devices, the local inputs and outputs are powered through terminal X2/UL; this terminal is powered externally.

Power supply of local inputs/outputs	XC-204-...	XC-303-...
Rated operating voltage U_L	System supply	X2/ U_L
Rated value U_e	24 V DC	24 V DC
admissible range	19.2 - 30V DC	18 - 30V DC
Residual ripple	$\leq 5\%$	$\leq 5\%$
Protection against polarity reversal	—	Yes
Input current I_L	max. 1 A	max. 2 A
Galvanic separation U_L to		
System bus	no	Yes
POW	no	Yes
RS485	no	Yes
CAN1	no	Yes
CAN2	—	Yes
Local inputs	no	no
Local outputs	no	no
eth0...eth2	Yes	Yes
Flag Display	none	LED, single-colored, green

19 Appendix

19.3 Technical specifications

19.3.4 Local inputs XC-204-..., XC-303-...

Each of the transistor inputs can alternatively also be configured as an output.

Digital inputs (EN 61131-2, type 1)	XC-204-...	XC-303-...
Inputs (quantity)	2	4
Input rated voltage	24V DC, observe polarity	24V DC, observe polarity
Voltage levels	19,2...30V DC	18...30V DC
Input current per channel at rated operating voltage at 24 V	normally 2.5 mA	normally 2.5 mA
Switching levels as per EN 61131-2		
Limit values type "1"	low < 5, high > 15 V DC	low < 5, high > 15 V DC
Input delay		
Off → On	< 0.2ms	< 0.2ms
On → Off	< 0.2ms	< 0.2ms
of which the following can be used as interrupt inputs:	I1...I2	I1...I4
Galvanic separation from		
From each other	No	No
Local outputs	No	No
System bus	No	Yes
POW	No	Yes
RS485	No	Yes
CAN1	No	Yes
CAN2	—	Yes
eth0...eth2	Yes	Yes
Flag Display	LED, single-colored, green	LED, single-colored, green
Cable length (unscreened)	< 30m	< 30m

19.3.5 Local outputs XC-204-..., XC-303-...

Each of the transistor outputs can alternatively also be configured as an input. If the PLC is RESET, the outputs will be switched off.

Digital outputs	XC-204-...	XC-303-...
Channels (quantity)	2	4
Short-circuit proof	Yes	Yes
Isolation voltage	—	500 V AC
Heat dissipation per channel		
Q1 to Q4	<0.1W	<0.1W
Load circuits		
Q1 to Q4	0.5 A	0.5 A
Output delay		
Off → On	typ. 0.1 ms	typ 0.1 ms
On → Off	typ. 0.1 ms ¹⁾	typ 0.1 ms ¹⁾
Duty factor	100%	100%
Simultaneity factor g	1	1
Galvanic separation from		
From each other	No	No
From the inputs	No	No
System bus	No	Yes
POW	No	Yes
RS485	No	Yes
CAN1	No	Yes
CAN2	—	Yes
eth0...eth2	Yes	Yes
Flag Display	LED, two-colored, green, red	LED, single-colored, green
Cable length (unscreened)	< 30m	< 30m

1) without capacitive load

19.3.6 CAN interfaces XC-204-..., XC-303-...

The following devices feature CAN interfaces:

a CAN interface

- XC-204-C11-003
- XC-204-C21-001
- XC-303-C11-001
- XC-303-C21-001

two CAN interfaces

- XC-303-C32-002

CAN(open)	XC-204-...	XC-303-...
Baud rate CAN1, CAN2	50/100/125/250/500/1000kBits/s	50/100/125/250/500/1000kBits/s
Device profile	to DS301V4	to DS301V4
29 Bit Identifier	Yes	Yes
PDO type	asyn., cyc., acyc.	asyn., cyc., acyc.
Connection	3 pole plug connector, Push-In	3 pole plug connector, Push-In
Bus termination resistors for first and last CAN stations	120 Ω, switchable for CAN1 with dip switch TC	120 Ω, switchable for CAN1 with dip switch TC1 CAN2 with dip switch TC2
CANopen stations (number)	maximum 126/8	maximum 126/8
Galvanic separation from CAN1 to		
Supply voltage U _{POW}	No	No
System bus	No	No
U _L supply voltage I/Q1...I/Q4	No	No
RS485	No	No
CAN2	—	Yes
Local inputs	No	No
Local outputs	No	No
eth0...eth2	Yes	Yes
Galvanic separation from CAN2 to		
Supply voltage U _{POW}	No	No
System bus	No	No
U _L supply voltage I/Q1...I/Q4	No	No
RS485	—	Yes
CAN1	—	Yes
Local inputs	No	No
Local outputs	No	No

19 Appendix

19.3 Technical specifications

eth0...eth2	—	Yes
Flag Display	LED, two-colored, green, red	LED, two-colored, green, red
Connection cable	A shielded cable must be used for the interface. The shielding must be terminated on both sides externally.	A shielded cable must be used for the interface. The shielding must be terminated on both sides externally.

19 Appendix

19.3 Technical specifications

19.3.7 RS485-Interface

The following devices feature an RS-485 interface:

- XC-204-C11-003
- XC-204-C20-002
- XC-303-C21-001
- XC-303-C32-002

RS485-Interface	XC-204-...	XC-303-...
Terminal type	3 pole plug connector, Push-In	3 pole plug connector, Push-In
Transfer rate as		
Modbus RTU	1200, 2400, 4800, 9600, 19200, 38400, 57600, 115200 Bit/s	1200, 2400, 4800, 9600, 19200, 38400, 57600, 115200 Bit/s
serial interface	4800, 9600, 19200, 38400, 57600, 115200 Bit/s EVEN, ODD, and NONE parity is supported, as are 1 or 2 stop bits; in conformity with CODESYS serial adapter	4800, 9600, 19200, 38400, 57600, 115200 Bit/s EVEN, ODD, and NONE parity is supported, as are 1 or 2 stop bits; in conformity with CODESYS serial adapter
Bus termination resistors for first and last stations	120 Ω switchable; To activate, both the TRSa and TRSb DIP switches must be switched to the ON position	220 Ω switchable; To activate, both the TRSa and TRSb DIP switches must be switched to the ON position
Galvanic separation RS485 to		
Supply voltage U_{Pow}	No	No
System bus	No	No
U_L supply voltage I/Q1...I/Q4	No	No
CAN1 ¹⁾	No	No
CAN2 ¹⁾	—	Yes
local inputs ¹⁾	No	No
local outputs ¹⁾	No	No
eth0...eth2	Yes	Yes
Flag Display	LED, multi-color, green, red	LED, multi-color, green, red
Connection cable	A shielded cable must be used for the interface. The shielding must be terminated on both sides externally.	A shielded cable must be used for the interface. The shielding must be terminated on both sides externally.

1) If provided

19.4 Glossary

POU	Programming organization unit A type POU object is a programming organization unit in a CODESYS project. In POU's schreiben Sie Quellcode für Ihr Steuerungsprogramm. You write source code in POU's for your control program.
Boot project	Project loaded from the CPU's non-volatile memory.
/home	Topmost file directory in the XControl PLC that a user with the "XC-303_user" status can access
Input delay	An input delay is the delay between a pulse edge from input terminals I1 to I4 and the CPU's GPIO.
OS	Operating system
MicroSD	Micro Secure Digital Card
Task	Process, task for operating system
Forcing	Setting by force, initializing changeable operands/tags with a fixed value
RTS	RunTimeSystem
PRG	Program
PLC	Programmable logic controller
RC	RemoteControl
IL Reference Listing	IL

Index

A	
Address overlaps	82
Addressing	
Inputs/outputs and markers	82
Automatically generating a boot application during a download	63
B	
Baud Rate	103
Boot application	
On microSD	64
On USB	64
Boot project	
Deleting, on SD/MMC	64
Deleting, on USB stick	65
Breakpoint	58
C	
Cable protection	42
Cable routing	41
Cache memory	19
CAN	
Baud rate	27
Cable length	27
Interface, Assignment	26
Telegrams, receive/send from user program ..	28
CAN connection cable	27
Change PC's IP address	52
Commissioning	58
Connection	
Inputs/outputs	46, 47
Interrupt actuators	50
Connection set-up	90, 95
Connection terminals	37
CPU	
Display of the operating states	57
Load	146
Cyclic task	72
D	
Debugging	58, 141
Default IP addresses	23
Default parameters	95
Delete password	69, 128
Diagnostics	141
DIP switch	55
Discovery Service	51
Documentation, online	7
Download	8
Drives	19
E	
EA_XC303Events	91
EDS file	
Installing	109, 114
update	109
Electromagnetic interference	30
Electronic data sheet	109
Ethernet	
Default IP addresses	23
Ethernet interface	22
Event controlled task	73
F	
Factory reset	128
Factory reset via USB	127
Flag Display	58
Flash	19
Forcing	58
Function blocks	138
Functions	138
DisableInterrupt	91
EnableInterrupt	92
Read...Direct	81
Write...Direct	81
G	
Gateway XN-312-GW-EC	
Manual	111
H	
Help for browser commands	145
I	
Inputs	
Addressing	82
Signal state	18
Wiring example	46, 47
Interface	
CANOpen, Configuration	26
ETH232, configuration	23
USB, configuration	22, 23
Interfaces	11

Interference factors	30	Potential relationships	38
Interrupt	91	Power down logic	17
Actuator connection	50	Power supply	
Inputs	50	for processor unit and local inputs/outputs	17
Interrupt, CAN Bus	28	Power off/interruption (behavior)	57
L		Priority (task)	71
Layout of units	31	Program	
LED		Call (task)	72
PLC	57	Processing	71
PRG	57	Start	56
LED display	18	Stop	56
Library		Programming	11
Installation	138	Programming interface	23
Lighting protection	42	Programming software	
Limit values, for memory usage	81	Version	11
Loading the program	63	R	
M		Reactors	41
Manual	7	Real Time Clock (RTC)	18
Markers Addressing	82	Refreshing outputs during the simulation	56
Memory		Removing the XN300 slice modules	35
Systems	19	Reset	59
Usage, limit values	81	Reset to factory default values	128
Memory system		RS485 cable	25
disk_sd	19	S	
disk_usb	19	Screen earth kit	41
MMC memory card	19	Segments	81
Monitoring time, Task	78	Signal state inputs/outputs	18
Mounting instruction	7	Simulation, refreshing outputs	56
Mounting position	31	Single cycle mode	58
Mounting XC300	31	Single-step mode	58
Multi Media Card	18	Startup behavior	53
Multitasking	71, 75	Status display in the front	60
O		Strip length	37
Online documentation	7	Suppressor circuit for interference sources	41
Operating states CPU (LED display)	57	Switching threshold	17
Operating system		System	
Updating	65	Events	71
Outputs		Libraries	138
Addressing	82	Load, CPU	146
Signal state	18	Memory	19
Wiring example	46, 47	-parameter predefined	95
P		Times	71
PC		System block	31
Change IP address	52	System events	74
PLC Shell commands	141		
plcload	146		

T

Task	
Condition	71
Configuration	71
Cyclic	72
Monitoring	78
Technical specifications	154
Test and startup	58
Type (task condition)	71

U

USB Drive	21
USB interface activation	51, 127, 145
USB interface, assignment	22, 23
USB-Stick	18

V

ventilation	30
Voltage dip	17

W

Watchdog	78
Active	78
Configuration	78
Example	79
Monitoring tasks	78
Web Config Tool	
Logging off	124
Web configuration server	122
Factory reset	85, 128
Navigation	124
Network interfaces	129
Power management	128
Remote use	122
Setting up a password	122
Start page	124
System configuration	125
Web visualization	120
Wiring	41
Wiring example	
Inputs/outputs	46, 47

X

XControl	
Device models	13
XControl web configuration server start page	124
XML file	
Update	114
XN300	8

Eaton is an intelligent power management company dedicated to protecting the environment and improving the quality of life for people everywhere. We make products for the data center, utility, industrial, commercial, machine building, residential, aerospace and mobility markets. We are guided by our commitment to do business right, to operate sustainably and to help our customers manage power – today and well into the future.

By capitalizing on the global growth trends of electrification and digitalization, we're helping to solve the world's most urgent power management challenges, and building a more sustainable society for people today and generations to come.

For more information, visit Eaton.com.