



## HencoLogic

Wired, connecting thermostats and control bars





## **Required items**

#### Control bars:

• Heating only, stand-alone only



HencoLogic **CU-6ZONEB-H** 



Optional HencoLogic **CU-6ZONEB-CON** 

· Heating & cooling



HencoLogic **CU-6ZONEB-HC** 



Optional HencoLogic **CU-6ZONEB-CON** 

#### Thermostat:



HencoLogic CU-DTHERMB-HC





HencoLogic **CU-ATHERMB-HC** 

### **Connecting thermostats**

For each thermostat, a 3-wire connection for heating or a 4-wire connection for heating & cooling is provided towards the control bar. There is a transformer in the control bar so all thermostats are always 24V. The thermal motors are always 230V.

The functions of the 4 wires are:

Fase	power supply thermostat
OUT	communication between thermostat & control bar
Nul	power supply thermostat
H/C	switchover wire for heating/cooling


On the left side of the control bar is an overview of the various connections. The same connections can be found on the back of the thermostat. Please note that the order of connections is different between the thermostat with display (CU-DTHERMB-HC) and the thermostat without display (CU-ATHERMB-HC).





### **Connecting control bars**

The control bars are interconnected via the contacts below. 2 wires for heating (Pump & OV) and 3 wires for heating & cooling. (Pump, OV & H/C)



When the control bars are interconnected, it is important to designate who is the master and who is the slave. This is done with DIP switch #1. Leave the master control bar, which is connected to the heat source, on OFF. The slaves are set to ON (sub controller).




DIP switch number	Function	Value (default: OFF)	Configuration
1	Controller function	OFF	Controller
1		ON	Sub Controller

If the pump contact is to be passed from the slaves to the master then set DIP switch #2 at the MASTER to ON (global pump)



DIP switch number	Function	Value (default: OFF)	Configuration
2	Pump (available only on	OFF	Local pump
	main controller, the sub is always local)	ON	Global pump

For control to the heat source there are 2 outgoing contacts available, 1 contact is 230V & 1 contact is potential free (de-energized). Both contacts are NO (Normally Open) contacts that are sent when there is a demand in 1 of the zones.



For switching between heating & cooling see manual "Cooling, wired"

Henco Industries NV Toekomstlaan 27, 2200 Herentals Tel. +32 14 28 56 60 www.henco.he



# We care to connect

# MyHenco

The best of Henco always at hand.



Register now for free.



