

Operating manual

WZSV 63K1/3M
WZSV 63H1/3M

Brine/Water heat pump
Brine heat station



UK

83026400eUK

Translation of the original operating manual



Table of contents

Table of contents		10.5 Yearly maintenance.....	23
1	About this operating manual	11 Faults.....	23
1.1	Validity.....	11.1 Unlock the safety temperature limiter	23
1.2	Reference documents	11.2 Manually unblock the circulating pumps	23
1.3	Symbols and identification markings	12 Dismantling and Disposal	24
1.4	Contact.....	12.1 Dismantling	24
2	Safety	12.2 Disposal and recycling	24
2.1	Intended use	12.3 Removal of the buffer battery.....	24
2.2	Personnel qualifications	Technical data / Scope of supply.....	25
2.3	Personal protective equipment	Performance curves.....	26
2.4	Residual risks.....	Dimensional drawings.....	27
2.5	Disposal	Control unit.....	28
2.6	Avoid damage to property.....	Wall-mounted bracket	28
3	Description.....	Installation plans.....	29
3.1	Layout	Installation plan 1	29
3.2	Accessories.....	Installation plan 2	30
3.3	Function	Installation plan 3	31
4	Operation and care.....	Hydraulic integration.....	32
4.1	Energy and environmentally aware operation	Unit variant Heating.....	32
4.2	Maintenance.....	with separate buffer tank	33
5	Delivery, storage, transport and installation	Unit variant Cooling (K)	34
5.1	Scope of supply	Keys hydraulic integration	35
5.2	Storage.....	Terminal diagrams	36
5.3	Unpacking and transport.....	Circuit diagrams.....	39
5.4	Installation		
6	Installation and connection.....		
6.1	Dismantle the module box		
6.2	Install the module box		
6.3	Install the hydraulic connections		
6.4	Connect the electrical cables.....		
6.5	Installing the control panel		
7	Flushing, filling and venting		
7.1	Remove the front panel of the module box.....		
7.2	Flush, fill and vent heat source		
7.3	Flush and fill the heating and domestic hot water charging circuit.....		
7.4	Flush, fill and vent the domestic hot water tank		
8	Insulate hydraulic connections		
9	Commissioning		
10	Maintenance		
10.1	Basic principles		
10.2	Maintenance after commissioning		
10.3	Maintenance as required		
10.4	Cleaning and flushing the plate heat exchanger		



1 About this operating manual

This operating manual is part of the unit.

- ▶ Before working on or with the unit read the operating manual carefully and follow it for all activities at all times, especially the warnings and safety instructions.
- ▶ Keep the operating manual to hand at the unit and hand over to the new owner if the unit changes hands.
- ▶ If you have any questions or anything is unclear, ask the local partner of the manufacturer or the factory's customer service.
- ▶ Note and follow all reference documents.

1.1 Validity

This operating manual refers solely to the unit identified by the nameplate and unit sticker (→ "Rating plate", page 7).

1.2 Reference documents

The following documents contain additional information to this operating manual:

- Planning & design manual, hydraulic integration
- Operating manual of the heating and heat pump controller
- Brief description of the heat pump controller
- Operating manual of the expansion board (accessories)
- Repair and service instructions for heat pumps with flammable (primary) refrigerant

1.3 Symbols and identification markings

Identification of warnings

	Safety-relevant information. Warning of physical injuries.
	Safety-relevant information. Warning of physical injuries. Flammable materials / flammable (primary) refrigerant
	Safety-relevant information. Warning of physical injuries. Flammable materials / flammable (primary) refrigerant

Symbol	Meaning
	Safety-relevant information. Warning of physical injuries. Danger of fatal injury due to electric current.
DANGER	Indicates imminent danger resulting in severe injuries or death.
WARNING	Indicates a potentially dangerous situation, which can result in severe injuries or death.
CAUTION	Indicates a potentially dangerous situation, which can result in moderate or minor injuries.
IMPORTANT	Indicates a potentially dangerous situation, which can result in property damage.

Symbols in the document

Symbol	Meaning
	Information for qualified personnel
	Information for the owner/operator
✓	Requirement for action
▶	Procedural instructions: Single-step instruction for action
1., 2., 3., ...	Procedural instructions: Numbered step within a multi-step instruction for action. Adhere to the given sequence.
	Additional information, e.g. a tip on making work easier, information on standards
→	Reference to further information elsewhere in the operating manual or in another document
•	Listing
	Secure connections against twisting



1.4 Contact

Addresses for purchasing accessories, for service cases or for answers to questions about the unit and this operating manual can be found on the internet at any time and is kept up-to-date:

- www.alpha-innotec.com

2 Safety

Only use the unit if it is in proper technical condition and only use it as intended, safely and aware of the hazards, and follow this operating manual.

2.1 Intended use

The unit is designed for household use and is solely intended for the following functions:

- Heating
- Domestic water heating
- Cooling (optional, with accessories or unit type ...K)
- ▶ Proper use includes complying with the operating conditions (→ "Technical data / Scope of supply", from page 25) and the operating manual and noting and following the reference documents.
- ▶ When using the local regulations note: laws, standards, guidelines, directives.

All other uses of the unit are not as intended.

2.2 Personnel qualifications

The operating manuals supplied with the product are intended for all users of the product.

The operation of the product via the heating and heat pump control and work on the product which is intended for end customers / operators is suitable for all age groups of persons who are able to understand the activities and the resulting consequences and can carry out the necessary activities.

Children and adults who are not experienced in handling the product and do not understand the necessary activities and the resulting consequences must be instructed and, if necessary, supervised by persons experienced in handling the product and who are responsible for safety.

Children must not play with the product.

The product may only be opened by qualified personnel.

All procedural instructions in this operating manual are intended exclusively for qualified and skilled personnel.

Only qualified, skilled personnel is able to carry out the work on the unit safely and correctly. Interference by unqualified personnel can cause life-threatening injuries and damage to property.

- ▶ Ensure that the personnel are familiar with the local regulations, especially those relating to working safely and in awareness of the hazard risks.
- ▶ Ensure that the personnel are qualified to handle refrigerant.
- Work on the refrigerating circuit may only be carried out by qualified personnel with appropriate qualifications for refrigeration system installation.
- Work on the electrics and electronics may only be carried out by electrical technicians.
- Any other work on the system may only be carried out by qualified personnel (heating installer, plumbing installer).

During the warranty and guarantee period, servicing and repair work may only be carried out by personnel authorised by the manufacturer.

2.3 Personal protective equipment

During transport and work on the unit, there is a risk of cuts due to the sharp edges of the unit.

- ▶ Wear cut-resistant protective gloves.

During transport and work on the unit, there is a risk of foot injuries.

- ▶ Wear safety shoes.

When working on liquid-conveying lines, there is a risk of injury to the eyes due to leakage of liquids.

- ▶ Wear safety goggles.

When handling antifreeze

- ▶ Wear chemical-resistant protective gloves.

During inadequate ventilation

- ▶ Wear respiratory protection.



2.4 Residual risks

Injuries caused by electric current

Components in the device are live with fatal voltage. Before working on the unit:

- ▶ Disconnect unit from power supply.
- ▶ Protect unit against being switched back on again.
- ▶ Residual voltage at the inverter. Wait for 90 seconds before opening the unit.

Existing earthing connections within housings or on mounting plates must not be altered. If this should nevertheless be necessary in the course of repair or assembly work:

- ▶ Restore earthing connections to their original condition after completion of the work.

Injuries caused by high temperatures

- ▶ Before working on the unit, let it cool down.

Safety instructions and warning symbols

- ▶ Observe the safety instructions and warning symbols on the packaging and on and in the unit.

Injury due to flammable liquids and potentially explosive atmospheres

Constituents of antifreeze mixtures, e.g. ethanol, methanol, are highly flammable and form an explosive atmosphere:

- ▶ Mix antifreeze in well-ventilated rooms.
- ▶ Note the hazardous substance markings and comply with the relevant safety regulations.

Injuries and environmental damage due to refrigerant



WARNING

The unit contains flammable refrigerant (R290/ propane) Care must be taken to ensure that there are no ignition sources in the vicinity of the appliance. Only qualified professionals are responsible for safe handling and maintenance of the unit. Please observe specific safety precautions when handling flammable refrigerants.

If refrigerant leaks from the unit due to a leak, proceed as follows:

1. Switch off unit.
2. Ensure that all unauthorised persons leave the danger area immediately.
3. Remove possible ignition sources from the danger area and keep them away from the danger area.
4. Block access to the danger area for unauthorised persons.
5. Notify authorised after sales service.

If damage is visible on the outside of the unit, proceed as follows:

1. Switch off unit.
2. Notify authorised after sales service.

2.5 Disposal

Environmentally hazardous substances

Improper disposal of environmentally hazardous substances (e.g. refrigerant, compressor oil) damages the environment:

- ▶ Collect substances safely.
- ▶ Dispose of the substances in an environmentally-friendly manner according to the local regulations.

2.6 Avoid damage to property

Cooling

If the heating surfaces are used for heating and cooling, the control valves must be suitable for heating and cooling.

By cooling with low flow temperatures, condensate can be expected to form on the heat distribution system as the temperature falls below the dew point. If the heat distribution system is not designed for these operating conditions, it must be protected by appropriate safety devices, e.g. dew point monitor (purchasable accessory).

Decommissioning/draining the heating

If the system/heat pump is decommissioned or drained after already being filled, it must be ensured that the condenser and any heat exchangers have been drained completely for the event of freezing temperatures. Residual water in heat exchangers and condensers can result in damage to the components.

- ▶ Completely drain the system and the condenser, and open vent valves.
- ▶ Blow them clear with compressed air, if required.



Improper action

Requirements for minimum scale and corrosion damage in hot water heating systems:

- Proper planning, design and start-up
- Closed system with regard to corrosion
- Integration of adequately dimensioned pressure retention
- Use of deionised heating water (VE water) or with water corresponding to VDI 2035 only
- Regular servicing and maintenance

If a system is not planned, designed, started up and operated according to the given requirements, there is a risk that the following damage and faults will occur:

- Malfunctions and the failure of components, e.g. pumps, valves
 - Internal and external leaks, e.g. from heat exchangers
 - Cross-section reduction and blockages in components, e.g. heat exchanger, pipes, pumps
 - Material fatigue
 - Gas bubbles and gas cushion formation (cavitation)
 - Negative effect on heat transfer, e.g. formation of coatings, deposits, and associated noises, e.g. boiling noises, flow noises
- Note and follow the information in this operating manual for all work on and with the unit.

Unsuitable quality of the fill and make-up water in the heating circuit

The efficiency of the system and the life of the heat generator and the heating components depend decisively on the quality of the heating water.

If the system is filled with untreated drinking water, calcium and magnesium precipitate as mineral scale. Limescale deposits form on the heat transfer surfaces of the heating. The efficiency drops and energy costs rise. In extreme cases the heat exchangers are damaged.

- Fill the system with deionised heating water (VE water) or with water corresponding to VDI 2035 only (low-salt operation of the system).



HINWEIS

No antifreeze products should be used!

Unsuitable quality of the water in the domestic hot water tank

- Ensure that the electrical conductivity of the domestic water is at least 100 µS/cm and that the drinking water is of drinking water quality.

Unsuitable quality of the water-antifreeze mixture in the heat source

- For operation of the heat source with water or a water-antifreeze mixture, ensure that the water used fulfils the quality specifications of the heating water side.

→ “7 Flushing, filling and venting“, from page 18



3 Description


3.1 Layout



NOTE

This section essentially names the components relevant for fulfilling the tasks described in this operating manual.

Housing with unit components



- 1 Domestic hot water tank
- 2 Heating circuit/hot water circulation pump
- 3 Volume flow sensor
- 4 Heating element

- 5 3-way changeover valve, heating circuit/
domestic hot water
- 6 Valve motor
- 7 Position of rating plate
- 8 Venter
- 9 Electrical switch cabinet
- 10 Domestic hot water tank sensor
- 11 Module box
- 12 Height-adjustable foot (4x)

Rating plate

Rating plates are attached to the following places on the unit:


- at the top of the heating station
- left-hand side, on the module box

The rating plate contains the following information at the top:

- Unit type, product number
- Serial number, unit index

The rating plate also contains an overview of the most important technical data.


Module box – variant without cooling



- 1 Compressor
- 2 Condenser
- 3 Vibration isolator (4x)
- 4 Lifting lug (4x)
- 5 Evaporator
- 6 Heat source circulation pump
- 7 Heating filling and drain tap
- 8 Heat source filling and drain tap



Module box – variant with cooling




- 1 Compressor
- 2 Condenser
- 3 Vibration isolator (4x)
- 4 Lifting lug (4x)
- 5 Evaporator
- 6 Heat source circulation pump
- 7 Heat source filling and drain tap
- 8 Heating filling and drain tap
- 9 Heat source filling and drain tap



NOTE


The hose connectors are not part of the scope of delivery with all KFE ball valves.

Control unit



- 1 Control panel
- 2 Push up flap upstream of USB connection (for qualified personnel for software updates and for data logging)
- 3 Wall-mounted bracket (only necessary for wall-mounted installation)

Underside of the control panel



- 1 Connection room control unit RBE RS 485 (accessory)
- 2 RJ45 connection cable to the network link
- 3 Connection to the controller board (not required)
- 4 Connection of Modbus cable to the Modbus distributor (network cable inside the unit)



3.2 Accessories

The following accessories are available for the unit through the manufacturer's local partner:

- Additional masking plate for the front cover panel, if the control is mounted on the wall
- Room thermostat for switching the cooling function (if included)
- Dew point monitor for protecting a system with cooling function at low flow temperatures
- Expansion board
- "Cooling package" for retrofitting of units with heating function only
- Heating circuit safety package
- Heat source circuit safety package
- Air / magnetic sludge separator

3.3 Function

Liquid refrigerant is evaporated (evaporator), the energy for this process is environmental heat and comes from the "ground" heat source (collector, borehole heat exchanger or groundwater via intermediate exchanger). The gaseous refrigerant is compressed (compressor), this causes the pressure to rise and therefore the temperature too. The gaseous refrigerant with high temperature is liquefied (condenser).

Here the high temperature is discharged to the heating water and is used in the heating circuit. The liquid refrigerant with high pressure and high temperature is expanded (expansion valve). The pressure and temperature drop and the process begins again.

Due to the integrated changeover valve and the integrated energy efficiency circulation pump the heated heating water can be used for charging the domestic hot water or for heating the building. The temperatures required and use are controlled by the heat pump controller. Reheating, drying out screed or increasing the domestic hot water temperature can be carried out using the integrated electric heating element, which is activated by the heat pump controller as and when necessary.

The integrated vibration isolators for the heating circuit and heat source prevent structure-borne sound and vibrations from being transferred onto the fixed pipes and therefore into the building.

Cooling

Cooling is integrated in type K units. Units without integrated Cooling can be retrofitted with the "Cooling package" accessories. The following options are possible for units with cooling function (→ operating manual of the heating and heat pump controller):

- Passive cooling (without compressor)
- Control of the cooling function via the heating and heat pump controller
- Automatic switching between heating and cooling mode

Network connection on the control

The control can be connected to a computer or network via a network cable. The heating and heat pump controller can then be controlled from the computer or from the network.

4 Operation and care



NOTE

The unit is operated via the control of the heating and heat pump controller (→ operating manual of the heating and heat pump controller).

4.1 Energy and environmentally aware operation

The generally accepted requirements for energy-aware and environmentally-aware operation of a heating system also apply to use of a brine/water heat pump. The most important measures include:

- No unnecessarily high flow temperature
- No unnecessarily high domestic hot water temperature (note and follow local regulations)
- Do not open windows with gap /tilt open (continuous ventilation), but instead open wide for a short time (purge ventilation)

4.2 Maintenance

Wipe down the outside of the unit only using a damp cloth or cloth with mild cleaning product (washing-up liquid, neutral cleaning product). Do not use any harsh, abrasive, acid or chlorine-based cleaning products.



5 Delivery, storage, transport and installation

IMPORTANT

Damage to the housing and the unit components due to heavy objects.

- Do not place any objects on the unit.

5.1 Scope of supply



NOTE

On delivery the accessories are enclosed in two packages on the housing.

- Check delivery immediately after receipt for outwardly visible damage and completeness.
- Notify supplier of any defects immediately.

The separate pack included contains:

- Control unit, consisting of the control, wall bracket and masking plate
- 6-mm anchors with screws (2x each) for wall-mounting the control unit
- Safety valve, outdoor sensor
- Compression fittings Ø28-Rp 1" (4x)
- Ball valve with filter 1" (1x) Must be mounted on the heating water inlet of the device! Observe the direction of flow!
- Replacement material after dismantling the module box:
 - Insulation hoses (4x)
 - Cable ties (8x)
 - O-rings (6x), Flat seal (1x)
- Screws for the strain reliefs in the electrical switch box

5.2 Storage



WARNING

The unit may only be stored in rooms that do not contain ignition sources. Do not drill or torch! Follow local rules!

- Where possible do not unpack the unit until directly before installation.
- Store unit protected against:
 - Moisture/damp
 - Frost
 - Dust and dirt

5.3 Unpacking and transport



NOTE

The module box can be removed for transport (→ "Dismantle the module box", page 12).

Notes on safe transport

The heating station and the module box are heavy (→ "Technical data / Scope of supply", from page 25). There is a risk of injuries or damage to property if the housing with the unit components falls or overturns or if the module box falls.

- The heating station and module box must be transported and installed by several persons.
- Secure the heating station during transport. Carry the module box by the carrying lugs.

The hydraulic connections are not designed for mechanical loads.

- Do not lift or transport the unit by the hydraulic connections.

If the module box is tilted by more than 45°, compressor oil runs into the cooling circuit.

- Do not tilt the unit with installed module box by more than 45°.

Transport the unit preferably with a pallet truck, alternatively with a handcart.

Transport with a pallet truck

- Transport the unit to the place of installation packaged and secured on a wooden pallet.

Unpacking



NOTE

If the unit is not transported by a pallet truck: Do not lift off the pallet until after unpacking and dismantling the housing panels.

1. Remove plastic films. Ensure that you do not damage the unit.
2. Dispose of the mounting bracket, transport and packaging material in an environmentally friendly way according to local regulations.
3. Remove the film from the plastic element of the front panel in the place of installation.




Dismantle housing panels for transport with handcart or carrying the unit

- ✓ Unit is unpacked (→ “Unpacking”, page 10).

To avoid damage to the housing panels:

1. Undo 2 screws at the bottom of the front panel.
Lift up the front panel and put it down in safe place.
2. Undo 3 screws at the right panel.
Lift up the side panel and put it down in safe place.
3. Undo 3 screws at the left panel.
Lift up the side panel and put it down in safe place.



Transport with a handcart




NOTE

- If transporting with a handcart the module box must be pushed in.
- The following figure with the handcart shows transporting the unit on its left-hand side; it can also be transported on its right-hand side.
- Secure the unit against slipping or tilting from the handcart
- Do not exceed 45° tilt angle.
- Do not expose the unit to strong shocks.
- Comply with local safety regulations during transport.

- ✓ Housing panels are dismantled.

To avoid damage: On a handcart, load the unit on its side only.



Transport unit on the handcart.

Carrying the unit

- ✓ Housing panels are dismantled.
1. Dismantle module box (→ “Dismantle the module box”, page 12) and carry it by the support lugs to the place of installation.
 2. Carry the unit in a position as upright as possible

5.4 Installation

Installation room and space requirements



NOTE

Note and follow the local regulations and standards regarding the installation room and space requirements. The more refrigerant in a heat pump, the bigger the room must be where the unit is installed. If there is a leak in a too small room there would be a forming of a flammable gas-air mixture. A free volume of 1.7 m³ must be maintained in the set-up room. The amount of refrigerant is shown on the type-plate of the appliance.



NOTE

If several heat pumps of the same type are installed only one heat pump need to be taken into account. If several heat pumps of different types are installed, only the heat pump with the largest refrigerant volume needs to be taken into account.

- ✓ Minimum volume corresponds to the requirements for the refrigerant used.
- ✓ Installation inside the building only.
- ✓ Installation room is dry and frost-free.
- ✓ Clearance dimensions are met (→ "Installation plans", from page 29).
- ✓ The surface/floor is suitable for installation of the unit:
 - level and horizontal
 - load-bearing capacity for the unit's weight


Aligning the unit

- ▶ Align the unit horizontally and stably in the installation site using the height-adjustable feet and a spanner size SW 13. Adjustment range: 25 mm.

Remove safety device

The transport lock of the circulation pump in the module box must be removed before installation.

- ✓ Unit is safely disconnected from the power supply and protected against being switched back on again.
1. Remove the front panel of the module box (→ "7.1 Remove the front panel of the module box", page 18).
 2. Remove styrofoam safety device.



3. Screw the front panel of the module box.

6 Installation and connection

6.1 Dismantle the module box

IMPORTANT

If the module box is tilted by more than 45°, compressor oil runs into the cooling circuit.

- ▶ Do not tilt the module box by more than 45°.



NOTE

- If necessary the module box can be dismantled for easier transport of the unit or for service reasons.
- Steps 1 to 3 are only required if the module box is connected and filled.


- ✓ Unit is safely disconnected from the power supply and protected against being switched back on again.
1. Remove the front panel of the module box (→ "7.1 Remove the front panel of the module box", page 18).
 2. Close shut-off valves to the heating circuit.
 3. Drain the unit via the filling and drain tap of the heating.




NOTE

The hose connectors are not part of the scope of delivery with all KFE ball valves.

- ▶ Unit **without** cooling:




- ▶ Unit **with** cooling:






4. Disconnect the electrical connections:


- Disconnect 2 white connectors (①) at the bottom of the electrical control cabinet. To do this, release the lugs by pressing on the sides of the connectors
- Pull out the black rectangular connector (②) at the top of the module box



5. Remove the insulation on the heat source and the heating circuit connections.




6. Use spanner to close the barriers to the heating circuit and to the heat source (behind the covers).




7. Drain the unit via the filling and drain tap of the heat source.


► Unit **without** cooling:




► Unit **with** cooling:



8. Remove 3 clips on the hydraulic connections. (2 clips with riveted grounding tape.)




9. Use spanner size SW 37 to unscrew the heating flow.







10. Disconnect the hydraulic connections; to do this, push the pipes apart as far as necessary.



11. Remove the 2 side retaining screws.




12. To protect the floor and move the module box (③) more easily: place boards (④) under it, e.g. from the packaging material.



13. Lift and hold nut (①) on the heating flow.
14. Slowly and carefully pull out the module box by the carrying lugs (②). Ensure that none of the pipes are damaged

15. Pull out the module box completely and place it on the boards.



6.2 Install the module box

1. Place the module box carefully in the bottom of the heating station and slowly and carefully push it in.
 - Lift and hold nut on the heating flow
 - Lift up pipes so that they do not get damaged
2. Attach the two side retaining screws.
3. Connect the hydraulic connections. (Reattach the three clips, two of them with grounding tape) At the same time, replace O-rings on the heat pump connections (→ separate pack included).
4. Reopen barriers to the heating circuit and the heat source.
5. Perform pressure test and insulate pipes with the enclosed insulation hoses (→ separate pack).
6. Connect the electrical cables:
 - Plug in 2 white connectors at the bottom of the electrical control cabinet. Ensure that the connectors move easily and the lugs latch into position
 - Plug in the black rectangular connector at the top of the module box



6.3 Install the hydraulic connections



NOTE

The safety valve that is integrated or included in delivery has a tolerance of plus / minus 10% for the set pressure. If local regulations, laws, standards or directives require a smaller tolerance range, the safety valve must be replaced on site with a safety valve that meets the requirements.

IMPORTANT

Avoid open heating systems and / or heating systems that are not oxygen diffusion-tight. If this is not possible, a system separation must be installed.

Depending on the dimensioning of the heat exchanger and the additionally required circulation pump, the system separation worsens the energy efficiency of the system.

IMPORTANT

Dirt and deposits in the (existing) hydraulic system can cause damage to the heat pump.

- ▶ Ensure that a air / magnetic sludge separator is installed in the heating circuit.
- ▶ Make sure that the ball valve with dirt filter (screen size 0.7 mm) from the separate pack is installed as close as possible to the heating water inlet (Return).
- ▶ Rinse the hydraulic system thoroughly prior to establishing the hydraulic connection of the heat pump.



NOTE

The heat source can be connected from the top, right or left.

If the heat source will be connected at the side, the cables can be cut to a residual length of at least 250 mm from the edge of the device (→ "Dimensional drawings", page 27).

IMPORTANT

Damage to the copper pipes due to unacceptable loading!

- ▶ Secure all connections against twisting.

- ✓ The heat source system has been installed in accordance with the specifications (→ planning & design manual, dimensioned diagrams, installation plans).
- ✓ Cross-sections and lengths of the pipes for the heating circuit and heat source are dimensioned adequately.
- ✓ The residual head of the circulation pumps produces at least the minimum throughput required for the unit type (→ "Technical data / Scope of supply", from page 25).
- ✓ The cables for the heat source and the heating are fixed to the wall or ceiling via a fixed point.

Install the compression fittings and ball valves

IMPORTANT

Leaks or fracture of the union nut due to excessive force!

1. Check pipe ends for scratches, dirt and deformation.
2. Check proper position of the clamping ring on the fitting.
3. Push the pipe through the clamping ring up to the limit stop in the fitting.
4. Tighten the union nut hand-tight and attach waterproof marking.
5. Tighten union nut with $\frac{3}{4}$ rotation.
6. Check connection for leaks.

If the connection leaks:

1. Undo connection and check pipe for damage.
2. Tighten the union nut hand-tight and retighten with the open-ended spanner with $\frac{1}{8}$ to $\frac{1}{4}$ turn, as the clamping ring is already in a clamping position.

Connect the unit to the heat source, domestic water pipes and heating circuit

1. Install shut-off devices at the connections of the heat source and heating circuit.
2. Insert the vent at the highest point of the heat source and the heating circuit.



3. Recommendation: Fit a dirt filter with mesh size 0.9 mm onto the heat source inlet.
4. Connect the domestic hot water tank according to the local regulations.
5. Recommendation: To balance out pressure fluctuations and water hammers and avoid unnecessary loss of water, install an expansion vessel with through-flow fitting.
6. Ensure that the operating overpressures (→ “Technical data / Scope of supply”, from page 25) are not exceeded. Install pressure reducer if necessary.

6.4 Connect the electrical cables

IMPORTANT

Irreparable damage to the compressor due to wrong rotating field (only applies to units with 400V connection).

- Ensure that there is a clockwise rotating field for the compressor load infeed.

Basic information on the electrical connection



NOTE

Ensure that the unit is supplied with electricity at all times. After working inside the unit and attaching the unit panelling, switch the power supply back on immediately.

- The specifications of the local energy supply company may apply to electrical connections
- Fit the power supply for the heat pump with an all-pole miniature circuit-breaker with at least 3 mm contact spacing (per IEC 60947-2)
- Note the level of the tripping current (→ “Technical data / Scope of supply”, from page 25)
- Comply with the electromagnetic compatibility regulations (EMC regulations)
- Lay unshielded power supply cables and shielded cables (bus cable) sufficiently far apart (> 100 mm)

Special voltages

The control box contains an accessory kit for converting the electrical system to a 3-phase, 230 V three-phase mains supply.

→ “Circuit diagrams”, page 39



NOTE

Check the local mains supply type!




NOTE


Installation must be carried out by qualified electricians only!

Pull in the cables and conductors and make the connections

1. Strip the sheathing of all cables to the external loads before laying in the cable duct of the control box.
2. Open electrical switch box:
 - Undo 2 screws at the top of the cover panel of the electrical control box
 - Unhook cover panel



3. Lay the control / sensor cables and unit supply cable and connect:
 - Route cables through the reserve conduits (①) and (②) only, from above into the inside of the unit






NOTE

The figure shows a unit variant without cooling.

4. Route cables from underneath through the cable openings in the control box (③)
5. Connect cables to the respective terminals (→ "Circuit diagrams", from page 39).
6. Route all cables inserted into the switch box through the strain reliefs and screw the strain reliefs tight with the screws from the separate pack.
7. Close the switch box by re-hooking the cover panel and screw the cover panel tight.

Operate the controller via a PC /network

1. During installation lay a shielded network cable (category 6) through the unit.
2. Plug the RJ-45 connector of the network cable into the socket of the control unit (①).



NOTE

The network cable can be retrofitted at any time.

6.5 Installing the control panel




NOTE


The control can be inserted in a recess in the front panel of the unit or can be installed on the wall.

Insert the control in the unit and connect

1. If required: Remove masking plate from the slot. To do this, dismantle the front panel (→ "Dismantle housing panels for transport with handcart or carrying the unit", page 11), press the lugs together and push out of the openings.
2. Remove film from the plastic element of the front panel.
3. Position the control unit in the recess in the front panel of the unit and press the latching lugs into the openings.



4. Wind the cable up or down and secure it so that the front panel can be removed and placed to the side of the unit. Do not cut the cable ties for strain relief of the connecting cable to the control board at the electric control box.
 - Connecting cable approx. 1.1 m from the fixing of the strain relief at the electrical control box
 - All other cables approx. 1.2 m
5. Use cable ties (→separate pack) to fix the connecting cable to a web of the masking plate around 20 cm in front of the connector (strain relief).



6. Push the cable through the opening in the front panel of the unit from below and into the control.
7. Press the lugs of the control into the openings in the front panel of the unit.
8. Insert cover in the free slot.

Mount the control on the wall and connect


IMPORTANT

Mount the wall bracket with control panel **only vertically** on a wall!

1. Release the rear bracket from the control.



2. If visually unattractive: Cut off the lugs on the rear of the control (are only needed to insert in the front panel).
3. Mark 2 drillholes (→ Dimensional drawing “Wall-mounted bracket”, page 28).
4. If cables are fed in from underneath: Break out the web at the bottom in the middle of the wall bracket. Use side-cutters if necessary.
5. Fix the wall-mounted bracket (②) with 2 wall plugs (①) and 2 screws (③).




6. Feed in the cables from the wall (e.g. in-wall box) or from below.
7. Route the connecting cable to control board and the Modbus cable from the top right-hand side at the rear from the heat pump and plug into the control at the bottom. (also connect the network cable if needed)
8. Push the control onto the wall-mounted bracket.
9. Push on cover. If applicable, position second cover (accessories) on the second unused slot.

7 Flushing, filling and venting

7.1 Remove the front panel of the module box

- Unscrew the front panel of the module box.



7.2 Flush, fill and vent heat source

Below are the approved antifreeze agents based on:

- Monopropylene glycol
- Monoethylene glycol
- Ethanol
- Methanol

Antifreeze agents based on salt are not permitted.

- When selecting the antifreeze agent, it must be ensured that it is compatible with the following materials:

- Brass (CW602N and CW614N)
- Stainless steel (AISI304, AISI316 and AISI316L)
- Copper (Cu-DHP CW024A - EN1652)
- Cast iron (EN-GJL-150)
- Composite (PES 30% GF)
- EPDM (ethylene propylene diene rubber)
- PTFE (Polytetrafluoroethylene)
- FKM (fluororubber)

If an antifreeze agent is not compatible with one of these materials, it may not be used.



Antifreeze agents from our product range are safe with regard to our units and the accessories purchased from us and guarantee compatibility with the listed materials.

- ▶ Pressure losses must be observed when selecting the antifreeze agent.
- ▶ The antifreeze agent that is selected and used must comply with the specifications and requirements of the local authorities and water management authorities.



WARNING

Methanol and ethanol can give off flammable and explosive gases. Therefore, the safety provisions for the anti-freeze must be noted and followed!

The hazard markings of all anti-freezes used must be noted and the relevant safety provisions must be followed.

- ▶ Make sure that the mixing ratio of water and antifreeze agent meets the required minimum antifreeze temperature in the heat source.
- “Technical data / Scope of supply“, from page 25
- ▶ For operation of the heat source with water-antifreeze mixture, ensure that the water used fulfils the quality specifications of the heating water side.
- “Heating water quality“, page 19
- ✓ Drain pipe of the safety valve is connected.
- ✓ Room is ventilated.
- 1. Flush the heat source system thoroughly.
- 2. Mix antifreeze with water thoroughly with the required ratio, before adding to the heat source.
- 3. Check the concentration of the water-antifreeze mixture.
- 4. Fill the heat source with the water-antifreeze mixture.
Fill until the system is air-free.
- 5. Fill the unit via the ball valves in the module box.

7.3 Flush and fill the heating and domestic hot water charging circuit

Heating water quality



NOTE

For detailed information refer, among other things, to the VDI Guidelines 2035 “Vermeidung von Schäden in Warmwasserheizanlagen” (preventing damage in hot water heating systems).


1. Ensure that the pH-value of the heating water is between 8.2 – 10, for aluminium materials between 8.2 – 9.
Ideally, the pH value should already be in the required range after filling. After 6 weeks at the latest, it must have adjusted to the required range.
2. Ensure that the electrical conductivity is < 100 µS/cm.





NOTE

If the required water quality is not achieved, consult a company specialising in the treatment of heating water.


3. Fill the system with deionised heating water (VE water) or with water corresponding to the VDI 2035 norm only (low-salt operation of the system).
Advantages of low-salt operation:
 - Low corrosion-promoting properties
 - No formation of mineral scale
 - Ideal for closed heating circuits
 4. Keep a system log for hot water heating systems in which relevant planning data and the water quality are entered (VDI 2035).
- ✓ Drain pipe of the safety valve is connected.
 - ✓ The front panel of the module box is unscrewed.
 - ▶ Ensure that the set pressure of the safety valve is not exceeded.
1. Pull the U-clip (②) off the floor of the valve motor (①).
 2. Pull the valve motor carefully upwards and off the 3-way changeover valve (③).



3. Turn the spindle of the 3-way changeover valve so that the rounded side of the spindle points in the direction of marking A of the connections of the 3-way changeover valve.



4. Flush the domestic hot water charging circuit for approx. 1 minute.
5. Turn the spindle so that the rounded side of the spindle points in the direction of marking B of the connections of the 3-way changeover valve.
6. Flush heating circuit thoroughly, until no more air is discharged.
7. Position the valve motor (1) on the 3-way changeover valve (3).
8. Insert the U-clip (2) into the floor of the valve motor.



9. Ensure that the U-clip has latched into position correctly:
 - ✓ Valve motor sits securely on the 3-way changeover valve.
 - ✓ Both prongs of the U-clip sit on the lug.
 - ✓ The tips of the U-clip are visible by approx. 2 mm (not significantly more!).
10. Screw the front panel of the module box.

7.4 Flush, fill and vent the domestic hot water tank

- ✓ Drain pipe of the safety valve is connected.
 - Ensure that the set pressure of the safety valve is not exceeded.
1. Open the domestic water inlet valve at the domestic hot water tank.
 2. Open taps for domestic hot water.
 3. Flush the domestic hot water tank until no more air discharges from the valves at the taps.
 4. Close taps for domestic hot water.



8 Insulate hydraulic connections

1. Insulate heating circuit, heat source and domestic water pipes according to the local regulations.
2. Open shut-off devices.
3. Perform a pressure test and check for leaks.
4. Insulate the internal piping of the module box with the insulation material from the separate pack included.
5. Insulate external piping on site.
6. Insulate all connections, fittings and pipes.
7. Insulate heat source so that it is vapour-diffusion tight.
8. Insulate the heating circuit of units with cooling vapour-diffusion tight too.

9 Commissioning



NOTE

The first filling and initial startup of the domestic hot water tank must be carried out by qualified personnel.

- ✓ Relevant planning & design data of the system is documented in full.
 - ✓ The competent energy supplier has been notified of operation of the heat pump system.
 - ✓ System is air-free.
 - ✓ Installation check using the rough checklist has been completed successfully.
 - ✓ Clockwise rotating field is present for the load supply at the compressor (only applies to units with 400V connection)
 - ✓ Heating station is installed and mounted according to this operating manual
 - ✓ The electrical installation has been carried out properly in accordance with this operating manual and local regulations
 - ✓ The power supply for the heat pump is equipped with an all-pole circuit-breaker with at least 3 mm contact spacing (IEC 60947-2)
 - ✓ The level of the tripping current is compliant
 - ✓ Heating circuit is flushed and vented
 - ✓ Frost protection of the heat source meets the requirements
→ "Technical data / Scope of supply", from page 25
 - ✓ All shut-off devices of the heating circuit are open
 - ✓ All shut-off devices of the heat source are open
 - ✓ The pipe systems and components of the system are leak-tight
1. Fill out carefully and sign the notice of completion for heat pump systems.
 2. In Germany: Send notice of completion for heat pump systems and rough checklist to the manufacturer's factory customer service department.
In other countries: Send notice of completion for heat pump systems and rough checklist to the manufacturer's local partner.
 3. Arrange for the heat pump system to be commissioned by after-sales service authorised by the manufacturer; this is a chargeable service.
→ "10.2 Maintenance after commissioning", page 22



10 Maintenance



NOTE

We recommend that you sign a maintenance agreement with an accredited heating company.

10.1 Basic principles

The cooling circuit of the heat pump does not require any regular maintenance.

Local regulations require, among other things, leak checks beforehand and/or for a logbook to be kept for certain heat pumps.

- Ensure compliance with local regulations with regard to the specific heat pump system.


10.2 Maintenance after commissioning

Check all installed dirt traps for dirt at the latest one week after commissioning and clean them if necessary.

- Switch off the system while the check and cleaning is being carried out.

Next checking and cleaning at the latest 2 weeks after commissioning.

Cleaning the shut-off device with dirt trap (separate package)





10.3 Maintenance as required

- Checking and cleaning the components of the heating circuit and the heat source, e.g. valves, expansion vessels, circulation pumps, filters, dirt traps

10.4 Cleaning and flushing the plate heat exchanger

1. Clean and flush the plate heat exchanger according to the manufacturer's instructions.
2. After flushing the plate heat exchanger with chemical cleaning agent: neutralise any residues and flush the plate heat exchanger thoroughly with water.

10.5 Yearly maintenance

- ▶ Determine the quality of the heating water by analysis. In the event of deviations from the specifications, take suitable measures without delay
- ▶ Check all installed dirt traps for dirt and clean them if necessary
- ▶ Check the function of the safety valve for the hot water accumulator and for the heating circuit.


11 Faults

- ▶ Read out the cause of the fault via the diagnostics program of the heating and heat pump controller.
- ▶ Contact the local partner of the manufacturer or the factory's customer service. Have the fault message and unit number (→ "Rating plate", page 7) to hand.

11.1 Unlock the safety temperature limiter

A safety temperature limiter is installed in the electric heating element. If the heat pump fails or there is air in the system:

- ▶ Check whether the Reset button (②) of the safety temperature limiter (①) has jumped out (by approx. 2 mm).




- ▶ Press the reset button (②) back in again.
- ▶ If the safety temperature limiter trips again, contact the local partner of the manufacturer or the factory's customer service.

11.2 Manually unblock the circulating pumps

Circulating pumps can block due to sediments or longer standstill periods. This blockage can be removed manually.

Release the blockage of the heating circulating pump

- ▶ Insert the screwdriver into the hole (①), press the plunger in the circulating pump against the shaft and release the blocked shaft in the direction of rotation of the circulating pump.





12 Dismantling and Disposal

12.1 Dismantling


- ✓ The disposal equipment is suitable for flammable refrigerants.
- ✓ The locally applicable regulations for handling flammable refrigerants are complied with.
- ▶ Keep away from sources of ignition.
- ▶ Collect all substances safely.
- ▶ Separate components according to their materials.

12.2 Disposal and recycling

- ▶ Dispose of environmentally hazardous substances (e.g. refrigerant, compressor oil) according to the local regulations.
- ▶ Recycle or ensure proper disposal of unit components and packaging materials according to local regulations.

12.3 Removal of the buffer battery

1. Use a screwdriver to push out the buffer battery (type: CR2032, lithium) on the processor board of the control



2. Dispose of the buffer battery according to local regulations.







Technical data / Scope of supply

Performance data		Values in brackets: (1 Compressor)		WZSV 63K(H)1/3M	
Heating capacity COP	for B0/W35 acc. to DIN EN 14511-x	kW COP		2,45 4,66	
	for B0/W45 acc. to DIN EN 14511-x	kW COP		2,20 3,13	
	for B0/W55 acc. to DIN EN 14511-x	kW COP		2,70 2,97	
	for B7/W35 flow of B0/W35	kW COP		2,51 4,75	
Heating capacity	for B0/W35	min. max.	kW kW	0,87 6,00	
	for B0/W45	min. max.	kW kW	0,77 5,47	
	for B0/W55	min. max.	kW kW	0,6 5,08	
	for B7/W35	min. max.	kW kW	1,1 7,09	
Cooling capacity at max. flow rate (B10/W18), dT 3K units with passive cooling: Identifier K			kW	4,1	
Operating limits					
Heating circuit return min. Heating circuit flow max.		Heating	within heat source min./max.	°C	20 75
Heating circuit return min. Heating circuit flow max.		Cooling	within heat source min./max.	°C	-
Heat source, heating		min. max.		°C	-13 30
Additional operating points				...	-
Installation location					
Room temperature		min. max.		°C	5 35
Relative humidity maximum (non-condensing)				%	60
Sound					
Sound pressure level at 1 m distance from edge of unit		min. max.		dB(A)	32 39
Sound power level		min. max.		dB(A)	39 51
Sound power level acc. to DIN EN 12102-1				dB(A)	40
Tonality Low-frequency				dB(A) • yes – no	-
Heat source					
Volume flow (pipe dimensioning)				l/h	1450
Residual head (with cooling)***) Pressure loss (with cooling) Flow rate		bar (bar) bar (bar) l/h		0,80 (0,65) - 1450	
Approved anti-freeze mixture		Monoethylene glycol Propylene glycol Methanol Ethanol		• • • •	
Anti-freeze concentration: Minimum frost protection down to				°C	-15
Max. allowable operating pressure				bar	4,5
Circulation pump control range		min. max.		l/h	200 2500
Heating circuit					
Flow rate (pipe dimensioning) Min. volume buffer tank in series Min. volume separation buffer tank		l/h l l		1050 - -	
Residual head (with cooling) Pressure loss (with cooling) Flow rate		bar (bar) bar (bar) l/h		0,60 (0,52) - 1050	
Max. allowable operating pressure				bar	3
General unit data					
Data of the standards according to version		EN14511-x DIN EN 12102-1		2022 2022	
Total weight (with cooling)		kg (kg)		223 (230)	
Box weight (with cooling) Tower weight (with cooling)		kg (kg) kg (kg)		63 (70) 160 (160)	
Max. allowable operating pressure refrigerating circuit		high pressure low pressure	MPa (g) MPa (g)	3,73 1,37	
Refrigerant type Refrigerant capacity		... kg		R290 0,165	
Domestic hot water tank					
Net volume		l		178	
Material		Enamel Stainless steel	• yes – no	• -	
Protective anode		Impressed current Magnesium	• yes – no	• -	
Heat exchanger area		m²		2,14	
Domestic hot water temperature Heat pump operation Electric heating element		up to °C up to °C		65 65	
Mixed water quantity according to ErP: 2009/125/EG (at 40°C, draw-off of 10 l/min)		l		242	
Mixed water quantity 40°C at 10l/min Tank temperature 60°C		l		-	
Mixed water quantity 40°C at 10l/min Tank temperature 50°C		l		-	
Standing loss according to ErP ErP: 2009/125/EG (at 65°C)		W		54	
Maximum allowable temperature		°C		95	
Operating pressure Max. pressure Test pressure		bar bar bar		6 10 13	
Nominal size cleaning flange		DN		-	
Insulation thickness tank		mm		-	
U-value of tank insulation		W/(m²·K)		-	
Maximum sulphide content of drinking water		mg/l		-	
Maximum chloride content of drinking water		mg/l		-	
Electrical conductivity		µS/cm		> 100	
Electrics					
Voltage code all-pole fuse protection for heat pump *)**)		... A		1-N/PE/230V/50Hz C16	
Voltage code all-pole fuse protection for heat pump *) + electric heating element **)		... A		- -	
Voltage code Control voltage fuse protection **)		... A		1-N/PE/230V/50Hz B10	
Voltage code Electric heating element fuse protection **)		... A		3-N/PE/400V/50Hz B16	
HP*): effect. power consumption B0/W35 (partial load operation) DIN EN 14511-x Electric consumption cosφ		kW A ...		0,53 0,84 0,92	
HP*): effective power consumption B0/W35 acc. to DIN EN 14511-x: min. max.		kW kW		0,21 1,62	
HP*): Max. machine current Max. power consumption within the operating limits		A kW		14 2,9	
Starting current: direct with soft starter		A A		< 5 -	
Degree of protection		IP		20	
Zmax		Ω		0,26	
Residual current circuit breaker		if required	type	B	
Electric heating element output		3 2 1 phase	kW kW kW	6 4 2	
Circulation pump power consumption, heating circuit heat source		min. max.	W W	2 – 63 3 – 140	
Other unit information					
Safety valve Heating circuit Response pressure		included in scope of supply: • yes – no bar		• 3	
Safety valve Heat source Response pressure		included in scope of supply: • yes – no bar		- -	
Buffer tank Volume		included in scope of supply: • yes – no l		- -	
Diaphragm expansion vessel Heating circuit Volume Prepressure		incl. in scope of supply: • yes – no l bar		- -	
Diaphragm expansion vessel Heat source Volume Prepressure		incl. in scope of supply: • yes – no l bar		- -	
Overflow valve Changeover valve, heating - domestic hot water		integrated: • yes – no		- •	
Vibration decoupling, Heating circuit Heat source		included in scope of supply or integrated: • yes – no		• •	
Controller Heat quantity recording Extension board		included in scope of supply or integrated: • yes – no		• • -	




Performance curves

WZSV 63K1/3M



Keys: UK823000L/170408


$\dot{V}_{HW}$	Heating water volume flow rate
$\dot{V}_{WQ}$	Heat source volume flow rate
Temp _{WQ}	Heat source temperature
Q _h	Heating capacity
Pe	Power consumption
COP	Coefficient of performance
Δp _{1HW}	Maximum residual head heating circuit
Δp _{2HW}	Maximum residual head heat source
VD	Compressor
Temp _{HW}	Heating water temperature (flow)





WZSV 63K(H)1/3M

Dimensional drawings




*) outside diameter **) inside diameter




Dimensional drawings

Control unit



All dimensions in mm..

Wall-mounted bracket





All dimensions in mm..



WZSV 63K(H)1/3M

Installation plan 1

V1



Keys: UK819448

All dimensions in mm.



V1	Version 1
FS	Free space for service purposes
FZ	Free space for functionally necessary accessories
OKF	Finished floor level
Rh min.	minimum room height



Installation plan 2

V2

WZSV 63K(H)1/3M



Keys: UK819448

All dimensions in mm.



V2	Version 2
FS	Free space for service purposes
FZ	Free space for functionally necessary accessories
OKF	Finished floor level
Rh min.	minimum room height



WZSV 63K(H)1/3M

Installation plan 3

V3



Keys: UK819448


All dimensions in mm.

V3	Version 3
FS	Free space for service purposes
OKF	Finished floor level
Rh min.	minimum room height



Hydraulic integration

Unit variant Heating




NOTE

This schematic diagram is an example of a system without shut-off and safety devices, and it does not replace the technical planning and design on site. All regional standards, laws and regulations must be observed. The pipe dimensions must be carefully planned and designed.



Unit variant Heating

with separate buffer tank




NOTE

This schematic diagram is an example of a system without shut-off and safety devices, and it does not replace the technical planning and design on site. All regional standards, laws and regulations must be observed. The pipe dimensions must be carefully planned and designed.



Hydraulic integration (cooling)

Unit variant Cooling (K)



NOTE
This schematic diagram is an example of a system without shut-off and safety devices, and it does not replace the technical planning and design on site. All regional standards, laws and regulations must be observed. The pipe dimensions must be carefully planned and designed.





	Vibration isolation		Gas- or oil-boiler	Split:	Switching valve domestic hot water / heating
	Shut-off device and drainage		Wood boiler	QN10	Switching valve cooling / heating
	Shut-off device with dirt trap		Brine pressure switch	QN12	Mixing valve additional heating
	Safety group		Swimming pool heat exchanger	GP12	Circulation pump
	Shut-off device		Separation heat exchanger / intermediate heat exchanger	BT1	Outdoor temperature sensor
	Circulation pump		Solar domestic hot water tank	BT7	upper domestic hot water (displayed value)
	Non return valve/ one way valve			BT3	Sensor return
	Overflow valve			BT6	Sensor domestic hot water
	Membrane expansion vessel		Pipe lead-in	BT4	Flow sensor cooling
	Second heat generator (ZWE)		Fresh water station (TWS)	BT15	Temperature sensor, liquid state
	3-way mixing valve / switching valve		Room control unit	BT25	Flow temperature heating
	4-way mixing valve / switching valve		Dew-point monitor	BT71	Return temperature heating / cooling
	Dirt-trap		Supply heat pump	BT52	Sensor heating boiler
	Wall breakthrough			BT50	Room temperature sensor
	Brine manifold		Circulation pump / switching valve domestic hot water	XL1	Flow heating
	Ground slinkies		Mixer circuit 1/2/3 (heating or cooling function)	XL2	Return heating / cooling
	Ground collector		Circulation pump heating circuit	XL3	Cold water
	Flow switch		Circulation pump / switching valve	XL4	Domestic hot water
	Groundwater spring pump with flow direction groundwater		Feed circulating pump	XL5	Circulation
	Buffer tank: - TPS Stratified storage tank - RPS Series buffer tank - TPSK Stratified storage tank (cooling) - WTPSK Stratified storage tank, wall-mounted (cooling)		Circulation pump	XL10	Flow cooling
	Multifunction tank		Domestic hot water charging pump	XL13	Liquid refrigerant
	Domestic hot water tank		Heat source circulation pump	XL14	Gaseous refrigerant
	Volume flow meter		Outdoor temperature sensor	XL18	Flow second heat generator
	Heat meter		Sensor domestic hot water	XL19	Return second heat generator
			Sensor mixer circuit	X2	Terminal second heat generator
			Sensor external return	EP Split	Expansion board Split
			Sensor return		(not included in scope of delivery)
			Flow sensor		
			Sensor desuperheater		
			Heating circuit		
			Heating mixing circuit		
			Cooling circuit		
			Cooling mixing circuit		
			Safety package primary		
			Safety package secondary		
			Circulation pump desuperheater		
			Controls supplied by customer		
			101		

Controls supplied by customer / on-site components:

Parts and components shown in the colour "grey" must be provided by the customer and also operated with a regulation provided by the customer.

The temperature difference control SLP of the additional board is excepted from this.

General:

Pipes, fittings and fixtures must be designed and insulated in accordance with the current and valid standards, guidelines and recognised rules of technology (e.g.: vapour diffusion-tight insulation if the temperature falls below the dew point).



WZSV 63K(H)1/3M




IMPORTANT

The cable cross-sections shown are only intended as a guideline for the electrician! They must be adapted to the regional regulations and the conditions of use (e.g. cable length, current carrying capacity, ambient temperature, type of installation)!



WZSV 63K(H)1/3M

Terminal diagram 2/3




Terminal diagram 3/3

WZSV 63K(H)1/3M

[illegible]




Circuit diagram 1/9






Circuit diagram 2/9

WZSV 63K(H)1/3M








42



WZSV 63K(H)1/3M


Circuit diagram 5/9






Circuit diagram 6/9

WZSV 63K(H)1/3M





Circuit diagram 7/9



Equipment	Description
B10	High-pressure sensor
B11	Low pressure sensor
K22	Electronic expansion valve heating
K50	ASB board
R1	Suction sensor, condenser
R2	Liquid temperature heating
R4	Hot gas sensor
R5	Heat source input sensor
R6	Heat source output sensor
R11	Coding resistance; 19,6kOhm
+MR1	Machine room

alpha innotec –
a brand of
ait-deutschland GmbH

Subject to technical changes.

ait-deutschland GmbH

Industriestr. 3
95359 Kasendorf
Germany

[T] +49 9228 / 9906-0
[F] +49 9228 / 9906-189
[E] info@alpha-innotec.de

www.alpha-innotec.com

