





6M.Tx – User Guide

Single phase modbus power monitors


6M.TX USER'S GUIDE


PRODUCT OVERVIEW	3
CONNECTION AND WIRING	4
DEVICE POWER SUPPLY	5
DIP SWITCH SETTINGS	6
CONFIGURATION SOFTWARE	7
CABLE CONNECTION	8
NEW CONNECTION FROM FACTORY PARAMETERS	12
CONNECTION TO THE DEVICE AND CHECK MEASUREMENTS IN REAL TIME	13
OFFLINE PROGRAMMING	14

PRODUCT OVERVIEW



6M.Tx family consists of 3 single phase power monitor devices that can be used in AC and DC systems. Frequency range for AC systems from 1 to 400 Hz, with nominal current from 50 up to 300 A (Up to 400 A in DC systems). 6M.Tx devices are able to make measurements of V_{pk} , I_{pk} , THD(U), etc... which relate to the quality of the network supply. Measurement data is sent using Modbus RS485 protocol.





- 1** - Voltage input terminals for connection to L (or N) of an AC system, or the secondary of a VT (Voltage transformer) if used. Or, for connection to the negative polarity of a DC system
- 2** - Voltage input terminals for connection to N, (or L) of an AC system, or the secondary of a VT (Voltage transformer) if used. Or, for connection to the positive polarity of a DC system
- 3** - Terminals for Modbus cable connection. Take care to observe the correct polarity (A+, B-).
The cable shield can be connected to the “-” or GND terminal of the power supply
- 4** - Terminals for connecting the 6M to either a 12 or 24 V DC power source.


To power the device correctly, we recommend using Finder power supplies: Type 78.12.1.230.2400 to power the product at 24 V DC or, Type 78.12.1.230.1200 to power the product at 12 V DC.

Both are 12 W power supplies; the choice should be made according to the power supply voltage required for the other components installed.

If it is necessary to use power supplies with higher power, refer to our catalogue or the website page:

<https://cdn.findernet.com/app/uploads/S78EN.pdf>

DIP SWITCH SETTINGS




Default

Address: 1

Baud: 9600

Default setting (1 ON and 2 OFF).


Use this setting to connect the PC to the 6M.Tx using Address 1 and baud rate of 9600 b/s.



Address: 1

Baud: 38400

Use setting 1 ON and 2 ON, to connect the 6M.Tx to a Modbus Master using Address 1 and transmission speed of 38400 b/s.




Use setting 1 OFF and 2 OFF, to use the 6M.Tx with the parameters set via software. To use the set parameters, remove power from the 6M.Tx, move DIP 1 downwards, and power up the 6M.Tx again.

IMPORTANT

The configuration software is written in JAVA.


IF NECESSARY, INSTALL THE VERSION OF JAVA 8 0 2510 8 enclosed in the software folder.

To activate the configuration software run the file 007_ver131




By clicking on "ACTIONS" at the top left, you can change the language.

01



To proceed you need to connect the 6M.Tx to a USB/Modbus converter.

02



IMPORTANT


To proceed with the programming of the 6M.Tx it is necessary to position the DIP Switches as the figure above: 1 ON, 2 OFF. Then switch the device off and on again by disconnecting and reconnecting the supply voltage. Press "NEXT" to continue.

This is the default position of the DIP Switches which allows you to reach 6M.Tx with

Address: 1 - Baud rate: 9600 bit/s

If the DIP Switches are not positioned as shown in the figure, it will not be possible to communicate with the 6M.Tx.

03




In this case the communication port is COM3.

If necessary, select the serial port from the drop-down menu and click on "UPDATE".


Then start connecting to the device.

04



LOAD CONFIGURATION FROM FILE

Allows you to load a configuration previously created and stored on the PC.



LOAD CONFIGURATION FROM DEVICE

Allows you to read the programming previously memorized on the 6M.Tx:
for example, this product was installed in a system which already had 4 other
devices installed, so has the address "4" (and has a baud rate of 115200).

Actions

6M CONFIGURATION SOFTWARE



MEASURING MODE **RMS**
ENERGY SAVING ON FLASH **ON**
CALCULATE FREQUENCY BY CURRENT CHANNEL **OFF**
INPUT VOLTAGE RATIO
INPUT CURRENT RATIO
FILTER **3**
MODBUS
BAUDRATE **9600**
PARITY **NONE**
RESPONSE DELAY
ADDRESS
FACTORY DEFAULT
MIN CURRENT THRESHOLD [mA]
MIN POWER THRESHOLD [W]
findernet.com

Click "NEXT"

Actions

6M CONFIGURATION SOFTWARE



**SAVE CONFIGURATION
TO A FILE**
**SEND AND TEST THE
CONFIGURATION
OF THE DEVICE**
**GO BACK TO STARTING
CONFIGURATION PAGE**
findernet.com

SAVE CONFIGURATION TO A FILE

This allows you to save the changes made previously or to store a “New configuration from factory parameters” on the hard disk of your PC.

SEND AND TEST THE CONFIGURATION OF THE DEVICE

Allows you to send the program to the 6M.Tx and to check its functioning.

NEW CONFIGURATION FROM DEFAULT PARAMETERS

Allows you to program the 6M.Tx starting from the factory parameters.

The screenshot shows the '6M CONFIGURATION SOFTWARE' window with the following settings:

- MEASURING MODE: RMS
- ENERGY SAVING ON FLASH: ON
- CALCULATE FREQUENCY BY CURRENT CHANNEL: OFF
- INPUT VOLTAGE RATIO: 1
- INPUT CURRENT RATIO: 1
- FILTER: 2
- MODBUS BAUDRATE: 9600
- MODBUS PARITY: NONE
- MODBUS RESPONSE DELAY: 1
- MODBUS ADDRESS: 1
- MIN CURRENT THRESHOLD [mA]: 0
- MIN POWER THRESHOLD [W]: 0

A 'FACTORY DEFAULT' button is visible. The footer includes 'findernet.com' and navigation buttons: 'GO TO STARTING PAGE', 'BACK', 'NEXT', and 'QUIT'.

Starting from the standard (factory) parameters, it is possible to program the 6M as follows:

Measuring mode: TRMS AC or DC depending on the type of system in which the 6M.Tx is installed.

Energy data saved to FLASH memory: saving active energy values (imported or exported) to the internal memory is enabled.

Frequency Calculation by current channel: voltage is typically used to calculate the frequency, but if this is not possible we can enable frequency calculation using the current.

Input voltage ratio: We can insert the VT transformation ratio, if a Voltage Transformer is installed at the voltage input terminals of the device.

Input current ratio: the 6M.Tx can also be used as a simple CT to measure the current in a system (in which case, connection to the voltage input terminals is not required).

Filter: selecting 1 you have a faster response speed, selecting 5 you have a slower response but more accurate reading. The default value is set to 2. For a more advanced setting it is possible to choose "Custom" in which we can apply filters in DC as well as in AC

Min current threshold (mA): current value below which 0 mA is read

Min power threshold (mW): power value below which 0 W is read

CONNECTION TO THE DEVICE TO SHOW REAL TIME MEASURES

This allows you to view all the electrical quantities measurable by the 6M.Tx in real time.

A USB/Modbus RS485 interface must be used as a communication bridge between the 6M.Tx and the PC.

Actions

6M CONFIGURATION SOFTWARE



	MIN	MEAS.	MAX	PEAK
Voltage [V]	0	228	231	329
Current [mA]	0	0	2801	12487
Active Power [W]	0	0	58	
Reactive Pow. [VAR]	0	0	540	
Apparent Pow. [VA]	0	0	641	
COS(φ)	0,000	0,000	1,000	
Energy [kWh]		1,15	SET	0
Pos. Energy [kWh]		2,10	SET	0
Neg. Energy [kWh]		-0,96	SET	0
Frequency [Hz]	0,0	50,0	50,2	
THD	0,000	0,000	4,165	


- ☐ FLASH SETTINGS
- ☐ FLASH CALIBRATION
- ☐ V OVER RANGE
- ☐ V UNDER RANGE
- ☐ I OVER RANGE
- ☐ I UNDER RANGE
- ☐ ERROR START ENERGY
- ☐ AC DETECTING

9600 Baud NO PARITY 8bit 1 Stopbit File Tar: 2205191425

findernet.com


GO TO STARTING PAGE BACK NEXT QUIT

01




This allows you to develop a 6M program without it being physically connected to the PC. The program will then be saved in a directory on the PC and subsequently sent to the device when "LOAD CONFIGURATION FROM FILE" is selected.

02




LOAD CONFIGURATION FROM FILE

Allows you to load and edit a previously created program.



NEW CONFIGURATION FROM DEFAULT PARAMETERS

It allows to create the program starting from the factory data. The program can be only saved on the PC and sent to the 6M only after connection with the USB/Modbus interface.



After the new configuration, by pressing next, you are asked to “save the configuration to file”. Proceed by storing it in a dedicated directory.

