


Rapid Link

RASP

Generation Change of Rapid Link RA-SP to RASP5



Level 3	1 – Fundamental – No previous experience necessary 2 – Basic – Basic knowledge recommended 3 – Advanced – Reasonable knowledge required 4 – Expert – Good experience recommended
----------------	--

All proprietary names and product designations are brand names or trademarks registered to the relevant title holders.

Break-Down Service

Please call your local representative:

Eaton.eu/aftersales

Eaton.com/us/en-us/support.html

Hotline After Sales Service:

+49 (0) 1805 223822 (de, en)

AfterSalesEGBonn@eaton.com

Original Application Note is the English version of this document.

All non-English language versions of this document are translations of the original application note.

1. Edition 2020, publication date 11/2020

Copyright

©2020 by Eaton Industries GmbH, 53115 Bonn

All rights reserved, also for the translation.

No part of this application note may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, micro-filming, recording or otherwise, without the prior written permission of Eaton Industries GmbH, Bonn.

Subject to alteration.

Content

1	General	6
2	Dimensions	6
3	AS-I Profile	6
4	Replacement Sequence.....	7
5	Parameterization Software, Keypad and App.....	7
6	DIP Switch Settings.....	8
7	Power Supply	9
8	Cross Reference	9
9	Parameter Cross Reference	12
10	References.....	15

Danger! - Dangerous electrical voltage!

- Disconnect the power supply of the device.
- Ensure that devices cannot be accidentally restarted.
- Verify isolation from the supply.
- Cover or enclose any adjacent live components.
- Follow the engineering instructions (AWA/IL) for the device concerned.
- Only suitably qualified personnel in accordance with EN 50110-1/-2 (VDE 0105 Part 100) may work on this device/system.
- Before installation and before touching the device ensure that you are free of electrostatic charge.
- The functional earth (FE, PES) must be connected to the protective earth (PE) or the potential equalization. The system installer is responsible for implementing this connection.
- Connecting cables and signal lines should be installed so that inductive or capacitive interference does not impair the automatic control functions.
- Suitable safety hardware and software measures should be implemented for the I/O interface so that an open circuit on the signal side does not result in undefined states.
- Deviations of the mains voltage from the rated value must not exceed the tolerance limits given in the specification, otherwise this may cause malfunction and/or dangerous operation.
- Emergency stop devices complying with IEC/EN 60204-1 must be effective in all operating modes. Unlatching of the emergency-stop devices must not cause a restart.
- Devices that are designed for mounting in housings or control cabinets must only be operated and controlled after they have been properly installed and with the housing closed.
- Wherever faults may cause injury or material damage, external measures must be implemented to ensure a safe operating state in the event of a fault or malfunction (e.g. by means of separate limit switches, mechanical interlocks etc.).
- Frequency inverters may have hot surfaces during and immediately after operation.
- Removal of the required covers, improper installation or incorrect operation of motor or frequency inverter may destroy the device and may lead to serious injury or damage.
- The applicable national safety regulations and accident prevention recommendations must be applied to all work carried on live frequency inverters.
- The electrical installation must be carried out in accordance with the relevant electrical regulations (e. g. with regard to cable cross sections, fuses, PE).
- Transport, installation, commissioning and maintenance work must be carried out only by qualified personnel (IEC 60364, HD 384 and national occupational safety regulations).
- Installations containing frequency inverters must be provided with additional monitoring and protective devices in accordance with the applicable safety regulations. Modifications to the frequency inverters using the operating software are permitted.
- All covers and doors must be kept closed during operation.
- To reduce the hazards for people or equipment, the user must include in the machine design measures that restrict the consequences of a malfunction or failure of the frequency inverter (increased motor speed or sudden standstill of motor). These measures include: – Other independent devices for monitoring safety related variables (speed, travel, end positions etc.).
 - Electrical or non-electrical system-wide measures (electrical or mechanical interlocks).
 - Never touch live parts or cable connections of the frequency inverter after it has been disconnected from the power supply. Due to the charge in the capacitors, these parts may still be alive after disconnection. Consider appropriate warning signs.

Disclaimer

The information, recommendations, descriptions, and safety notations in this document are based on Eaton's experience and judgment and may not cover all contingencies. If further information is required, an Eaton sales office should be consulted. Sale of the product shown in this literature is subject to the terms and conditions outlined in the applicable Terms and Conditions for Sale of Eaton or other contractual agreement between Eaton and the purchaser. THERE ARE NO UNDERSTANDINGS, AGREEMENTS, WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING WARRANTIES OF FITNESS FOR A PARTICULAR PURPOSE OR MERCHANTABILITY, OTHER THAN THOSE SPECIFICALLY SET OUT IN ANY EXISTING CONTRACT BETWEEN THE PARTIES. ANY SUCH CONTRACT STATES THE ENTIRE OBLIGATION OF EATON. THE CONTENTS OF THIS DOCUMENT SHALL NOT BECOME PART OF OR MODIFY ANY CONTRACT BETWEEN THE PARTIES. As far as applicable mandatory law allows so, in no event will Eaton be responsible to the purchaser or user in contract, in tort (including negligence), strict liability, or otherwise for any special, indirect, incidental, or consequential damage or loss whatsoever, including but not limited to damage or loss of use of equipment, plant or power system, cost of capital, loss of power, additional expenses in the use of existing power facilities, or claims against the purchaser or user by its customers resulting from the use of the information, recommendations, and descriptions contained herein. The information contained in this manual is subject to change without notice.

1 General

The following information indicates the differences that must be taken into account when expanding systems or creating new projects with RASP5 units, as well as when using them to replace RA-SP2... or RA-SPV... devices.

The devices have the following major differences:

- Dimensions
- Parameter software, parameters, keypad and app functionality
- DIP-Switches to parameter software - sensors and thermistor settings
- No AS-i connection required for RASP5 in manual mode
- AS-Interface profile

The controls' handling and functions remain the same. RASP5 combines the functionality of RA-SP2... and RA-SPV... in a single device. If required, the vector functionality can be activated via the parameters.

2 Dimensions

The dimensions of the RASP5 and RA-SP2... and RA-SPV... are different!

The detailed dimensions are given in the instruction leaflet listed in the reference.

3 AS-I Profile

Changing AS-I devices with different Profiles, requires extended engineering knowledge! RASP... units have AS-I profile S-7.E.0 (old) and AS-I profile S-7.4 (new). Due to the expanded AS-I profile, the scanner (gateway) needs to carry out a new initialization process if new RASP devices with profile S-7.4 are used as a replacement. To do this, the AS-I scanner needs to be switched to configuration mode. In this mode, the AS-I scanner will recognize the type and profile of the AS-I device connected to the AS-I cable. The profile is hardcoded into the device modules during production and cannot be changed. Refer to AS-I scanner documentation for the detailed information.

The Bit assignment of the AS-I control signals are not changed. However, depending the scanner or gateway which is used it could be that the bit assignment in the PLC can change (PLC tags or Variables)

**Notice!**

Make sure that the PLC (AS-I scanner) is supporting the new Device Profile S-7.4!

4 Replacement Sequence

Proceed following steps for a proper replacement.

1. Turn key and selector switch (FWD/REV) to '0' position (RA-SP and RASP5).
2. Read the parameter from RA-SP... (DrivesSoft).
3. Read the address from RA-SP... (with addressing device).
4. Note the DIP-positions of the RA-SP.
5. Disconnect motor-, energy-, AS-I -, sensor-, actor connectors from RA-SP...
6. Set parameters of the RASP5 accordingly (with keypad, app or drivesConnect)
7. Settings for the DIP switches must be transferred to RASP5 by parameter settings.
8. Connect all cables, connectors (line 400 V AC, AS-I, motor and sensors).
9. Ready to start.




Attention!

Before power on it must be ensured that the motor and the motor cable is properly connected.


5 Parameterization Software, Keypad and App

The table below shows the comparison of RA-SP... to RASP5 via PC software, PC cable, keypad and smartphone app.

	RA-SP / RA-SPV	RASP5
Parameterization PC Software	DrivesSoft 	drivesConnect 
Remote Keypad	DX-KEY-10 	DX-KEY-OLED 
PC - Connection	DEX-CBL-2M0-USB	DX-CBL-PC-3M0
		DX-COM-STICK-KIT (Bluetooth Stick)
Parameterization App	Not supported	Bluetooth Stick DX-COM-STICK3-KIT is required 

Connection cable DX-CBL-PC-3M0 and DX-COM-STICK-KIT allows communication and data exchange between RASP5 and a PC.

NOTICE: Connection cable, Keypad or Bluetooth Stick are not supplied with the RASP5. Those are optional articles.




The drivesConnect mobile App helps to connect smartphone to the RASP5. The parametrization and monitor information can be done by using the App (Android or IOS based). For detailed information refer to Appnote: **AP040189EN** in the [Overview Drives Appnotes](#)

Bluetooth connection to RASP5

6 DIP Switch Settings

The functionality of RA-SP... and RASP5 is the same. RA-SP... is generally set via parameters, but some special functions of RA-SP... are set via DIP switches. At RASP5 these settings are also made via parameters.

Functions	RA-SP- DIP Switches				RASP5 – Parameters
Motor cable monitoring	DIP 1				P2-27
AS-interface diagnostics	DIP 2				RASP5 includes a ASI bit for Healthy signal. This can not be deactivated.
Sensor inputs I3 and I4	DIP 3				P3-06 to P3-09
Quick stop and interlocked manual:	DIP 4	DIP 5	DIP 6		P1-13
	-	-	-		0
	OFF	OFF	OFF	->	1
	OFF	OFF	ON	->	2
	OFF	ON	OFF	->	3
	OFF	ON	ON	->	4
	ON	OFF	OFF	->	5
	ON	OFF	ON	->	6
	ON	ON	OFF	->	7
	ON	ON	ON	->	8
Phase reversal	DIP 7				P6-08
Stop behavior	DIP 8				P6-11

7 Power Supply

The previous models (e.g. RA-SP2-...) are supplied with power supply and AS-I connectors (M12 data bus). RASP5 is not supplied with power cable and AS-I data bus cable.

In the system where RA-SP2-... has to be replaced by RASP5, following accessory must be ordered separately:

- RA-C3/C2-1,5HF or RA-C3/C1-1,5HF
- RA-XM12-1M

8 Cross Reference

The RA-SP... cross-reference list to RASP5 can be found at the following table.

Date: 01.04.2020		RASP5																Accessories					Please note: The cross-marked accessories are required for the 1:1 exchange! X [®] OLED-Keypad or drivesConnect necessary (no DIP-switch parameterization)			
X [®] = successor, if 230 V brake is necessary X [®] = successor, if 400 V brake is necessary	Type	RASP5-2400A31-5120000S1	RASP5-2402A31-5120000S1	RASP5-2404A31-5120000S1	RASP5-2400A31-5120100S1	RASP5-2402A31-5120100S1	RASP5-2404A31-5120100S1	RASP5-4400A31-5120000S1	RASP5-4402A31-5120000S1	RASP5-4404A31-5120000S1	RASP5-4400A31-5120100S1	RASP5-4402A31-5120100S1	RASP5-4404A31-5120100S1	RASP5-5400A31-5120000S1	RASP5-5402A31-5120000S1	RASP5-5404A31-5120000S1	RASP5-5400A31-5120100S1	RASP5-5402A31-5120100S1	RASP5-5404A31-5120100S1	RA-C3/C1-1,5HF	RA-C3/C2-1,5HF	RA-XM1 2-1M		DX-KEY-OLED	drivesConnect	DX-CBL-PC-3M0
Type	Code	198542	198543	198544	198545	198546	198547	198554	198555	198556	198557	198558	198559	198566	198567	198568	198569	198570	198571	290210	290211	272057		169133	free	744-A3036-00P
RA-SP2-340-075/C1	254678	X																		X		X				
RA-SP2-340-075/C2	254680	X																			X	X				
RA-SP2-340-1K1/C1	272069							X												X		X				
RA-SP2-340-1K1/C2	272070							X													X	X				
RA-SP2-340-2K2/C1	254679													X						X		X				
RA-SP2-340-2K2/C2	254681													X							X	X				
RA-SP2-341(230)-075/C1	264317		X																	X		X				
RA-SP2-341(230)-075/C1-Q	101450		X																	X		X				
RA-SP2-341(230)-075/C2	264770		X																		X	X				
RA-SP2-341(230)-1K1/C1	268977								X											X		X				
RA-SP2-341(230)-1K1/C2	268978								X												X	X				
RA-SP2-341(230)-2K2/C1	272077													X						X		X				
RA-SP2-341(230)-2K2/C2	272078													X							X	X				
RA-SP2-341-075/C1	254682			X																X		X				
RA-SP2-341-075/C2	254683		X																		X	X				
RA-SP2-341-1K1/C1	267948								X											X		X				
RA-SP2-341-1K1/C2	264653								X												X	X				
RA-SP2-341-2K2/C1	254684															X				X		X				
RA-SP2-341-2K2/C2	254685															X					X	X				
RA-SP2-342-075/C1	272063	X																		X		X				
RA-SP2-342-075/C1-060	289245	X																		X		X				
RA-SP2-342-075/C2	272064	X																			X	X				
RA-SP2-342-075/C2-060	281724	X																			X	X				
RA-SP2-342-075/C3A	290405	X																								
RA-SP2-342-075/C3A-060	116955	X																								
RA-SP2-342-1K1/C1	272071							X												X		X				
RA-SP2-342-1K1/C1-060	289246							X												X		X				

Date: 01.04.2020			RASP5																		Accessories							
X ¹⁾ = successor, if 230 V brake is necessary X ²⁾ = successor, if 400 V brake is necessary	Type		RASP5-2400A31-5120000S1	RASP5-2402A31-5120000S1	RASP5-2404A31-5120000S1	RASP5-2400A31-5120100S1	RASP5-2402A31-5120100S1	RASP5-2404A31-5120100S1	RASP5-4400A31-5120000S1	RASP5-4402A31-5120000S1	RASP5-4404A31-5120000S1	RASP5-4400A31-5120100S1	RASP5-4402A31-5120100S1	RASP5-4404A31-5120100S1	RASP5-5400A31-5120000S1	RASP5-5402A31-5120000S1	RASP5-5404A31-5120000S1	RASP5-5400A31-5120100S1	RASP5-5402A31-5120100S1	RASP5-5404A31-5120100S1	RA-C3/C1-1.5HF	RA-C3/C2-1.5HF	RA-XM12-1M	DX-KEY-OLED	drivesConnect	DX-CBL-PC-3M0		
Type	Code		198542	198543	198544	198545	198546	198547	198554	198555	198556	198557	198558	198559	198566	198567	198568	198569	198570	198571	290210	290211	272057	169133	free	744-A3036-00P	Comment	
RA-SP2-342-1K1/C2	272072								X													X	X					
RA-SP2-342-1K1/C2-060	281515								X													X	X					
RA-SP2-342-1K1/C3A	290408								X																			
RA-SP2-342-1K1/C3A-060	116956								X																			
RA-SP2-342-2K2/C1	272079														X							X		X				
RA-SP2-342-2K2/C1-060	289247														X							X		X				
RA-SP2-342-2K2/C2	272080														X								X	X				
RA-SP2-342-2K2/C2-060	281516														X								X	X				
RA-SP2-342-2K2/C3A	290411														X													
RA-SP2-342-2K2/C3A-060	116957														X													
RA-SP2-343(230)-075/C1	272067		X																			X		X				
RA-SP2-343(230)-075/C1-060	283125		X																			X		X				
RA-SP2-343(230)-075/C2	272068		X																				X	X				
RA-SP2-343(230)-075/C2-060	285008		X																				X	X				
RA-SP2-343(230)-075/C3A	290407		X																									
RA-SP2-343(230)-075/C3A-060	116958		X																									
RA-SP2-343(230)-1K1/C1	272075									X												X		X				
RA-SP2-343(230)-1K1/C1-060	283127									X												X		X				
RA-SP2-343(230)-1K1/C2	272076									X													X	X				
RA-SP2-343(230)-1K1/C2-060	281518									X													X	X				
RA-SP2-343(230)-1K1/C3A	290410									X																		
RA-SP2-343(230)-1K1/C3A-060	116959									X																		
RA-SP2-343(230)-2K2/C1	272083															X						X		X				
RA-SP2-343(230)-2K2/C1-060	284383															X						X		X				
RA-SP2-343(230)-2K2/C2	272084															X							X	X				
RA-SP2-343(230)-2K2/C2-060	281517															X							X	X				
RA-SP2-343(230)-2K2/C3A	290413															X												
RA-SP2-343-075/C1	272065			X																		X		X				
RA-SP2-343-075/C2	272066			X																			X	X				
RA-SP2-343-075/C3A	290406			X																								
RA-SP2-343-1K1/C1	272073										X											X		X				
RA-SP2-343-1K1/C2	272074										X												X	X				
RA-SP2-343-1K1/C2-060	281519										X												X	X				
RA-SP2-343-1K1/C3A	290409										X																	
RA-SP2-343-2K2/C1	272081																X					X		X				
RA-SP2-343-2K2/C2	272082																X						X	X				
RA-SP2-343-2K2/C2-060	281540																X						X	X				
RA-SP2-343-2K2/C3A	290412																X											
RA-SP2-HE-342-075/C3A	290414	X																										
RA-SP2-HE-342-075/C3A-060	289112	X																										
RA-SP2-HE-342-075/C3A-061	113610	X																										
RA-SP2-HE-342-1K1/C2A-060	292315							X															X					

Date: 01.04.2020	RASP5																				Accessories					Please note: The cross-marked accessories are required for the 1:1 exchange! X³⁾ OLED-Keypad or drivesConnect necessary (no DIP-switch parameterization)														
X ¹⁾ = successor, if 230 V brake is necessary X ²⁾ = successor, if 400 V brake is necessary	Type	198542	198543	198544	198545	198546	198547	198554	198555	198556	198557	198558	198559	198566	198567	198568	198569	198570	198571	290210	290211	272057	169133	free	744-A3036-00P			Comment												
Type	Code																																							
RA-SP2-HE-342-1K1/C3A	290417							X																																
RA-SP2-HE-342-1K1/C3A-060	289114							X																																
RA-SP2-HE-342-1K1/C3A-061	113612							X																																
RA-SP2-HE-342-2K2/C2A-060	292318													X								X																		
RA-SP2-HE-342-2K2/C3A	290420													X																										
RA-SP2-HE-342-2K2/C3A-060	289116													X																										
RA-SP2-HE-342-2K2/C3A-061	113614													X																										
RA-SP2-HE-343(230)-075/C3A	290416		X																																					
RA-SP2-HE-343(230)-075/C3A-060	289113		X																																					
RA-SP2-HE-343(230)-075/C3A-061	113611		X																																					
RA-SP2-HE-343(230)-1K1/C2A-060	290396								X										X																					
RA-SP2-HE-343(230)-1K1/C3A	290419								X																															
RA-SP2-HE-343(230)-1K1/C3A-060	289115								X																															
RA-SP2-HE-343(230)-1K1/C3A-061	113613								X																															
RA-SP2-HE-343(230)-2K2/C2A-060	290397													X					X																					
RA-SP2-HE-343(230)-2K2/C3A	290343													X																										
RA-SP2-HE-343(230)-2K2/C3A-060	289117													X																										
RA-SP2-HE-343(230)-2K2/C3A-061	113615													X																										
RA-SP2-HE-343-075/C3A	290415			X																																				
RA-SP2-HE-343-1K1/C3A	290418								X																															
RA-SP2-HE-343-2K2/C3A	290344															X																								
RA-SPV-HE-342-1K1/C2A-060	292316									X									X																					
RA-SPV-HE-342-1K1/C3A-060	289150									X																														
RA-SPV-HE-342-1K1/C3A-061	113616									X																														
RA-SPV-HE-342-2K2/C2A-060	292319																	X				X																		
RA-SPV-HE-342-2K2/C3A-060	289152																	X																						
RA-SPV-HE-342-2K2/C3A-061	113617																	X																						
RA-SPV-HE-343(230)-075/C3A	106496					X																																		
RA-SPV-HE-343(230)-075/C3A-060	116954					X																																		
RA-SPV-HE-343(230)-1K1/C2A-060	292317											X								X							Additional 2 m AS-Interface cable necessary													
RA-SPV-HE-343(230)-1K1/C3A	106497											X																												
RA-SPV-HE-343(230)-1K1/C3A-060	289151											X																												
RA-SPV-HE-343(230)-1K1/C3A-061	113618											X																												
RA-SPV-HE-343(230)-2K2/C2A-060	290398																	X			X						Additional 2 m AS-Interface cable necessary													
RA-SPV-HE-343(230)-2K2/C3A	290341																	X																						
RA-SPV-HE-343(230)-2K2/C3A-060	289153																	X																						
RA-SPV-HE-343(230)-2K2/C3A-061	113619																	X																						
RA-SPV-HE-343-075/C3A	105014							X																																
RA-SPV-HE-343-1K1/C3A	105015												X																											
RA-SPV-HE-343-1K1/C3A	105015												X																											
RA-SPV-HE-343-2K2/C3A	290345																		X																					
DEX-KEY-10	231421																								X														RAMO5 and RASP5 only	
DrivesSoft	free																																	X					RAMO5 and RASP5 only	
DEX-CBL-2M0-PC	233184																																			X				RAMO5 and RASP5 only

9 Parameter Cross Reference

The most important parameters are listed below:

RA-SP				RASP5	
Identifier	Name	Description	ID	Description	Note
A01	SetpointSource	Selection of frequency set point source	P1-13	SEN Config Select	RASP has no potentiometer
A02	Startcommands	Selection of Start signal source	P1-13	SEN Config Select	Operation via keypad not possible
A03	f-Vmax	Base frequency	P1-09	Motor Nom Frequency	
A04	f-max	Maximum frequency (fmax)	P1-01	f-max	
A20	f-refKeypad	Frequency set point, frequency set point of the keypad (PNU A(0)01 must be 02)	P1-12	f-Fix1	
A21	f-Fix 1	Frequency set point, fixed frequency (1)	P2-01	f-Fix2	
A22	f-Fix 2	Frequency set point, fixed frequency (2)	P2-02	f-Fix3	
A23	f-Fix 3	Frequency set point, fixed frequency (3)	P2-03	f-Fix4	
A24	f-Fix 4	Frequency set point, fixed frequency (4)	P2-04	f-Fix5	
A25	f-Fix 5	Frequency set point, fixed frequency (5)	P2-05	f-Fix6	
A26	f-Fix 6	Frequency set point, fixed frequency (6)	P2-06	f-Fix7	
A27	f-Fix 7	Frequency set point, fixed frequency (7)	P2-07	f-Fix8	
A41	BoostMode	Voltage boost characteristics	P7-01	Motor Identification	
A42	V-Boost	Boost, voltage increase with manual boost	P7-03	Motor Stator Resistance R1	
A43	f-Boost	Boost, frequency for maximum boost	P1-11	V-Boost	
A44	V/f-Mode	V/f characteristic	P6-01	Motor Control Mode	
A45	V-max	V/f characteristic, output voltage	P1-07	Motor Nom Voltage	
A51	DC-Brake	DC braking	P4-04	t-DCBrake@Stop	Included in P4-04
A52	f-DCB-On	DC braking, starting frequency	P4-03	f-DCBrake@Stop	

A54	M-DCB	DC braking, braking torque	P4-01	DC-Brake Current	
A55	t-DCB	DC braking, braking duration	P4-04	t-DCBrake@Stop	
A92	t-acc 2	Acceleration time (2)	P2-11	t-acc2	
A93	t-dec 2	Deceleration time (2)	P2-13	t-dec2	
A95	f-acc 1-2	Acceleration time, change-over frequency from first to second acceleration time	P2-12	n-accMulti1	
A96	f-dec 1-2	Deceleration time, change-over frequency from deceleration time (1) to deceleration time (2)	P2-14	n-decMulti1	
A97	accMode	acceleration time, characteristic	P2-08	t-SRamp1	
A98	decMode	Deceleration time, characteristic	P2-08	t-SRamp1	
b12	I-OL	Thermal overload, tripping current	P1-08	Motor Nom Current	
b21	ImaxMotor	Motor current limitation, function	P6-10	Action @I-CurrentLimit	
b22	ImaxMotorLimit	Motor current limitation, tripping current	P6-04	M-Max Motoring	
b31	PNUAccess	Parameter lock (access right)	P2-33	Parameter Lock	
b83	f-PulseRate	Carrier frequency	P2-22	Switching Frequency	
C42	FA2accLevel	Output function, threshold value for the frequency message FA2 while acceleration	P3-02	Brake f-open	
C43	FA2decLevel	Output function, threshold value for the frequency message FA2 while deceleration	P3-03	Brake f-close	
F02	t-acc 1	Acceleration time 1	P1-03	t-acc	
F03	t-dec 1	Deceleration time 1	P1-04	t-dec	
d01	f-Out	Display output frequency	P0-07	Output Frequency	
d02	I-Out	Display output current	P0-09	Motor Current	
d05	DigiInState	Display status of digital inputs 1 to 6	P0-51	Input Data 1 Value	
d05_1	DigiIn1State	Display status of digital input 1	P0-51	Input Data 1 Value	

d05_2	DigiIn2State	Display status of digital input 2	P0-51	Input Data 1 Value	
d05_3	DigiIn3State	Display status of digital input 3	P0-51	Input Data 1 Value	
d05_4	DigiIn4State	Display status of digital input 4	P0-51	Input Data 1 Value	
d05_5	DigiIn5State	Display status of digital input 5	P0-51	Input Data 1 Value	
TRIP_cause1	TripHistory1Error	Error number	P0-13	Trip Log	
TRIP_cause2	TripHistory2Error	Error number	P0-13	Trip Log	
TRIP_cause3	TripHistory3Error	Error number	P0-13	Trip Log	
TRIP_counter	TripCounter	Counts errors since last power on.			
TRIP_Current1	TripHistory1I	Output current at trip	P0-40	MotorCurrent Log	
TRIP_Current2	TripHistory2I	Output current at trip	P0-40	MotorCurrent Log	
TRIP_Current3	TripHistory3I	Output current at trip	P0-40	MotorCurrent Log	
TRIP_DCBusVoltage1	TripHistory1DC	DC-Link voltage at trip. Displayed in 0,1 V/digit (DF5..6-322) respectively 0,2 V/digit (DF5..6-340)	P0-37	DC-Link V-Ripple Log	
TRIP_DCBusVoltage2	TripHistory2DC	DC-Link voltage at trip. Displayed in 0,1 V/digit (DF5..6-322) respectively 0,2 V/digit (DF5..6-340)	P0-37	DC-Link V-Ripple Log	
TRIP_DCBusVoltage3	TripHistory3DC	DC-Link voltage at trip. Displayed in 0,1 V/digit (DF5..6-322) respectively 0,2 V/digit (DF5..6-340)	P0-37	DC-Link V-Ripple Log	

10 References

Documentation			
	RAMO 4.0	RAMO5	LINK
Manual	AWB2190-1430E	MN034004EN	DownloadCenter
Instruction Leaflet	AWB2190-1430E	IL034085ZU	DownloadCenter
Application Note - Parametrisation per Bluetooth	-	AP040189EN	Drives AP Note Overview Document http://www.eaton.com/ap/overview/drives
PowerXL Device Firmware Update	-	AP040214EN	Drives AP Note Overview Document http://www.eaton.com/ap/overview/drives



Notice!

Follow the engineering instructions (AWA/AWB or IL/MN) for the device concerned.

Eaton is dedicated to ensuring that reliable, efficient and safe power supply is available when it is needed most. With vast of energy management across different industries, experts at Eaton deliver customized, integrated solutions to solve our customer' most critical challenges.

Our focus is on delivering the right solution for the Application. But decision makers demand more than just Innovative products. They turn to Eaton for an unwavering Commitment to personal support that makes customer Success a top priority. For more information, visit [Eaton.com](https://www.eaton.com)

Eaton addresses worldwide:

[Eaton.com/us/en-us/locate/global-locations.html](https://www.eaton.com/us/en-us/locate/global-locations.html)

Eaton Industries GmbH
Hein-Moeller-Str. 7- 11
D-53115 Bonn/Germany

® 2020 Eaton
All Rights Reserved
Publication No. AP040196EN

Eaton is a registered trademark
All other trademarks are property
of their respective owners