Niko Rocker for single switch functions, alu ganache

222-56001

4 year warranty

The Niko Rocker clicks onto the switch part of the single switch function. Click the Rocker set onto the function before you click the Niko Rocker faceplate into place.

The Niko Rocker consists of a click connector made out of high grade, durable plactic that permanently fixes the lever. The lever is made of .

- Exclusive materials
- Metal controls
- Authentic vintage design
- Belgian design & craftsmanship
- Proven Niko quality
- Unique illuminated switch design (by adding feedback LED)

Technical data

Niko Rocker for single switch functions, alu ganache.

- Number of buttons: 1
- Type of control: switch or push button
- Colour: alu ganache
- Number of lenses: 0
- Marking: CE