




Pos.	Signify	Spare parts-Nr.	Quantity	Pos.	Signify	Spare parts-Nr.	Quantity
1	Lever	B961852AA	1 Set				
2	Rubber button	A963751NU	1 Pcs.				
3	Rosette M41x1.5	B961386AA	1 Pcs.				
4	Screw M41x1.5/M46x1.5	B961387NU	1 Set				
5	Hot limit stop	A861181NU	1 Pcs.				
6	Cartridge Ø38mm	A861156NU*	1 Set				
7	Pull knob	B960486AA	1 Pcs.				
8	Casc.perlator M24x1-D	A960537AA	1 Pcs.				
9	Diverter automatic	B960167AA	1 Set				
10	Non-return valve	A960944NU	2 Pcs.				
11	S-connections	B960241AA	1 Set				
12	Sh.hose L1500mm	BF150AA	1 Pcs.				
13	Hand shower 80mm, 1F	B9400AA	1 Pcs.				

*Universal set (not all parts needed)