



Module overview



Audio module




Audio/Video module 130




Audio/Video Module 180


Welcome




Keypad module




Fingerprint module




Round pushbutton module



Round pushbutton module with RFID/IC



Bar pushbutton module 3/6




Bar pushbutton module 4/8




Infomodul

Welcome & Welcome IP



Touch 5 module




Audio/Video module

Welcome IP


Audio Outdoor Station frame (unit: mm)

Welcome




Video Outdoor Station frame (unit: mm)



Welcome & Welcome IP





Surface-mounted box (unit: mm)




Hole size of the flush-mounted box (unit: mm)




Hole size of the pre-mounted box (unit: mm)






Preparation of installation


Use gloves to protect yourself against cuts.




Mounting modules



Connecting modules




Installation height



Surface-mounted with surface-mounted box


PartA-1



Continue Part B

Flush-mounted without pre-mounted box


PartA-2



Continue Part B


Mounting the front cover

Part B



Flush-mounted with pre-mounted box


PartA-3



Continue Part B


Cavity wall installation

PartA-4




Continue Part B


Dismantle single column Outdoor Station



Dismantle the modules



Dismantle the name lable



Replace the nameplate

