Adaptive Evacuation

AE-CU Interface

Relay module



Relay module

Information units ,scenario active' and ,fault' are reported to the ZB-S by the AE-CU via the relay module (installed in a ZB-S/US-S). Six ZB-S/US-S can be connected per AE-CU. More on request.

Ordering details

Туре	Scope of supply	Order No.
Relay module	Relay module connection set for use per ZB-S/US-S for connection to a AE-CU	40071361422

^{*}Note: Relay module must be mounted externally at sub stations with functional integrity.