



BC 851 .. BC 852 ..		BC 853 .. BC 854 ..	
Pos.	Part No.	Pos.	Part No.
1	A 861 451 XX	1	A 861 451 XX
2	A 861 420 XX	2	A 861 420 XX
3	A 861 397 NU	3	A 861 397 NU
4	A 960 197 NU	4	A 960 197 NU
5	A 960 486 NU	5	A 960 486 NU
6	B 960 900 XX	6	B 960 900 XX
7	A 961 172 NU	7	A 961 172 NU
8	A 962 370 NU	8	A 960 364 NU
9	A 961 230 XX	9	A 961 230 XX





Ideal Standard

Joy








BC 851 .. BC 852 ..
BC 853 .. BC 854 ..

0324 / A 868 675



Ideal Standard International NV
Corporate Village – Gent Building
Da Vincilaan 2
1935 Zaventem
Belgium
<https://www.idealstandard.com>





 P	bar	 0,5	 1 	Q (3 bar) 
 T	°C	 MAX. 85	 65 40 	l/min 5