

Double key with 'I' and 'O' symbols for wireless switch or push button with 4 control buttons, cream

100-00008



A double key with the symbol "I" and "O" for a bus push button with 4 control buttons.
Colour: cream.

Technical data

Double key with 'I' and 'O' symbols for wireless switch or push button with 4 control buttons, cream.



- Number of buttons: 4
- Material finishing: polycarbonate (PC) + acrylic-styrene-acrylate (ASA)
- Type of control: push button
- Colour: cream
- Colour RAL (approximately): 1013
- Colour NCS (approximately): NCS S 1005-Y10R
- Surface treatment: coloured in mass
- Imprint indication: each key on the central plate is printed with the symbols "I" and "O" in indelible print
- Number of lenses: 0
- Dismantling method: pull the central plate off the mechanism
- Protection degree: IP41 for the combination of a mechanism, central plate and faceplate
- Impact resistance: after mounting, an impact-resistance of IK06 is guaranteed
- Fire safety:
 - all plastic components are self-extinguishing (comply with a filament test of 650°C)
 - all plastic components are halogen-free
- Dimensions of finishing: 45 x 45 mm (HxW)
- Dimensions (HxWxD): 44.5 mm x 44.5 mm x 8.6 mm
- Marking: CE