



## Montagehandleiding Instructions de montage Montagehinweis Mounting instructions




TYPE	02	03	04	06	08	10
A	82.5	82.5	110.0	110.0	137.5	165.0
B	23.0	23.0	23.0	23.0	27.5	27.5
C	4.5	4.5	4.5	4.5	4.5	4.5
D	15.3	15.3	15.3	15.3	22.5	22.5
E	45.5	45.5	45.5	45.5	46.3	46.3
F	25.5	25.5	25.5	25.5	26.0	26.0
G	55.7	55.7	83.2	83.2	110.7	138.2
K	9.0	9.0	9.0	9.0	9.5	9.5
L	19.8	19.8	19.8	19.8	24.0	24.0
M	28.0	28.0	28.0	28.0	31.5	31.5
N	48.0	48.0	48.0	48.0	48.0	48.0

De warmtewisselaar is omkeerbaar (aansluiting rechts)  
L'échangeur de chaleur est renversible (raccordement à droit)  
Der Wärmetauscher ist umkehrbar (Anschluss rechts)  
The heat exchanger is reversible (connection right)


### > AFMETINGEN > DIMENSIONS > ABMESSUNGEN > DIMENSIONS



- > BEKLEDING AFNEMEN
- > ENLEVER L'HABILLAGE
- > VERKLEIDUNG ENTFERNEN
- > TAKE OFF THE CASING




- > OMKEERBAAR ROOSTER
- > GRILLE REVERSABLE
- > UMKEHRBARER ROST
- > REVERSIBLE GRILLE




- > FILTER UITNEMEN
- > ENLEVER LE FILTRE
- > FILTER ENTFERNEN
- > TAKING OUT THE FILTER


# BRIF Brise Freestanding



- > MONTAGE VOETEN
- > MONTAGE DES PIEDS
- > MONTAGE DER FÜSSE
- > MOUNTING THE FEET





## Montagehandleiding Instructions de montage Montagehinweis Mounting instructions




### > AFMETINGEN > DIMENSIONS > ABMESSUNGEN > DIMENSIONS

TYPE	02	03	04	06	08	10
A	82.5	82.5	110.0	110.0	137.5	165.0
B	23.0	23.0	23.0	23.0	27.5	27.5
C	4.5	4.5	4.5	4.5	4.5	4.5
D	15.3	15.3	15.3	15.3	22.5	22.5
E	45.5	45.5	45.5	45.5	46.3	46.3
F	25.5	25.5	25.5	25.5	26.0	26.0
G	55.7	55.7	83.2	83.2	110.7	138.2
K	9.0	9.0	9.0	9.0	9.5	9.5
L	19.8	19.8	19.8	19.8	24.0	24.0
M	28.0	28.0	28.0	28.0	31.5	31.5
N	48.0	48.0	48.0	48.0	48.0	48.0


- > De warmtewisselaar is omkeerbaar (aansluiting rechts)
- > L'échangeur de chaleur est renversible (raccordement à droit)
- > Der Wärmetauscher ist umkehrbar (Anschluss rechts)
- > The heat exchanger is reversible (connection right)



- > OMKEERBAAR ROOSTER
- > GRILLE RENVERSABLE
- > UMKEHRBARER ROST
- > REVERSIBLE GRILLE





- OPTION 87740.
- > NAAR BENEDEN BLAZEND
- > SOUFLAGE VERS LE BAS
- > NACH UNTEN BLAZEND
- > EXHAUST DOWNWARDS



- \*Het toestel licht kantelen om de afvoer van het condenswater te bevorderen.
- \*Légèrement incliner l'appareil afin de faciliter l'écoulement du condensat.
- \*Das Gerät leicht abschüssig montieren zum befördern des Kondensatablaufs.
- \*Fit the apparatus with a slight inclination to facilitate the drainage of the condensation water.

- > BEKLEDING AFNEMEN
- > ENLEVER L'HABILLAGE
- > VERKLEIDUNG ENTFERNEN
- > TAKE OFF THE CASING



- > FILTER UITNEMEN
- > ENLEVER LE FILTRE
- > FILTER ENTFERNEN
- > TAKING OUT THE FILTER