



Spare Parts / Ersatzteile / Pièces de recharge / Pezzi di Ricambio / Piezas de requesto /
Parte de reposição / Reserveonderdelen / Reservdelar / Reservedeler / Varaosat /
Vraosat / Varahlutir / Ανταλλακτικά / Yedek Parçalar / Náhradní díly / Náhradné diely /
Nadomestni deli / Резервни части / Запчасти / Części Zapasowe / Piese de schimb
/ Rendelhet ő alkatrészek / Запасні частини / Reservni delovi / Резервни дел ови /
Резервни дел ови / Atsargini ū dali ū / Tellitavad varuosad / Rezervju daļu




Ideal Standard

IOM




A 9119 **

1115 / MTAc A9119





Position



- 1 = A 963 280 **
- 2 = A 963 281 NU
- 3 = A 963 259 **





Ideal Standard International NV
Corporate Village - Gent Building
Da Vincilaan 2
1935 Zaventem
Belgium
www.idealstandardinternational.com



1



2



3

