


Overview



-2-

Operation



Accepting a call:
Lift the handset and speak.



Ending a call:
Replace the handset.



Open a door:
Press the button.

-3-



Switching the corridor lights on:
Press the button.



Activating the mute function of the microphone during the conversation:
Press the button.



Activating the mute function of the ring tone:
Press the button.

-4-

Setting the volume of the call tone



» Press the button longer than 5 seconds to change to setting mode.
» All icons light up green.



» Lift handset.



» Press the button.
» A test tone sounds on the device.
» Press the button again until the desired volume is set (5 stages).



» Press the button longer than 3 seconds to finish.
» The icons are off.

-5-

If you need help

For additional information please read the detailed operating manual. The manual is available as download on our website. Scan the QR code with your smartphone/tablet or open the following site in the browser:




www.busch-jaeger-katalog.de/8300-0-0001,artikel.html



For further questions please contact:
+49-2351-956-1600



Setting the bell sound of the front door

-  » Press the button longer than 5 seconds to change to setting mode.
» All icons light up green.
-  » Press the button with handset replaced. A bell tone sounds.
» Press the button again until the desired bell tone sounds (5 tones).
-  » Press the button longer than 3 seconds to finish.
» The icons are off.

Setting the bell sound of the floor door




-  » Press the button longer than 5 seconds to change to setting mode.
» All icons light up green.
-  » Press the button with handset replaced. A bell tone sounds.
» Press the button again until the desired bell tone sounds (5 tones).
-  » Press the button longer than 3 seconds to finish.
» The icons are off.

ABB-Welcome 83205-AP-xxx

Indoor audio station with handset Brief instructions

