

—  
INSTALLATION INSTRUCTION


# Mechanical interlock

## OETLZW3, -14, -15





# OETLW3, -14, -15





---

## Contact us

### **ABB Oy**

Muottitie 2A 65320

Vaasa, Finland

**[abb.com/lowvoltage](http://abb.com/lowvoltage)**