


## Rosette Ø 40,5 x 11 mm - Brushed Durabrand (23kt Gold)

## SPARE PARTS

90 27 97 506 00



|                                                                                     |                                     |                    |
|-------------------------------------------------------------------------------------|-------------------------------------|--------------------|
|    | Brushed<br>Durabrand (23kt<br>Gold) | 90 27 97 506 00-28 |
|    | Chrome                              | 90 27 97 506 00-00 |
|    | Brushed Platinum                    | 90 27 97 506 00-06 |
|    | Platinum                            | 90 27 97 506 00-08 |
|    | Durabrand (23kt<br>Gold)            | 90 27 97 506 00-09 |
|    | Dark Chrome                         | 90 27 97 506 00-19 |
|    | Brushed Light Gold<br>(PVD)         | 90 27 97 506 00-27 |
|    | Matte Black                         | 90 27 97 506 00-33 |
|    | Brushed Bronze<br>(PVD)             | 90 27 97 506 00-42 |
|   | Brushed<br>Champagne (22kt<br>Gold) | 90 27 97 506 00-46 |
|  | Champagne (22kt<br>Gold)            | 90 27 97 506 00-47 |
|  | Brushed Chrome                      | 90 27 97 506 00-93 |
|  | Brushed Dark<br>Platinum            | 90 27 97 506 00-99 |



## Rosette Ø 40,5 x 11 mm - Brushed Durabrass (23kt Gold)

---

SPARE PARTS

90 27 97 506 00



## Rosette Ø 40,5 x 11 mm - Brushed Durabronz (23kt Gold)

SPARE PARTS

90 27 97 506 00