


Soap dish Ø 120 x 20 mm - Light Gold (PVD)

SPARE PARTS

08 17 97 570



	Light Gold (PVD)	08 17 97 570-26
	Chrome	08 17 97 570-00
	Brushed Platinum	08 17 97 570-06
	Platinum	08 17 97 570-08
	Durabronze (23kt Gold)	08 17 97 570-09
	Matte White	08 17 97 570-10
	Dark Chrome	08 17 97 570-19
	Brushed Light Gold (PVD)	08 17 97 570-27
	Brushed Durabronze (23kt Gold)	08 17 97 570-28
	Matte Black	08 17 97 570-33
	Brushed Dark Brass (PVD)	08 17 97 570-39
	Brushed Bronze (PVD)	08 17 97 570-42
	Brushed Champagne (22kt Gold)	08 17 97 570-46
	Champagne (22kt Gold)	08 17 97 570-47
	Brushed Chrome	08 17 97 570-93
	Brushed Dark Platinum	08 17 97 570-99



Soap dish Ø 120 x 20 mm - Light Gold (PVD)

SPARE PARTS

---

08 17 97 570



Soap dish Ø 120 x 20 mm - Light Gold (PVD)

SPARE PARTS

---

08 17 97 570