

IR remote control for users

351-25310



AUTO: Activate automatic mode

- Press this button to activate the automatic mode.

ON: Switch on light for 6 hours

- Press this button to switch the light on constantly for 6 hours. After that time, the detector resumes its automatic operation. Please note: this button cannot be used if the TIME setting is on pulse.

OFF: Switch off light for 6 hours

- Press this button to switch the light off completely for 6 hours. After that time, the detector resumes its automatic operation. Please note: this button cannot be used if the TIME setting is on pulse.

Compatible articles: 351-25050, 351-25065, 351-25340, 351-25451, 351-25457, 351-25463, 351-25467, 351-25475, 351-26450, 351-26470, 351-26480, 351-26560, 351-26562, 351-26570, 351-26572

- Easy detector control with remote control
- Ideal for end users

Choice of operation:

AUTO = automatic operation (default)

ON = light permanently on for 6h*

OFF = light permanently off for 6h

Technical data

AUTO: Activate automatic mode

- Press this button to activate the automatic mode.

ON: Switch on light for 6 hours



- Press this button to switch the light on constantly for 6 hours. After that time, the detector resumes its automatic operation. Please note: this button cannot be used if the TIME setting is on pulse.

OFF: Switch off light for 6 hours

- Press this button to switch the light off completely for 6 hours. After that time, the detector resumes its automatic operation. Please note: this button cannot be used if the TIME setting is on pulse.

Compatible articles: 351-25050, 351-25065, 351-25340, 351-25451, 351-25457, 351-25463, 351-25467, 351-25475, 351-26450, 351-26470, 351-26480, 351-26560, 351-26562, 351-26570, 351-26572

- Compatible articles: 351-25050, 351-25065, 351-25340, 351-25451, 351-25457, 351-25463, 351-25467, 351-25475, 351-26450, 351-26470, 351-26480, 351-26560, 351-26562, 351-26570, 351-26572
- Impact resistance: IK02
- Marking: CE

Dimensions

