


















Holder for soap dish 60 x 34 x 20 mm - Brushed Bronze (PVD)

SPARE PARTS

08 17 30 502



	Brushed Bronze (PVD)	08 17 30 502-42
	Chrome	08 17 30 502-00
	Brushed Platinum	08 17 30 502-06
	Platinum	08 17 30 502-08
	Durabronze (23kt Gold)	08 17 30 502-09
	Matte White	08 17 30 502-10
	Dark Chrome	08 17 30 502-19
	Light Gold (PVD)	08 17 30 502-26
	Brushed Light Gold (PVD)	08 17 30 502-27
	Brushed Durabronze (23kt Gold)	08 17 30 502-28
	Matte Black	08 17 30 502-33
	Brushed Dark Brass (PVD)	08 17 30 502-39
	Brushed Champagne (22kt Gold)	08 17 30 502-46
	Champagne (22kt Gold)	08 17 30 502-47
	Brushed Chrome	08 17 30 502-93
	Brushed Dark Platinum	08 17 30 502-99



Holder for soap dish 60 x 34 x 20 mm - Brushed Bronze (PVD)

SPARE PARTS

08 17 30 502



Holder for soap dish 60 x 34 x 20 mm - Brushed Bronze (PVD)

SPARE PARTS

08 17 30 502