



—
INSTALLATION INSTRUCTION

Auxiliary contact

OEZNP3



OEZNP3





Contact us

ABB Oy

Muottitie 2A 65320

Vaasa, Finland

abb.com/lowvoltage