



—
INSTALLATION INSTRUCTION

Cable entry plate


OEZXP_120C...380C




OEZXP_120C...380C




A00196A



OEZXP_120C...380C



A00193A



A00195A



Contact us

ABB Oy

Muottitie 2A 65320

Vaasa, Finland

abb.com/lowvoltage