

Rosette for mixer 80 x 80 x 9 mm - Brushed Bronze (PVD)

SPARE PARTS

09 27 78 048



	Brushed Bronze (PVD)	09 27 78 048-42
	Chrome	09 27 78 048-00
	Brushed Platinum	09 27 78 048-06
	Platinum	09 27 78 048-08
	Brushed Durabronze (23kt Gold)	09 27 78 048-28
	Brushed Dark Bronze (PVD)	09 27 78 048-39
	Brushed Dark Bronze (PVD)	09 27 78 048-43
	Brushed Champagne (22kt Gold)	09 27 78 048-46
	Champagne (22kt Gold)	09 27 78 048-47
	Brushed Chrome	09 27 78 048-93
	Brushed Dark Platinum	09 27 78 048-99



Rosette for mixer 80 x 80 x 9 mm - Brushed Bronze (PVD)

SPARE PARTS

09 27 78 048



Rosette for mixer 80 x 80 x 9 mm - Brushed Bronze (PVD)

SPARE PARTS

09 27 78 048