

Rosette Push-on rosette - Chrome

SPARE PARTS

90 27 01 015 00



	Chrome	90 27 01 015 00-00
	Brushed Dark Brass (PVD)	90 27 01 015 00-39
	Brushed Bronze (PVD)	90 27 01 015 00-42
	Brushed Dark Platinum	90 27 01 015 00-99



Rosette Push-on rosette - Chrome

SPARE PARTS

90 27 01 015 00



Rosette Push-on rosette - Chrome

SPARE PARTS

90 27 01 015 00