

**Rosette for washstand deck-mounted spout without pop-up waste 60 x 60 x 9
mm - Brushed Dark Brass (PVD)**

SPARE PARTS

09 27 78 034



	Brushed Dark Brass (PVD)	09 27 78 034-39
	Chrome	09 27 78 034-00
	Brushed Platinum	09 27 78 034-06
	Platinum	09 27 78 034-08
	Brushed Light Gold (PVD)	09 27 78 034-27
	Brushed Durabrass (23kt Gold)	09 27 78 034-28
	Brushed Bronze (PVD)	09 27 78 034-42
	Brushed Dark Bronze (PVD)	09 27 78 034-43
	Brushed Champagne (22kt Gold)	09 27 78 034-46
	Champagne (22kt Gold)	09 27 78 034-47
	Cyprus	09 27 78 034-49
	Brushed Chrome	09 27 78 034-93
	Brushed Dark Platinum	09 27 78 034-99



Rosette for washstand deck-mounted spout without pop-up waste 60 x 60 x 9
mm - Brushed Dark Brass (PVD)

SPARE PARTS

09 27 78 034



Rosette for washstand deck-mounted spout without pop-up waste 60 x 60 x 9
mm - Brushed Dark Brass (PVD)

SPARE PARTS

09 27 78 034