


# SPARE PARTS

PROSYS ECO FRAME



# SPARE PARTS

PROSYS ECO FRAME

REP.	CODE	DESCRIPTION
1	RV16667	Prosys Service Tunnel
2	RV25767	Lever Block For Eco Frame
3	RV25867	Eco Control Plate Fixers & Cist Holders (x2)
4	RV16967	Prosys 150, Eco & 2.0 Stop Valve
5	RV25967	Inlet Valve Connection Hose For Eco
6	RV26167	Inlet Valve Support For Eco Frame
7	RV26267	Inlet Valve Delayed Fill For Eco
8	RV26367	Maintenance KIT For Eco Inlet Valve
9	RV26467	Prosys 150 & Eco Flush Pipe O Ring Ø55 (x5)
10	RV26567	Flush Pipe For Eco Frame
	RV17567	Prosys 150 & Eco Freestanding Flush Pipe
11	RV21867	Prosys Flush Pipe Seal For 150, 80 & Eco Ø40/45 (x5)
12	RV26667	Prosys Flush Valve For Eco Frame
13	RV15567	Prosys Outlet Valve Seal 150, 80 & Eco Including Eco 2.0 (x 12)
A1	RV17767	Prosys 120 EasyFix Wall Bracket L=181mm For Wall Depth 150 > 210mm; Can be used with E2332, E2333, R0350, R0358, R0380.
A2	RV27967	Additional Optional Wall Brackets For R0427 Prosys Eco NF Frame
B	RV27167	Prosys WC Bowl Fixation Rods M12 (x2)
C	R0201AC	Prosys WC Fixings Protective Caps White
	R0201AA	Prosys WC Fixings Protective Caps Chrome
D	RV19967	Prosys Flush Pipe 180mm x Ø45 Including Seal
E	RV26767	Prosys Flush Pipe Connection Seal To WC (x5)
F	RV18267	Prosys WC Connection Pipe Ø90x250
G	RV18367	Prosy Rubber Seal For WC Bowl Ø125
H1	RV17867	Prosys Wall & Floor Fixation Screws (x4) For Standard WC Frames
H2	RV17967	Prosys Floor Fixation KIT For Freestanding WC Frame (x4)
I	RV18167	Prosys Outlet Bend Adaptor 90/110
	RV21767	Prosys Outlet Bend Adaptor 90/100 PVC
J	RV18067	Prosys Outlet Bend 90 x 90mm
	RV21667	Prosys Outlet Bend 90 x 100mm (FR)
	RV22567	Prosys Outlet Bend 90 x 110mm
K	RV27267	Prosys Fixed Outlet Bend Support For Eco Standard Frame
	RV19167	Prosys WC Frame Adjustable Outlet Support For Freestanding Eco Frame

Ideal Standard International NV  
Corporate Village – Gent Building  
Da Vincilaan 2  
B1935 – Zaventem  
Belgium



BE +32 (0)2 325 66 33  
BG +359 675 30362  
DE +49 (0)228 521 580  
EG +202 26969700  
FR +33 (0)1 49 38 28 00  
GB 01482 496 318  
GR +30 210 67 90 810  
HR +38591 22 99 304

HU +36 30 6991 594  
IT 800 652 290  
ME +971 4 804 2400  
NL +31 (0)77 355 08 08  
PL +48 71 7868 301/302  
RO +40 21 3223 201/202  
SI 00386 59 919040  
TR +90 216 314 87 87

UA +359 675 30 468  
AL/XK/BA +359 887 709 696  
CZ/SK +420 417 592 179  
DK/NO/SE +45 75 84 10 10  
ES/PT +34 93 561 80 00  
LV/LT/EE +371 673 57 792  
RS/MK/ME +381 11 713 80 58  
RU/MD +7 495 669 23 11

