


—
INSTALLATION INSTRUCTION

Fourth pole

OTP_125FP, OTP_125MP





Contact us

ABB Oy

Muottitie 2A 65320

Vaasa, Finland

abb.com/lowvoltage