


—
INSTALLATION INSTRUCTION

Switch Conversion kits OETLZW_




OETLZW11, 12, 13

Change-over mechanism


OETLZW11

OT315...400
OS315...400



OETLZW12


OT315...800E
OT600U
OS315...400




By-pass mechanism

OETLZW13

OT315...800E
OT600U
OS315...400




OETLZW11, 12, 13




1,2 Nm
11 lb.in

OETLZW 11




18,5 min /
22 max


S01707B1

OETLZW 12
OETLZW 13

14




S01707B3




Change over function

OETLZW11, 12




By-pass function
OETLZW13




Dimension drawing

OETLZW11, 12, 13



S00116B

	A	B	C
OETLZW 11	210+(0...11)x20 mm		12



S00117B

	A	B	D
OETLZW 12	210+(0...18)x20 mm		220 mm
OETLZW 13	210+(0...18)x20 mm	250+(0...18)x20 mm	320 mm



Contact us

ABB Oy

Muottitie 2A 65320

Vaasa, Finland

abb.com/lowvoltage