


—  
INSTALLATION INSTRUCTION









## Cover plate

### OMZC2








# OMZC2

## IP54



# OMZC2

## IP54





---

## Contact us

### **ABB Oy**

Muottitie 2A 65320

Vaasa, Finland

**[abb.com/lowvoltage](http://abb.com/lowvoltage)**