






Pull button for pop-up waste - Brushed Light Gold (PVD)

SPARE PARTS

09 20 71 031



	Brushed Light Gold (PVD)	09 20 71 031-27
	Chrome	09 20 71 031-00
	Brushed Platinum	09 20 71 031-06
	Brushed Dark Platinum	09 20 71 031-99



Pull button for pop-up waste - Brushed Light Gold (PVD)

SPARE PARTS

09 20 71 031



Pull button for pop-up waste - Brushed Light Gold (PVD)

SPARE PARTS

09 20 71 031