

Pull button for pop-up waste Ø 15 x 37 mm - Brushed Light Gold (PVD)

SPARE PARTS

09 20 01 040



	Brushed Light Gold (PVD)	09 20 01 040-27
	Chrome	09 20 01 040-00
	Dark Chrome	09 20 01 040-19
	Light Gold (PVD)	09 20 01 040-26
	Brushed Durabronze (23kt Gold)	09 20 01 040-28
	Matte Black	09 20 01 040-33
	Brushed Dark Brass (PVD)	09 20 01 040-39
	Brushed Bronze (PVD)	09 20 01 040-42
	Brushed Champagne (22kt Gold)	09 20 01 040-46
	Champagne (22kt Gold)	09 20 01 040-47
	Brushed Chrome	09 20 01 040-93
	Brushed Dark Platinum	09 20 01 040-99



Pull button for pop-up waste Ø 15 x 37 mm - Brushed Light Gold (PVD)

SPARE PARTS

09 20 01 040



Pull button for pop-up waste Ø 15 x 37 mm - Brushed Light Gold (PVD)

SPARE PARTS

09 20 01 040