


Selecteer de TacoSetter met het juiste instelbereik.

Instel-meetbereik	0,3	0,6	1	1,5	2	2,4	3	3,5	4	6	7,5	8	10	12	15	16	20	28	30	40	90							
TacoSetter Inline 100																												
23-1202 223.1232.104	0,3—1,5 l/min																											
23-1203 23-1233 223.1233.104	0,6—2,4 l/min																											
23-1204 23-1234 223.1204.104 223.1234.104	1—3,5 l/min																											
23-1208 23-1238 223.1208.104 223.1238.104	2—8 l/min																											
23-1209 23-1239 223.1209.104	3—12 l/min																											
23-1300	4—15 l/min																											
23-1302	8—30 l/min																											
23-1305	10—40 l/min																											
TacoSetter Inline 130																												
601.07234.104	1—3,5 l/min																											
601.07238.104	2—8 l/min																											
601.07318.000	1,5—7,5 l/min																											
601.07310.000	4—15 l/min																											
601.07312.000	10—30 l/min																											
601.07370.000	4—15 l/min																											
601.07378.000	10—40 l/min																											
223.7556.334	1,5—6 l/min																											
223.7566.334	4—16 l/min																											
223.7576.334	8—28 l/min																											
223.7586.000	10—40 l/min																											
601.07427.000	20—90 l/min																											
601.07457.000	20—90 l/min																											
601.07467.000	20—90 l/min																											
TacoControl Flowmeter (alleen meetbereik)																												
23-4213	0,6—2,4 l/min																											
23-4214	1—3,5 l/min																											
23-4218	2—8 l/min																											
23-4219	3—12 l/min																											
TacoSetter Rondo																												
23-3206 223.3206.325 223.3206.341	0,6—8 l/min																											



Afbeeldingen zijn indicatief. De maatvoering en aansluiting kan afwijken per artikel.

Selecteer de TacoSetter met het juiste instelbereik.

Instel-meetbereik	2	4	6	8	10	12	15	20	25	30	40	50	55	60	70	75	80	100	120	200	325	450	650										
TacoSetter Bypass 100																																	
23-1262 23-1361 23-1272	2—8 l/min																																
23-1360 23-1370	4—15 l/min																																
23-1362 23-1372				8—30 l/min																													
23-1460 23-1470				6—20 l/min																													
23-1461 23-1471				10—40 l/min																													
23-1561 23-1571							20—70 l/min																										
23-1661										30—120 l/min																							
23-1861													50—200 l/min																				
TacoSetter Bypass 130																																	
23-1380 223.2380.350	2—12 l/min																																
23-1381 223.2381.350				8—20 l/min																													
23-1482 223.2482.350				10—40 l/min																													
TacoSetter Bypass 185																																	
223.2382.000 223.2382.385	2—12 l/min																																
223.2383.000 223.2383.385				8—30 l/min																													
223.2480.000				10—40 l/min																													
223.2580.000							20—70 l/min																										
TacoSetter Bypass Flens																																	
23-2151																60—325 l/min																	
23-2251																75—450 l/min																	
23-2351																100—650 l/min																	
TacoSetter Hyline																																	
605.08410.000				10—25 l/min																													
605.08411.000							15—40 l/min																										
605.08412.000										20—60 l/min																							
605.08523.000										20—55 l/min																							
605.08524.000										30—80 l/min																							

Afbeeldingen zijn indicatief. De maatvoering en aansluiting kan afwijken per artikel.