

Finishing set for a wireless switch or push button with 4 control buttons and LED control, cream

100-90002



Finishing set with four control buttons to control a LED controller. Each control button has its own label: switch on/dim up, switch off/dim down, colour loop and favourites. This button, combined with the base for the wireless switch with four control buttons (410-00002), is particularly suitable for the control of the wireless 4-channel constant voltage controller (410-00121).



Technical data

Finishing set for a wireless switch or push button with 4 control buttons and LED control, cream.

- Number of buttons: 4
- Material finishing: polycarbonate (PC) + acrylic-styrene-acrylate (ASA)
- Type of control: push button
- Colour: cream
- Colour RAL (approximately): 1013
- Colour NCS (approximately): NCS S 1005-Y10R
- Surface treatment: coloured in mass
- Imprint indication: colour control
- Number of lenses: 0
- Fire safety:
 - all plastic components are self-extinguishing (comply with a filament test of 650°C)
 - all plastic components are halogen-free
- Dimensions (HxWxD): 44.5 mm x 44.5 mm x 8.6 mm
- Marking: CE