Extension for 32 buttons to a door loudspeaker

10-881-01



The extension module on the door loudspeaker allows you to add up to 32 buttons to your call tablet. The module is simply connected to the flush-mounting loudspeaker, type 10-880-01, via a connection cable. You can add a maximum of 5 extension modules to a door loudspeaker.


Technical data

Add-on module for door loudspeaker of max. 32 bell push-buttons/dwelling units – door loudspeaker is provided with terminals for connection of 32 potential-free bell push-buttons - connection of max. 6*(max. 208 housing units): can be integrated behind front panel caps provided by the architect: to each bell push button provided by the architect, 2 internal units can be assigned: several internal units can be assigned via the service set: confirmation tone when bell push button is pressed: the bell push button provided by the architect can also be used to switch the light: interchangeable memory for exchanging data between similar external units: 3-wire technique: input current: I(a) = 1.0mA when off: allowed ambient temperature: -20 to $50^{\circ}C$ - dimensions: $H 80 \times W 104 \times D 35mm$



CE

Dimensions





www.niko.eu 10-881-01 - 03-03-2022

Wiring diagram

