

Rosette for washstand deck-mounted spout with pop-up waste 60 x 60 x 9 mm - Champagne (22kt Gold)

SPARE PARTS

09 27 78 032



	Champagne (22kt Gold)	09 27 78 032-47
	Chrome	09 27 78 032-00
	Brushed Platinum	09 27 78 032-06
	Platinum	09 27 78 032-08
	Brushed Durabronze (23kt Gold)	09 27 78 032-28
	Brushed Dark Brass (PVD)	09 27 78 032-39
	Brushed Bronze (PVD)	09 27 78 032-42
	Brushed Dark Bronze (PVD)	09 27 78 032-43
	Brushed Champagne (22kt Gold)	09 27 78 032-46
	Cyprus	09 27 78 032-49
	Brushed Chrome	09 27 78 032-93
	Brushed Dark Platinum	09 27 78 032-99



Rosette for washstand deck-mounted spout with pop-up waste 60 x 60 x 9 mm
- Champagne (22kt Gold)

SPARE PARTS

09 27 78 032



Rosette for washstand deck-mounted spout with pop-up waste 60 x 60 x 9 mm
- Champagne (22kt Gold)

SPARE PARTS

09 27 78 032