Data Sheet | Item Number: 249-130

Syringe; Contents: 20 ml Alu-Plus contact paste

https://www.wago.com/249-130





Material dataFire load0 MJWeight35.3 g

Commercial data	
Product Group	2 (Terminal Block Accessories)
eCl@ss 10.0	27-14-11-92
eCl@ss 9.0	27-14-11-92
ETIM 8.0	EC002848
ETIM 7.0	EC002848
PU (SPU)	20 (5) pcs
Packaging type	Box
Country of origin	DE
GTIN	4017332133890
Customs tariff number	34039900000

Environmental Product Compliance	
RoHS Compliance Status	Compliant, No Exemption

Downloads

Environmental Product Compliance

Compliance Search

Environmental Product Compliance 249-130



Data Sheet | Item Number: 249-130

https://www.wago.com/249-130



Documentation

Bid Text			
249-130	17.05.2017	doc 23.50 KB	\perp
249-130	19.02.2019	xml 2.49 KB	<u>↓</u>

CAD/CAE-Data

CAE data

EPLAN Data Portal 249-130

 \perp

Installation Notes

Application



WAGO Rail-Mount Terminal Blocks (up to 4 mm²/12 AWG)

For each conductor entry: Insert nozzle of the "Alu-Plus" syringe in every open conductor entry hole (one after the other).



Press plunger down until "Alu-Plus" has filled all conductor entry holes.

Application



WAGO Lighting Connectors

Push nozzle of the "Alu-Plus" syringe first into the circular entry and then into the square conductor entry hole of the WAGO Lighting Connector.



Press the plunger down until "Alu-Plus" has filled both entry holes.

Note: Not suitable for higher temperature applications!

Application



1. Push nozzle of the "Alu-Plus" syringe into every open conductor entry hole (one after the other).



2. Press plunger down until "Alu-Plus" has filled all conductor entry holes.

Subject to changes. Please also observe the further product documentation!

Current addresses can be found at:: $\underline{www.wago.com}$

Page 2/2 Version 12.11.2023