

PLF-P-PK

Assembly instructions



Assembly instructions

- 1 Determine the desired position and hold the mounting plate level against the wall.
- 2 The elongated slotted holes in the centre are used to fix the mounting plate to the wall. Mark out the drilling points using these slotted holes.
- 3 Drill the marked holes and, if necessary, insert suitable wall plugs.
- 4 Secure the mounting plate firmly to the wall using suitable screws and wall plugs (not supplied).
- 5 Select the correct pair of holes for the fitting:
 - ⦿ Inner pair of holes: centre-to-centre distance 120 mm.
 - ⦿ Outer pair of holes: centre-to-centre distance 153 mm.
- 6 Position the fitting on the mounting plate and secure it with the screws supplied.
- 7 After installation, check that the fitting is securely fastened and correctly aligned.