

Differential pressure sensor Air dual

Differential pressure transmitter with two independent measuring systems. With 8 selectable ranges each and Modbus functionality. For monitoring over-, under- or the differential pressure of air and other nonflammable and non-aggressive gases. Typical application in HVAC systems for monitoring air filters, fans V-belts as well as the use in pressure differential systems. IP65 / NEMA 4X rated enclosure.





Type Overview

Туре	Measuring range [Pa] [Pa]	Communication	Output signal active pressure	Output signal active volumetric flow	Burst pressure
22ADP-154D	-1002500	Modbus RTU	05 V, 010 V	05 V, 010 V	40 kPa
Fechnical data					
	Electrical data	Nominal voltage		AC/DC 24 V	
		Nominal voltage i	range	AC 1929 V / DC 153	5 V
		Power consumpti	on AC	4.3 VA	
		Power consumpti	on DC	2.3 W	
		Electrical connect	ion	Pluggable spring loade 2.5 mm ²	d terminal block max
		Cable entry		Cable gland with strain	relief 2x ø6 mm
	Data bus communication	Communication		Modbus RTU	
		Number of nodes		Modbus see interface c	lescription
	Functional data	Sensor technolog	у	Piezo measuring eleme	ent
		Application		Air	
		Multirange		8 measuring ranges se	lectable
		Voltage output		2 x 05 V, 010 V, min	. resistance 10 kΩ
		Output signal active note		Output 05/10 V selectable with switch	
		Typical response time		Adjustable 0.8 s or 4.0 s	
	Measuring data	Measured values		Differential pressure Volumetric flow	
		Measuring fluid		Air and non-aggressive	gases
	Specification Flow	Measuring range	volumetric flow	Adjustable via Modbus Default setting: 0750' Selectable units: m³/h,	







Technical data

Specification Pressure	Measuring range pressure settings	Setting Range [Pa] Range [inch WC] Factor
		setting S0 02500 010
		S1 02000 08
		S2 01500 06
		S3 01000 04
		S4 0500 02
		S5 0250 01
		S6 0100 00.4
		S7 -100100 -0.40.4
	Accuracy	Deviation compared to the reference device
		measuring range ≤500 Pa: ±5 Pa measuring range >500 Pa: ±10 Pa
	Long town stability	
	Long term stability	±2.5% FSO (Full Scale Output) / 4 yr.
Safety data	Protection class IEC/EN	III, Safety Extra-Low Voltage (SELV)
	Power source UL	Class 2 Supply
	Degree of protection IEC/EN	IP65
	Degree of protection NEMA/UL	NEMA 4X
	Enclosure	UL Enclosure Type 4X
	EU Conformity	CE Marking
	Certification IEC/EN	IEC/EN 60730-1 and IEC/EN 60730-2-6
	Quality Standard	ISO 9001
	UL Approval	cULus acc. to UL60730-1A/-2-6, CAN/CSA
	Turne of earlier	E60730-1
	Type of action	Type 1
	Rated impulse voltage supply	0.8 kV
	Pollution degree	3
	Ambient humidity	Max. 95% RH, non-condensing
	Ambient temperature	-1050°C [15122°F]
	Fluid temperature	-1050°C [15122°F]
Materials	Cable gland	PA6, black
	Housing	Cover: PC, orange
		Bottom: PC, orange
		Seal: NBR70, black
		UV resistant

Safety notes



This device has been designed for use in stationary heating, ventilation and air-conditioning systems and must not be used outside the specified field of application. Unauthorised modifications are prohibited. The product must not be used in relation with any equipment that in case of a failure may threaten humans, animals or assets.

Ensure all power is disconnected before installing. Do not connect to live/operating equipment.

Only authorised specialists may carry out installation. All applicable legal or institutional installation regulations must be complied with during installation.

The device contains electrical and electronic components and must not be disposed of as household refuse. All locally valid regulations and requirements must be observed.





Manual zero-point calibrat	In normal operation zero-point calibration should be executed every 12 months. Attention! For executing zero-point calibration, the power supply must be connected one ho before. • Release both tube connectors from the pressure ports + and - • Press the button "Manual zero-point calibration" until the LED lights permanently • Wait until the LED flashes again and reinstall the tube connectors to the pressure ports (no + and -)		
Indicators and Operation			
Indicat	ors Depending on the device and the number of measured values, the disp scales. Parameters, such as the fading in/out of measured values, brigh function, are changed via the app or bus system. During the boot proce hardware versions are displayed.	ntness and traffic lig	
1234	1 Fault / sensor failure		
	2 Service / visual inspection due		
6→(Д×ସ‡ବି)	 TLF (traffic light function) active (thresholds for display colour change) 	es)	
6 → dP *	 4 Radio active (not available) 		
	 Status bar Measured value (* appears when TLF function is activated for this value) Unit of measure 		
	Onic of measure		
	Management value		
	8 Measured value		
Parts included	8 Measured value		
Parts included	8 Measured value Description	Туре	
Parts included		Type A-22D-A10 A-22AP-A08	
Parts included	Description Mounting plate L housing Duct connector kit, PVC tube 2 m, 2 connection elements (Plastic) for 22ADP Cable Gland with strain relief ø68 mm	A-22D-A10	
	Description Mounting plate L housing Duct connector kit, PVC tube 2 m, 2 connection elements (Plastic) for 22ADP Cable Gland with strain relief ø68 mm Dowels	A-22D-A10	
	Description Mounting plate L housing Duct connector kit, PVC tube 2 m, 2 connection elements (Plastic) for 22ADP Cable Gland with strain relief ø68 mm Dowels Screws	A-22D-A10	
Accessories	Description Mounting plate L housing Duct connector kit, PVC tube 2 m, 2 connection elements (Plastic) for 22ADP Cable Gland with strain relief ø68 mm Dowels Screws ies Description Pitot tube, Metal, L 40 mm, Tube connection 5 mm	A-22D-A10 A-22AP-A08 Type A-22AP-A02	
Accessories	Description Mounting plate L housing Duct connector kit, PVC tube 2 m, 2 connection elements (Plastic) for 22ADP Cable Gland with strain relief ø68 mm Dowels Screws ies Description Pitot tube, Metal, L 40 mm, Tube connection 5 mm Pitot tube, Metal, L 100 mm, Tube connection 5 mm	A-22D-A10 A-22AP-A08 Type A-22AP-A02 A-22AP-A04	
Accessories	Description Mounting plate L housing Duct connector kit, PVC tube 2 m, 2 connection elements (Plastic) for 22ADP Cable Gland with strain relief ø68 mm Dowels Screws ies Description Pitot tube, Metal, L 40 mm, Tube connection 5 mm	A-22D-A10 A-22AP-A08 Type A-22AP-A02	
Accessories	Description Mounting plate L housing Duct connector kit, PVC tube 2 m, 2 connection elements (Plastic) for 22ADP Cable Gland with strain relief ø68 mm Dowels Screws ies Description Pitot tube, Metal, L 40 mm, Tube connection 5 mm Pitot tube, Metal, L 100 mm, Tube connection 5 mm Connection adapter flex conduit, M20x1.5, for cable gland 1x 6 mm, Multipack 10 pcs. Connection adapter flex conduit, M20, for cable gland 2x 6 mm,	A-22D-A10 A-22AP-A08 Type A-22AP-A02 A-22AP-A04	
Accessories	Description Mounting plate L housing Duct connector kit, PVC tube 2 m, 2 connection elements (Plastic) for 22ADP Cable Gland with strain relief ø68 mm Dowels Screws ies Description Pitot tube, Metal, L 40 mm, Tube connection 5 mm Pitot tube, Metal, L 100 mm, Tube connection 5 mm Connection adapter flex conduit, M20x1.5, for cable gland 1x 6 mm, Multipack 10 pcs.	A-22D-A10 A-22AP-A08 Type A-22AP-A02 A-22AP-A04 A-22G-A01.1	

Optional accessories	Description	Туре
	Pitot tube, Metal, L 40 mm, Tube connection 5 mm	A-22AP-A02
	Pitot tube, Metal, L 100 mm, Tube connection 5 mm	A-22AP-A04
	Connection adapter flex conduit, M20x1.5, for cable gland 1x 6 mm, Multipack 10 pcs.	A-22G-A01.1
	Connection adapter flex conduit, M20, for cable gland 2x 6 mm, Multipack 10 pcs.	A-22G-A02.1
	Airflow volume probe 100 mm for round duct, min. 2 m/s, Probe length 100 mm	EXT-AC-R100
	Airflow volume probe 125 mm for round duct, min. 2 m/s, Probe length 125 mm	EXT-AC-R125
	Airflow volume probe 160 mm for round duct, min. 2 m/s, Probe length 160 mm	EXT-AC-R160
	Airflow volume probe 200 mm for round duct, min. 2 m/s, Probe length 200 mm	EXT-AC-R200





	Description	Туре
	Airflow volume probe 250 mm for round duct, min. 2 m/s, Probe length 250 mm	EXT-AC-R250
	Airflow volume probe 315 mm for round duct, min. 2 m/s, Probe length 315 mm	EXT-AC-R315
	Airflow volume probe 400 mm for round duct, min. 2 m/s, Probe length 400 mm	EXT-AC-R400
	Airflow volume probe 500 mm for round duct, min. 2 m/s, Probe length 500 mm	EXT-AC-R500
	Airflow volume probe 630 mm for round duct, min. 2 m/s, Probe length 630 mm	EXT-AC-R630
	Airflow volume probe 200 mm for rectangular duct, min. 2 m/s, Probe length 200 mm	EXT-AC-L200
	Airflow volume probe 250 mm for rectangular duct, min. 2 m/s, Probe length 250 mm	EXT-AC-L250
	Airflow volume probe 300 mm for rectangular duct, min. 2 m/s, Probe length 300 mm	EXT-AC-L300
	Airflow volume probe 400 mm for rectangular duct, min. 2 m/s, Probe length 400 mm	EXT-AC-L400
	Airflow volume probe 500 mm for rectangular duct, min. 2 m/s, Probe length 500 mm	EXT-AC-L500
	Airflow volume probe 600 mm for rectangular duct, min. 2 m/s, Probe length 600 mm	EXT-AC-L600
	Airflow volume probe 700 mm for rectangular duct, min. 2 m/s, Probe length 700 mm	EXT-AC-L700
Tools	Description	Туре
	Belimo Duct Sensor Assistant App	Belimo Duct Sensor Assistant App
	Bluetooth dongle for Belimo Duct Sensor Assistant App	A-22G-A05
	* Bluetooth dongle A-22G-A05	

Certified and available in North America, European Union, EFTA States and UK.



~	•
LAR	1100
Ser	vice

Tools connectionThis sensor can be operated and parametrised using the Belimo Duct Sensor Assistant App.When using the Belimo Duct Sensor Assistant App, the bluetooth dongle is required to enable
communication between the app and the Belimo sensor.


For the standard operation and parametrisation of the sensor the bluetooth dongle and the Belimo Duct Sensor Assistant App are not needed. The sensor will arrive pre-configured with the factory default settings shown above.

Requirement:

- Bluetooth dongle (Belimo Part No: A-22G-A05)
- Bluetooth-capable smartphone
- Belimo Duct Sensor Assistant App (Google Play & Apple App Store)

Procedure:

- Plug the Bluetooth dongle into the sensor via the Micro-USB connector or by means of the interface PCB
- Connect Bluetooth-capable smartphone with Bluetooth dongle
- Select parametrisation in the Belimo Duct Sensor Assistant App




Wiring diagram



Supply from isolating transformer.

The wiring of Modbus RTU (RS-485) is to be carried out in accordance with applicable regulations (www.modbus.org). The device has switchable resistors for bus termination. Modbus-GND: Supply and communication are not galvanically isolated. Connect earth signal of the devices with one another.





Detailed documentation


The separate document Sensor Modbus-Register informs about Modbus register, addressing, parity and bus termination (DIP1: address, DIP2: baud rate, parity, bus termination) In addition to the information on the bus, the following analog outputs are available:

AOU1: differential pressure 1

AOU2: differential pressure 2


If required, the outputs AOU1 and AOU2 can be changed to volumetric flow via bus system. The volumetric flow is calculated from the differential pressure, the k-factor and the height. Factory setting for the k-factor is 1.00 and for the height 330 metres above sea level. The values of the k-factor and the height can be changed via bus system.


Wiring RS-485 Modbus RTU





Dimensions





0.45	kg

Further documentation

Type 22ADP-154D

- Modbus Interface description
- Installation instructions