


Communicative linear actuator adjusting dampers and slide valves in technical building installations

- Actuating force 150 N
- Nominal voltage AC/DC 24 V
- Control modulating, communicative 2...10 V variable
- Position feedback 2...10 V variable
- Length of Stroke Max. 100 mm, adjustable in 20 mm increments
- Communication via Belimo MP-Bus
- Conversion of sensor signals





## **Technical data**

Electrical data	Nominal voltage	AC/DC 24 V
	Nominal voltage frequency	50/60 Hz
	Nominal voltage range	AC 19.228.8 V / DC 21.628.8 V
	Power consumption in operation	2.5 W
	Power consumption in rest position	1.3 W
	Power consumption for wire sizing	5 VA
	Connection supply / control	Cable 1 m, 4x 0.75 mm <sup>2</sup>

Parallel operation Yes (note the performance data)

Data bus communication Communicative control MP-Bus

> Number of nodes MP-Bus max. 8

**Functional data** Actuating force motor 150 N

Manual override

25%, 50%, 75% reduced Actuating force variable Operating range Y 2...10 V Input impedance 100 kΩ Start point 0.5...30 V Operating range Y variable End point 2.5...32 V Operating modes optional Open/close

3-point (AC only) Modulating (DC 0...32 V)

Position feedback U 2...10 V Position feedback U note Max. 0.5 mA

Position feedback U variable Start point 0.5...8 V End point 2.5...10 V

Position accuracy ±5%

Direction of motion motor selectable with switch Direction of motion note Y = 0 V: with switch 0 (retracted) / 1 (extended) Direction of motion variable electronically reversible

with push-button, can be locked Stroke 100 mm

Length of Stroke Max. 100 mm, adjustable in 20 mm increments Stroke limitation can be limited on both sides with mechanical

end stops Running time motor 150 s / 100 mm 70...270 s / 100 mm Running time motor variable

Adaptation setting range manual **UL** Approval

Hygiene test

Type of action

Pollution degree

Ambient humidity

Servicing

Weight

Ambient temperature

Storage temperature

Rated impulse voltage supply / control

cULus according to UL60730-1A, UL60730-2-14

The UL marking on the actuator depends on the production site, the device is UL-compliant

According to VDI 6022 Part 1 / SWKI VA 104-01, cleanable and disinfectable, low

Max. 95% RH, non-condensing

-30...50°C [-22...122°F] -40...80°C [-40...176°F]

maintenance-free

and CAN/CSA E60730-1

in any case

emission

Type 1

0.8 kV

0.53 kg

3



#### **Technical data Functional data** Adaptation setting range variable No action Adaptation when switched on Adaptation after pushing the manual override button Override control MAX (maximum position) = 100% MIN (minimum position) = 0% ZS (intermediate position, AC only) = 50% Override control variable MAX = (MIN + 32%)...100%MIN = 0%...(MAX - 32%)ZS = MIN...MAX Sound power level, motor 45 dB(A) Safety data Protection class IEC/EN III, Safety Extra-Low Voltage (SELV) Power source UL Class 2 Supply Degree of protection IEC/EN IP54 Degree of protection NEMA/UL NEMA 2 Enclosure UL Enclosure Type 2 EMC CE according to 2014/30/EU Certification IEC/EN IEC/EN 60730-1 and IEC/EN 60730-2-14

Weight



## Safety notes



- This device has been designed for use in stationary heating, ventilation and air-conditioning systems and must not be used outside the specified field of application, especially in aircraft or in any other airborne means of transport.
- Outdoor application: only possible in case that no (sea) water, snow, ice, insolation or
  aggressive gases interfere directly with the device and that it is ensured that the ambient
  conditions remain within the thresholds according to the data sheet at any time.
- Only authorised specialists may carry out installation. All applicable legal or institutional installation regulations must be complied with during installation.
- The device may only be opened at the manufacturer's site. It does not contain any parts that can be replaced or repaired by the user.
- · Cables must not be removed from the device.
- The rotary supports and coupling pieces available as accessories must always be used if transverse forces are likely. In addition, the actuator must not be tightly bolted to the application. It must remain movable via the rotary support (refer to «Installation notes»).
- If the actuator is exposed to severely contaminated ambient air, appropriate precautions
  must be taken on the system side. Excessive deposits of dust, soot etc. can prevent the gear
  rod from being extended and retracted correctly.
- If not installed horizontally, the maual override button may only be actuated when there is no pressure on the gear rod.
- To calculate the actuating force required for air dampers and slide valves, the specifications supplied by the damper manufacturers concerning the cross- section and the design, as well as the installation situation and the ventilation conditions must be observed.
- If a rotary support and/or coupling piece is used, actuation force losses are to be expected.
- The device contains electrical and electronic components and must not be disposed of as household refuse. All locally valid regulations and requirements must be observed.

#### **Product features**

## Operating mode

Conventional operation:

The actuator is connected with a standard control signal of 0...10 V and drives to the position defined by the control signal. Measuring voltage U serves for the electrical display of the damper position 0...100% and as control signal for other actuators.

Operation on Bus:

The actuator receives its digital control signal from the higher level controller via the MP-Bus and drives to the position defined. Connection U serves as communication interface and does not supply an analogue measuring voltage.

The actuator has a seal closing function. The mechanical end stop is actively approached as soon as the control signal < DC 2.1 V or > DC 9.9 V. As soon as the control signal is again > DC 2.2 V or < DC 9.8 V, the actuator drives to the position defined by the control signal in the adapted range.

#### **Converter for sensors**

Connection option for a sensor (passive or active sensor or switching contact). The MP actuator serves as an analogue/digital converter for the transmission of the sensor signal via MP-Bus to the higher level system.

#### Parametrisable actuators

The factory settings cover the most common applications. Single parameters can be modified with the Belimo service tools MFT-P or ZTH EU.

## Simple direct mounting

The actuator can be directly connected with the application using the enclosed screws. The head of the gear rod is connected to the moving part of the ventilating application individually on the mounting side or with the Z-KS2 coupling piece provided.

## Manual override

Manual override with push-button possible (the gear train is disengaged for as long as the button is pressed or remains locked).



#### **Product features**

#### Adjustable stroke

If a stroke limitation will be adjusted, the mechanical operating range on this side of the gear rod can be used starting with an extension length of 20 mm and then can be limited respectively in increments of 20 mm by means of mechanical end stops Z-AS2.


## High functional reliability

The actuator is overload protected, requires no limit switches in intermediate positions and automatically stops when the end stop is reached (at rest).

## Home position

The first time the supply voltage is switched on, i.e. at the time of commissioning, the actuator carries out a synchronisation. The synchronisation is in the home position (0%).

The actuator then moves into the position defined by the control signal.



## Adaptation and synchronisation

An adaptation can be triggered manually by pressing the "Adaptation" button or with the PCTool. Both mechanical end stops are detected during the adaptation (entire setting range).

Automatic synchronisation after pressing the manual override button is configured. The synchronisation is in the home position (0%).

The actuator then moves into the position defined by the control signal.

A range of settings can be adapted using the PC-Tool (see MFT-P documentation)

## Accessories

Gateways	Description	Туре		
	Gateway MP to BACnet MS/TP	UK24BAC		
	Gateway MP to Modbus RTU	UK24MOD		
Electrical accessories	Description	Туре		
	Signal converter voltage/current 100 kΩ 420 mA, Supply AC/DC 24 V	Z-UIC		
	Positioner for wall mounting	SGA24		
	Positioner for built-in mounting	SGE24		
	Positioner for front-panel mounting	SGF24		
	Positioner for wall mounting	CRP24-B1		
	MP-Bus power supply for MP actuators	ZN230-24MP		
Mechanical accessories	Description	Туре		
	End stop kit, Multipack 20 pcs.	Z-AS2		
	Rotary support, for linear actuator, for compensation of transverse	Z-DS1		
	forces			
	Coupling piece M6	Z-KS2		
Tools	Description	Туре		
	Service tool, with ZIP-USB function, for parametrisable and	ZTH EU		
	communicative Belimo actuators, VAV controller and HVAC performance devices			
	Belimo PC-Tool, Software for adjustments and diagnostics	MFT-P		
	Adapter for Service-Tool ZTH	MFT-C		
	Connecting cable 5 m, A: RJ11 6/4 ZTH EU, B: 6-pin for connection to service socket	ZK1-GEN		
	Connecting cable 5 m, A: RJ11 6/4 ZTH EU, B: free wire end for connection to MP/PP terminal	ZK2-GEN		

#### **Electrical installation**



Supply from isolating transformer.

Parallel connection of other actuators possible. Observe the performance data.





## **Electrical installation**

#### Wire colours:

- 1 = black
- 2 = red
- 3 = white
- 5 = orange

# Wiring diagrams






1	2	3		
	_~	2 V	¥	<b></b>
	~	10 V	Ŧ	₩


## **Functions**

## Functions with basic values (conventional mode)

Override control with AC 24 V with relay contacts





Minimum limit with positioner SG..




Override control with AC 24 V with Control remotely 0...100% with rotary switch

positioner SG..





Primary/secondary operation (position-dependent)



Caution:

to DC 2...10 V.


The operating range must be set

The 500 Ohm resistor converts the 4...20 mA current signal to a voltage signal DC 2...10 V.



## Functions with basic values (conventional mode)

Control with 4...20 mA via external resistor



Functional check

# 1 2 3 5 Y U

## **Procedure**

- 1. Connect 24 V to connections 1 and 2
- 2. Disconnect connection 3:
- with direction of rotation L:


Actuator rotates to the left

- with direction of rotation R:

Actuator rotates to the right

- 3. Short-circuit connections 2
- Actuator runs in opposite direction

## MP-Bus Network topology



network topology (star, ring, tree or mixed forms are permitted).


There are no restrictions for the

Supply and communication in one and the same 3-wire cable

- no shielding or twisting necessary
- no terminating resistors required

## Functions with specific parameters (Parametrisation necessary)


Connection on the MP-Bus



Max. 8 MP-Bus nodes




## Functions with specific parameters (Parametrisation necessary)





- Supply AC/DC 24 V
- Output signal 0...10 V (max. 0...32 V)
- Resolution 30 mV

## Connection of external switching contact



- Switching current 16 mA @ 24
- Start point of the operating range must be parametrised on the MP actuator as ≥0.5 V







Ni1000	−28+98°C	8501600 Ω <sup>2)</sup>	
PT1000 -35+155°C		8501600 Ω <sup>2)</sup>	
NTC	-10+160°C 1)	200 Ω60 kΩ <sup>2)</sup>	

- 1) Depending on the type
- 2) Resolution 1 Ohm Compensation of the measured value is recommended

Override control and limiting with AC 24 V with relay contacts



## Control open/close






## **Functions**

## Functions with specific parameters (Parametrisation necessary)


Override control and limiting with AC 24 V with rotary switch




## Caution:

The "Close" function is only guaranteed if the start point of the operating range is defined as min. 0.5 V.

## Control 3-point with AC 24 V



## Operating controls and indicators



## 1 Direction of stroke switch

Switch over: Direction of stroke changes

## 2 Push-button and LED display green

Off: No power supply or malfunction

On: In operation

Press button: Triggers stroke adaptation, followed by standard mode

## 3 Push-button and LED display yellow

Off: Standard mode

On: Adaptation or synchronisation process active

Flickering: MP-Bus communication active

Flashing: Request for addressing from MP client

Press button: Confirmation of the addressing

## Manual override button

Press button: Gear train disengages, motor stops, manual override possible

Release Gear train engages, synchronisation starts, followed by standard

button: mode

## 5 Service plug

For connecting parametrisation and service tools

## Check power supply connection

2 Off and 3 On Possible wiring error in power supply

## **Installation notes**



If a rotary support and/or coupling piece is used, losses in the actuation force losses are to be expected.



## **Installation notes**

## Applications without transverse forces

The linear actuator is screwed directly to the housing at three points. Afterwards, the head of the gear rod is fastened to the moving part of the ventilation application (e.g. damper or slide valve).

## Applications with transverse forces


Connect the coupling piece with the internal thread (Z-KS2) to the head of the gear rod. Screw the rotary support (Z-DS1) to the ventilation application. Afterwards, the linear actuator is screwed to the previously mounted rotary support with the enclosed screw. Then, the coupling piece, which is mounted to the head of the gear rod, is attached to the moving part of the ventilating application (e.g. damper or slide valve). The transverse forces can be compensated for to a certain limit with the rotary support and/or coupling piece. The maximum permissible swivel angle of the rotary support and coupling piece is 10°, laterally and upwards.

## Service


## **Tool connection**

The actuator can be parametrised by ZTH EU via the service socket. For an extended parametrisation the PC tool can be connected.

## Connection ZTH EU / PC-Tool



## **Dimensions**





## **Further documentation**

- Overview MP Cooperation Partners
- Tool connections
- Introduction to MP-Bus Technology

# **Application notes**

• For digital control of actuators in VAV applications patent EP 3163399 must be considered.