



NKCR.E48139 Auxiliary Devices

[Page Bottom](#)

Auxiliary Devices

[See General Information for Auxiliary Devices](#)

ABB STOTZ-KONTAKT GMBH
EPPELHEIMER STR 82
69123 HEIDELBERG, GERMANY

E48139

Interface units auxiliary devices, open type, Cat. No. 95. followed by 049-052, 087-091, 095-109, 136-141; Cat. No. 96.053, 96.079, 96.080, 98.018, 98.028 or 98.029.

Open-type overload relays, Type T25DU followed by .16, .25, .4, .63, 1.0, 1.4, 1.8, 2.4, 3.1, 4.0, 5.0, 6.5, 8.5, 11, 14, 19, 25 or 32.

Type TA25DU followed by .16, .25, .4, .63, 1.0, 1.4, 1.8, 2.4, 3.1, 4.0, 5.0, 6.5, 8.5, 11, 14, 19, 25 or 32; Cat. No. 1SAZ211201R10 followed by 05, 09, 13, 17, 21, 23, 25, 28, 32, 33, 35, 38, 40, 43, 45, 47, 51 or 53, for Class 10; Type TA25DU followed by 1.8, 2.4, 3.1, 4.0, 5.0, 6.5, 8.5, 11, 14, 19, 25 or 32; Cat. No. 1SAZ211401R10 followed by 25, 28, 32, 33, 35, 38, 40, 43, 45, 47, 51 or 53 for Class 20.

Type TA42DU followed by 18-42A; Type 1SAZ311201R100 followed by 1, 2 or 3; Type TA42DU followed by 25, 32 or 42; Cat. No. 1SAZ311401R100 followed by 1, 2 or 3.

Type TA75DU 25-80A; Cat. No. 1SAZ321201R100, followed by 1-6 incl. for Class 10; Type TA75DU 25-80A; Cat. No. 1SAZ321401R100 followed by 1-6 incl., for Class 20.

Type T80DU followed by 42, 52, 63 or 80; Type TA80DU followed by 42, 52, 63, or 80; Cat. No. 1SAZ 331 201 R100 followed by 3, 4, 5 or 6 for class 10; Type TA80DU followed by 42, 52, 63, or 80; Cat. No. 1SAZ 331 401 R100 followed by 3, 4, 5 or 6 for class 20.

Type TA110DU90 or TA110DU110; Cat. No. 1SAZ411201R100 followed by 1 or 2.

Cat. No. T16, TA40 or TF42 followed by 0.13, 0.17, 0.23, 0.31, 0.41, 0.55, 0.74, 1.0, 1.3, 1.7, 2.3, 3.1, 4.2, 5.7, 7.6, 10, 13, 16, 20, 24, 29, 35 or 38 (20, 24, 29, 35 and 38 only for TF and TA).

Type TA200DU, followed by 90, 110, 135, 150, 175 or 200.

Type TA450, followed by DU or SU, followed by 60, 80, 105, 140, 185, 235, 310 or 400; Type T900, followed by DU or SU, followed by 375, 500, 650 or 850.

Open-type, Terminal block adapters, AB25/25, AB25/32, AB80, GJZ4201110R001; AB200, DB25/25, DB25/32, DB80 or DB200.

Overload relay, Electronic, Open-type: Cat. No. E16DU or EF19 followed by 0.32, 1.0, 2.7, 6.3 or 18.9; Cat. No. E45DU or EF45 followed by 30 or 45; Cat. Nos. E80DU, E140DU, E200DU, E320DU, E500DU, E800DU.

Accessory - Mechanical reset, Model 1TGB100038; Terminal adapters Types DB16, DB45E, DB80E, DB145E.

Transformer modules, Models P30 to P80 incl. followed by 102, 111, 120, 202, 211, 220, 302, 311, 320, 402, 411 or 420.

Open type, Auxiliary devices, Electronic Relays, Model GHC followed by 105 or 106, followed by 0201, followed by R0001, R0002, R0003, R0004, R0005 or R0006.

Auxiliary devices, overload relay, open Type: Cat. Nos. UMC22 and UMC100 may be followed by additional suffixes.

Model GHC, followed by 105 or 106, followed by 0201, 0301, 1201 or 1301, followed by R0011, R0012, R0013, R0014, R0015 or R0016.

Model GHC 461 02, followed by 01, 02, 03, 04, 05, 06, 07, 08, 09, 10, 11 or 12, followed by R0004.

Model GHC 461 10, followed by 01, 02 or 03, followed by R0001, R0003 or R0004.

Model GHC 461 1304, followed by R0001, R0002, R0003 or R0004.

Model GHC 462 00, followed by 01, 02, 03, 04, 05, 06, 07, 08, 09, 10 or 11, followed by R0001, R0003 or R0004.

Model GHC 462 10, followed by 02, 03 or 04, followed by R0001, R0003 or R0004.

Model GHC 463 0001, followed by R0001, R0002, R0003 or R0004.

Model GHC 464 or GHC 465, followed by 0101, followed by R0001, R0003 or R0004.

Auxiliary Devices, Open Type: Cat. No. K6 or KC6 followed by 40E, 31Z or 22Z, followed by 1.4, 1.7, 2.4 or 2.48.

Auxiliary Switches, Cat. No. CA6 or CAF6 followed by -11K, 11E, -02 or 11M-20, followed by E, K, M or N.

Accessories - I/O modules, Models DX111, DX122 and VI150.

Accessory - Single mounting kits, Models DB16 and DB42.

Last Updated on 2011-12-19

[Questions?](#)

[Print this page](#)

[Notice of Disclaimer](#)

[Page Top](#)

© 2012 UL LLC

The appearance of a company's name or product in this database does not in itself assure that products so identified have been manufactured under UL's Follow-Up Service. Only those products bearing the UL Mark should be considered to be Listed and covered under UL's Follow-Up Service. Always look for the Mark on the product.

UL permits the reproduction of the material contained in the Online Certification Directory subject to the following conditions: 1. The Guide Information, Designs and/or Listings (files) must be presented in their entirety and in a non-misleading manner, without any manipulation of the data (or drawings). 2. The statement "Reprinted from the Online Certifications Directory with permission from UL" must appear adjacent to the extracted material. In addition, the reprinted material must include a copyright notice in the following format: "© 2012 UL LLC".