Data Sheet | Item Number: 2002-478

Staggered jumper; 8-way; insulated; light gray

https://www.wago.com/2002-478





Color: Ight gray

Electrical data

Ratings per IEC/EN		
Nominal voltage (III/3)	400 V	
Rated impulse voltage (III/3)	6 kV	
Rated current	25 A	

Physical data

Width	40.3 mm / 1.587 inches
Jumper assignment	1-2-3-4-5-6-7-8

Material data	
Note (material data)	
	Information on material specifications can be found here
Color	light gray
Fire load	0.103 MJ
Weight	4.9 g

Commercial data	
Product Group	22 (TOPJOB S)
eCl@ss 10.0	27-14-11-40
eCl@ss 9.0	27-14-11-40
ETIM 8.0	EC000489
ETIM 7.0	EC000489
PU (SPU)	25 pcs
Packaging type	Bag
Country of origin	DE
GTIN	4055143692311
Customs tariff number	85366990990

Data Sheet | Item Number: 2002-478

https://www.wago.com/2002-478



Environmental Product Compliance

RoHS Compliance Status Compliant, No Exemption

Approvals / Certificates

Declarations of conformity and manufacturer's declarations



Approval	Standard	Certificate Name
Railway	-	Railway Ready

WAGO GmbH & Co. KG

Downloads

Environmental Product Compliance

Compliance Search

Environmental Product

Compliance 2002-478

Documentation

Additional Information		
Technical Section	pdf 2240.62 KB	<u> </u>

Bid Text			
2002-478	19.02.2019	xml 2.62 KB	$\overline{\downarrow}$
2002-478	27.04.2017	doc 24.00 KB	\perp

CAD/CAE-Data

CAD data

2D/3D Models 2002-478

C	/	١E	(b	a	ta

EPLAN Data Portal 2002-478

WSCAD Universe 2002-478

ZUKEN Portal 2002-478



Data Sheet | Item Number: 2002-478

https://www.wago.com/2002-478



Installation Notes

Commoning



Orient the staggered jumpers' red stripes on the inside.

Insert the staggered jumper and push down until it hits the backstop.



Commoning two potentials in one single jumper slot via extremely slim staggered jumpers.


Commoning



Orient the staggered jumpers' red stripes on the inside.

Insert the staggered jumper and push down until it hits the backstop.

Commoning



Removing a staggered jumper: Insert the operating tool between the staggered jumpers, then lift up the jumper.

Commoning



Staggered jumper (seven contacts)

Breaking off contact lugs. Individual jumper contacts can be broken off by bending them. The remaining piece of insulation will meet requirements for clearances and creepage distances.



Staggered jumpers

Marking with a felt-tip pen.



Staggering jumpers in a single jumper

Custom staggered jumpers can be created, e.g., for bridging over a terminal block with a different potential. Make sure that only one contact lug is in contact with the terminal block.

The contact lugs of the customized staggered jumpers contact the terminal blocks via the gaps created in the second jumper. Insert and press the ready-made jumper assembly into the jumper slot until it hits the backstop.

Subject to changes. Please also observe the further product documentation!

Current addresses can be found at:: www.wago.com

Page 3/3 Version 08.11.2023